

Lauben 2000BW

Lauben Rice Cooker 2000BW User Manual

Model: 2000BW

INTRODUCTION

Thank you for choosing the Lauben Rice Cooker 2000BW. This multifunctional appliance is designed to simplify your cooking with its 12 preset programs, digital display, and non-stick ceramic coating. This manual provides detailed instructions for safe operation, maintenance, and troubleshooting to ensure you get the most out of your new rice cooker.

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance and keep them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the voltage indicated on the appliance corresponds to your mains voltage.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children. Close supervision is necessary when the appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only accessories recommended by the manufacturer.
- Do not place the appliance on or near a hot gas or electric burner, or in a heated oven.
- Always unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool before putting on or taking off parts.
- Exercise extreme caution when moving an appliance containing hot oil or other hot liquids.
- The inner pot has a non-stick coating. Avoid using metal utensils that could scratch the surface.
- The exterior of the rice cooker features Cool-Touch technology, but caution should still be exercised around steam vents and the lid during operation.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Lauben Rice Cooker 2000BW.



Figure 1: Lauben Rice Cooker 2000BW, a sleek black appliance with a digital display and wooden base accents.



Figure 2: Included accessories: non-stick inner pot, stainless steel steam insert, measuring cup, and rice spoon.

Der Innentopf des Reiskochers ist mit einer **hochwertigen Keramikoberfläche beschichtet, die keinen unerwünschten Nachgeschmack oder unangenehme Aromen an die zubereiteten Speisen abgibt.**




Figure 3: The inner pot features a high-quality ceramic non-stick coating for easy cooking and cleaning.



Schön und praktisch

- Dekorelemente aus Holz werden Ihre Küche schmücken.
- Der praktische Griff sorgt für eine einfache Handhabung.

Figure 4: The convenient carrying handle makes the rice cooker easy to transport.

Components:

- **Main Unit:** Houses the heating element and control panel. Features a convenient carrying handle.
- **Digital Display:** Touch screen interface for program selection and time adjustment.
- **Inner Pot:** 2-liter capacity with high-quality ceramic non-stick coating.
- **Stainless Steel Steam Insert:** For healthy steaming of vegetables, fish, and more.
- **Measuring Cup:** For precise measurement of ingredients.
- **Rice Spoon:** Designed for use with the non-stick inner pot.
- **Lid:** Seals the cooking chamber, with a steam release valve.

SETUP

Unpacking and Initial Cleaning:

1. Carefully remove all packaging materials and promotional labels from the rice cooker.
2. Wash the inner pot, steam insert, measuring cup, and rice spoon with warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.

Placement:

- Place the rice cooker on a stable, flat, heat-resistant surface.
- Ensure there is adequate ventilation around the appliance, especially around the steam vent.
- Keep it away from direct sunlight, heat sources, and moisture.

OPERATING INSTRUCTIONS

The Lauben Rice Cooker 2000BW features an intuitive digital display and 12 preset programs for versatile cooking.



Figure 5: Close-up of the digital touch display, showing program options and time.

Using the Digital Display and Programs:

1. **Preparation:** Add desired ingredients to the inner pot. Ensure the inner pot is properly seated in the main unit. Close the lid securely.
2. **Power On:** Plug the rice cooker into a suitable power outlet. The digital display will illuminate.
3. **Select Program:** Use the touch controls on the digital display to navigate through the 12 preset programs.



Dampfeinsatz im Lieferumfang enthalten

Die gesündeste Art der Nahrungszubereitung,
ohne Fett und Zucker.

Figure 6: Visual representation of the 12 precise preset programs available.

The 12 preset programs include:

- Rice
- Rice "Clay" (Claypot Rice)
- Brown Rice
- Soup
- Porridge
- Cakes
- Legumes (Beans)
- Yogurt
- Curry
- Steam
- Stew
- Warm (Reheat)

- Start Cooking:** Once a program is selected, the cooking process will begin automatically or after a confirmation press, depending on the program.
- Manual Program Setting:** For more control, you can manually adjust cooking times and temperatures for certain programs if the option is available on the display. Refer to the display interface for specific manual adjustment options.
- Start Delay:** Utilize the start delay function to program the rice cooker to begin cooking at a later time, ensuring your meal is ready when you need it.
- Temperature Retain (Keep Warm):** After cooking is complete, the rice cooker will automatically switch to a "Keep Warm" mode to maintain the food's temperature until serving.
- Automatic Shutdown:** The appliance is equipped with an automatic shutdown feature for safety and energy efficiency once the cooking cycle is complete or after a period of inactivity in "Keep Warm" mode.

Steaming Function:

To use the steaming function, place the stainless steel steam insert into the inner pot with the appropriate amount of water below it. Place your food on the steam insert, close the lid, and select the "Steam" program.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your Lauben Rice Cooker and ensure optimal performance.

- Always unplug** the rice cooker from the power outlet and allow it to cool completely before cleaning.
- Inner Pot:** The ceramic non-stick inner pot is designed for easy cleaning. It can be washed by hand with warm, soapy water and a soft sponge, or placed in the dishwasher. Avoid abrasive cleaners or scouring pads that could damage the non-stick surface.
- Steam Insert, Measuring Cup, and Spoon:** These accessories can be washed by hand with warm, soapy water or placed in the dishwasher.
- Exterior:** Wipe the exterior of the main unit with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure no water enters the electrical components.
- Lid:** Clean the lid and steam vent regularly to prevent blockages and ensure proper steam release.
- Storage:** Store the rice cooker in a dry place when not in use.

TROUBLESHOOTING

If you encounter any issues with your rice cooker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice is too hard or undercooked.	Insufficient water; incorrect rice-to-water ratio; lid not properly closed.	Add more water according to rice type; ensure lid is sealed; use correct measuring cup.
Rice is too soft or mushy.	Too much water; rice soaked for too long.	Reduce water amount; do not soak rice for extended periods unless specified.
Rice cooker does not turn on.	Not plugged in; power outage; faulty outlet.	Check power connection; test outlet with another appliance; contact customer support if issue persists.
Steam leaking from lid.	Lid not properly closed; seal damaged; steam vent blocked.	Ensure lid is securely closed; inspect and clean lid seal and steam vent.

Problem	Possible Cause	Solution
Food sticks to the inner pot.	Non-stick coating damaged; insufficient oil (for certain recipes).	Avoid metal utensils; use a small amount of cooking oil if recipe allows.

If the problem persists after trying these solutions, please contact Lauben customer support for assistance.

SPECIFICATIONS

Detailed technical specifications for the Lauben Rice Cooker 2000BW.

Feature	Detail
Brand	Lauben
Model Number	2000BW
Color	Black
Capacity	2 Liters
Power / Wattage	400 watts
Voltage	220 Volts
Material	Stainless Steel (inner pot, steam insert), Ceramic (inner pot coating)
Auto Shutoff	Yes
Special Features	Automatic Shut Off, Carrying Handle, Cool-Touch Exterior, Non-Stick, Timer, Digital Display, 12 Preset Programs, Start Delay, Temperature Retain
Item Weight	2.57 Kilograms
Product Dimensions	21.5D x 26W x 23.5H centimeters
Lid Material	Ceramic (as per product specifications, likely referring to inner pot coating)
Product Care Instructions	Dishwasher Safe (inner pot), Hand Wash

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Lauben website. Keep your proof of purchase for any warranty claims.

For technical assistance or inquiries, please contact Lauben customer service.




© 2025 Lauben. All rights reserved.

Related Documents

 <p>Lauben Low Sugar Rice Cooker 3000AT LAUBEN LOW SUGAR RICE COOKER 3000AT LAUBEN LOW SUGAR RICE COOKER 3000WT</p>	<p><u>Lauben Low Sugar Rice Cooker 3000AT/3000WT User Manual</u></p> <p>Comprehensive user manual for the Lauben Low Sugar Rice Cooker 3000AT and 3000WT, covering safety instructions, product overview, operating procedures, cleaning, maintenance, and troubleshooting.</p>
 <p>5 zdravých a jednoduchých recipitů k Lauben Low Sugar Rice Cooker 1500</p> <p>Lauben</p>	<p><u>Lauben Low Sugar Rice Cooker 1500: 5 Healthy & Simple Recipes</u></p> <p>Explore five easy and healthy recipes designed for the Lauben Low Sugar Rice Cooker 1500, including Oatmeal Porridge, Hong Kong Clay Pot Rice, Spanish Chicken with Rice, Yellow Pea Soup, and Vegetable Thai Curry.</p>
 <p>Lauben red dot award IF LAUBEN LOW SUGAR RICE COOKER 1500AT LAUBEN LOW SUGAR RICE COOKER 1500WT</p>	<p><u>Lauben Low Sugar Rice Cooker 1500AT/1500WT User Manual</u></p> <p>Comprehensive user manual for the Lauben Low Sugar Rice Cooker models 1500AT and 1500WT, covering safety instructions, product features, operation, maintenance, and troubleshooting.</p>
 <p>Lauben red dot award IF LAUBEN LOW SUGAR RICE COOKER 1500AT LAUBEN LOW SUGAR RICE COOKER 1500WT</p>	<p><u>Lauben Low Sugar Rice Cooker 1500AT & 1500WT: User Manual & Operating Guide</u></p> <p>Get the official user manual for Lauben Low Sugar Rice Cooker models 1500AT and 1500WT. This guide covers specifications, safety, operation, maintenance, and troubleshooting for healthier rice cooking. Visit lauben.com for more.</p>

Documents - Lauben – 2000BW



LAUBEN MULTIFUNCTION RICE COOKER
2000BW

Benutzeranleitung - Übersetzung der Originalbenutzeranleitung | User Guide - translation of the original user guide
Účetnictví uživatelského manuálu | Používateľská príručka - preklad pôvodnej užívateľskej príručky | Instrukcja obsługi
- prevedená z originálnej užívateľskej príručky | Korisnički vodič - preveden izvornog korisničkog vodiča

[\[pdf\] User Manual Guide](#)

561690 LBRCMMRC200BA ryzovar MULTI screen bemova Manual Multifunction Rice Cooker 2000BW

Lauben lauben multifunction rice cooker 2000bw |||

DE EN CZ SK LAUBEN MULTIFUNCTION RICE COOKER PL **2000BW** HU SL HR


DE Lauben Multifunction Rice Cooker **2000BW** bersetzung der

Originalbenutzeranleitung 3 EN Lauben Multifunction Rice Cooker **2000BW**

Translation of the original user guide 14 CZ Lauben Multifunction Rice Cooker

2000BW Uziva...

lang:de **score:48** filesize: 1.49 M page_count: 84 document date: 2024-05-10



LAUBEN MULTIFUNCTION RICE COOKER
2000BW

Benutzeranleitung - Übersetzung der Originalbenutzeranleitung | User Guide - translation of the original user guide
Účetnictví uživatelského manuálu | Používateľská príručka - preklad pôvodnej užívateľskej príručky | Instrukcja obsługi
- prevedená z originálnej užívateľskej príručky | Korisnički vodič - preveden izvornog korisničkog vodiča

[\[pdf\] User Manual Guide Declaration of Conformity](#)

561690 LBRCMMRC200BA ryzovar MULTI screen bemova LAUBEN MULTIFUNCTION RICE COOKER

2000BWDas Unternehmen elem6 s r o erklärt hiermit dass der Lauben Multifunktions Reiskocher

2000BW den grundlegenden Anforderungen und anderen relevanten Lauben Multifunction Rice Cooker

CZ SK EN DE HUdwn alza cz manual 138727 NÁjvod k použitíovar ÄernÄ½LAUBEN

2000BWRÄ½Ä¾ovar ÄernÄ½ DATARTDas relevanten v1Lauben HUdataart document 7 doc

6785700dwn ||| DE EN CZ SK LAUBEN MULTIFUNCTION RICE COOKER PL 2000BW HU SL HR DE

Lauben Multifunction Rice Cooker 2000BW bersetzung der Originalbenutzeranleitung 3 EN Lauben

Multifunction Rice Cooker 2000BW Translation of the original user guide 14 CZ La

DE EN CZ SK LAUBEN MULTIFUNCTION RICE COOKER PL **2000BW** HU SL HR

DE Lauben Multifunction Rice Cooker **2000BW** bersetzung der

Originalbenutzeranleitung 3 EN Lauben Multifunction Rice Cooker **2000BW**

Translation of the original user guide 14 CZ Lauben Multifunction Rice Cooker

2000BW Uziva...

lang:de **score:44** filesize: 1.49 M page_count: 84 document date: 2024-05-10

[\[pdf\] Declaration of Conformity](#)

Prezentace aplikace PowerPoint Martin Šmehlík Lauben Multifunction Rice Cooker 2000BW NÁjvod 579

59 kB RyÄ¾ovar Nay sk 3185383cdn nay images orig 3 ProduktovÄ½ list RÄ½Ä¾ovar

ÄernÄ½RÄ½Ä¾ovar ÄernÄ½ DATARTLauben skv1dataart cz document 5 4 doc 6783453cdn ||| |||

Lauben Multifunction Rice Cooker 2000BW Elegantn spolecnk pro snadn a zdrav vaen KSP Keramick nepilnav povrch Vnitn hrnec rzovaru je potazen prmiov keramickm povrchem, kter do pipravovanch pokrm neuvoluje zdhou nezdouc pachu ani nepjemu

Lauben Multifunction Rice Cooker **2000BW** Elegantn spolecnk pro snadn a zdrav vaen KSP Keramick nepilnav povrch Vnitn hrnec rzovaru je potazen prmiov keramickm povrchem, kter do pipravovanch pokrm neuvoluje zdhou nezdouc pachu ani nepjemu aromata. Povrch je navc nepilnav, takze se nic nepipl. 12 f...

lang:hr **score:29** filesize: 579.59 K page_count: 4 document date: 2024-09-04



Elegantn spolecnk pro
snadn a zdrav vaen

