

ZQS1222

Sing-E Mini Portable Wireless Speaker with Wireless Charger

Model: ZQS1222

INTRODUCTION

The Sing-E Mini Portable Wireless Speaker with Wireless Charger ZQS1222 is designed to provide a versatile audio and charging solution. It features a sleek, circular design with an integrated LED display, wireless charging capabilities, and robust sound quality. This manual will guide you through the proper use and care of your device.

Key Features

- **Wireless Charging:** Supports wireless charging for compatible devices.
- **Compact Design:** Unique circular shape with a vibrant LED light display.
- **Multimedia Functionality:** Includes a digital clock display.
- **Versatile Connectivity:** Bluetooth and auxiliary cable support for audio streaming.
- **Rechargeable Battery:** Built-in battery for portable operation.

WHAT'S IN THE BOX

- Sing-E Mini Portable Wireless Speaker (ZQS1222)
- Power Cable



T4M

Image: The Sing-E Mini Portable Wireless Speaker ZQS1222 shown with its retail packaging and included power cable.

PRODUCT OVERVIEW

Familiarize yourself with the various parts and controls of your speaker.



Image: Front view of the speaker, highlighting the LED display and control buttons.



Image: Top view of the speaker, showing the integrated wireless charging pad.



Image: Back view of the speaker, illustrating the various input ports including AUX, USB, TF card, and DC IN.

SETUP

Charging the Device

1. Connect the provided power cable to the DC IN port on the speaker and to a suitable power adapter (not included) or USB port.
2. Allow the speaker to fully charge before its first use. The charging indicator will provide status.

Initial Power On

1. Press and hold the power button located on the top panel of the speaker until the LED display illuminates.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode (indicated by 'bt' on the display). If not, press the Mode button to switch.
2. Enable Bluetooth on your smartphone, tablet, or other audio device.
3. Search for available devices and select "ZQS1222" from the list.
4. Once connected, the speaker will emit an audible confirmation, and you can begin streaming audio.

Wireless Charging Function

To use the wireless charging feature, place your Qi-compatible device directly onto the charging pad

located on the top surface of the speaker. Ensure the device is centered for optimal charging. The charging indicator on your device will confirm charging status.

LED Light Control

The speaker features dynamic LED lighting. Use the dedicated light control button (often marked with a light bulb icon) to cycle through different light modes or to turn the lights on/off. Refer to the button layout for specific controls.

Clock Display and Alarm

The integrated LED display shows the current time. Consult the user interface buttons (e.g., 'M' for Mode, '+' and '-' for adjustment) to set the time and configure alarm functions. Detailed instructions for setting the clock and alarm are typically found in the quick start guide included with the product.



Image: The speaker displaying the time on its LED screen in a low-light environment.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from

direct sunlight and extreme temperatures.

- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in active use.

TROUBLESHOOTING

Problem	Solution
Speaker does not power on.	Ensure the power cable is securely connected and the battery is charged. Try charging the device for at least 30 minutes.
Cannot pair via Bluetooth.	Make sure the speaker is in Bluetooth pairing mode. Disable and re-enable Bluetooth on your device. Ensure no other devices are currently connected to the speaker. Move closer to the speaker.
Wireless charging is not working.	Verify that your device supports Qi wireless charging. Ensure the device is properly aligned on the charging pad. Remove any thick phone cases that might interfere with charging.
No sound or low volume.	Check the volume levels on both the speaker and your connected device. Ensure the correct input mode (Bluetooth, AUX) is selected.

SPECIFICATIONS

Model: ZQS1222

Speaker Type: Portable Speaker

Color: White

Product Dimensions: 10"D x 3"W x 10"H

Speaker Maximum Output Power: 10 Watts

Connectivity Technology: Bluetooth

Battery Capacity: 500mAh

Wireless Charging Output: Up to 1500mAh

WARRANTY AND SUPPORT

For warranty information, technical assistance, or customer support, please refer to the documentation provided at the time of purchase or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

Manufacturer: Generic

ASIN: B0DH7CPR7S

Item Model Number: 123456789