

boAt Stone 193 Pro / Stone 190 Pro

boAt Stone 193 Pro / 190 Pro Bluetooth Speaker User Manual

Model: Stone 193 Pro / Stone 190 Pro

INTRODUCTION

Thank you for purchasing the boAt Stone 193 Pro / 190 Pro Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it carefully to ensure optimal performance and longevity of your device. The boAt Stone 193 Pro and 190 Pro models offer similar features and functionality, and this manual applies to both.

PACKAGE CONTENTS

- 1 x boAt Stone 193 Pro / 190 Pro Bluetooth Speaker
- 1 x Charging Cable
- 1 x Warranty Card

PRODUCT OVERVIEW



Front view of the boAt Stone 193 Pro / 190 Pro Bluetooth Speaker, showcasing its compact, square design with a textured black grille and the boAt logo.



Illustration highlighting the 5W boAt Signature Sound, indicating powerful and clear audio output from the speaker's internal components.



Image depicting the speaker in use with a person enjoying music, emphasizing its long battery life of up to 12 hours of playback.


IPX6

Splash and Water Resistance



The speaker being held near a river, illustrating its IPX6 rating for splash and water resistance, making it suitable for outdoor use.

Multiple Connectivity Modes




The speaker placed on a picnic table with people in the background, demonstrating its True Wireless Stereo (TWS) functionality for pairing two speakers for immersive sound.

Portable Design

Take The Beats Wherever You Go



Close-up of the speaker's side panel showing various ports and buttons, highlighting its multiple connectivity options including AUX, TF Card, and Bluetooth v5.3.



The speaker being placed into a small bag, emphasizing its portable design for easy transport.

TWS Functionality

Pair Another Stone 193 Pro Wirelessly for
Immersive Stereo Sound



An image showing the speaker next to a smartphone displaying a call, indicating the built-in microphone for hands-free calling, along with icons for One Touch Voice Assistant and Type-C Charging.



A comparison image showing both the Stone 193 Pro and Stone 190 Pro speakers, noting that either model may be received depending on stock availability.

SETUP

Charging the Speaker

1. Connect the provided Type-C charging cable to the charging port on the speaker.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show the charging status. A full charge typically takes a few hours.

OPERATING INSTRUCTIONS

Power On/Off

- To power on, press and hold the Power button for a few seconds until you hear an audible prompt and the LED indicator lights up.
- To power off, press and hold the Power button again for a few seconds until you hear an audible prompt and the LED indicator turns off.

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (the LED indicator will flash).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "Stone 193 Pro" or "Stone 190 Pro" from the list of devices.
4. Once paired, the LED indicator will turn solid, and you will hear a confirmation sound.

TWS (True Wireless Stereo) Functionality

To experience immersive stereo sound, you can pair two boAt Stone 193 Pro / 190 Pro speakers together.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (if available, or a combination of volume buttons as per specific model instructions) until you hear a prompt.
3. The two speakers will automatically connect to each other. Once connected, the primary speaker's LED will flash, indicating it's ready to pair with your device.
4. Connect your device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.

Call Management

- **Answer/End Call:** Press the Play/Pause button once.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds.
- **Redial Last Number:** Double-press the Play/Pause button.

Music Playback

- **Play/Pause:** Press the Play/Pause button once.
- **Next Track:** Press the Volume Up (+) button for 2 seconds.
- **Previous Track:** Press the Volume Down (-) button for 2 seconds.
- **Volume Up:** Short press the Volume Up (+) button.
- **Volume Down:** Short press the Volume Down (-) button.

Connectivity Options

- **AUX Mode:** Connect an audio device using a 3.5mm AUX cable to the speaker's AUX port. The speaker will automatically switch to AUX mode.
- **TF Card Mode:** Insert a TF (microSD) card with audio files into the designated slot. The speaker will automatically play music from the card.

MAINTENANCE

- Keep the speaker away from extreme temperatures, direct sunlight, and dust.
- Clean the speaker with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Avoid dropping the speaker or subjecting it to strong impacts.
- Ensure the charging port is dry before connecting the charging cable.
- When not in use for extended periods, store the speaker in a cool, dry place and charge it periodically to maintain battery health.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is charged. Connect it to a power source and try again.

Problem	Possible Solution
Cannot pair with Bluetooth device.	<ul style="list-style-type: none">◦ Ensure the speaker is in pairing mode.◦ Make sure Bluetooth is enabled on your device.◦ Move the speaker closer to your device.◦ Forget the speaker from your device's Bluetooth list and try pairing again.
No sound or low volume.	<ul style="list-style-type: none">◦ Adjust the volume on both the speaker and your connected device.◦ Ensure the speaker is properly connected via Bluetooth, AUX, or TF card.◦ Check if the audio source is playing.
TWS pairing fails.	<ul style="list-style-type: none">◦ Ensure both speakers are fully charged and not connected to any other device.◦ Power off both speakers and try the TWS pairing process again.

SPECIFICATIONS

Feature	Detail
Model Name	Stone 193 Pro / Stone 190 Pro
Speaker Type	Portable Speaker
Speaker Output Power	5 Watts
Playtime	Up to 12 Hours
Connectivity Technology	Bluetooth v5.3, AUX, TF Card
Water Resistance Level	IPX6 (Splash and Water Resistant)
Built-in Microphone	Yes, for hands-free calling
TWS Feature	Yes, for stereo pairing
Charging Port	Type-C
Item Weight	220 Grams
Product Dimensions	99D x 47W x 99H Millimeters
Battery Type	Lithium Polymer (included)

WARRANTY AND SUPPORT

Your boAt Stone 193 Pro / 190 Pro Bluetooth Speaker comes with a limited warranty. Please refer to the included Warranty Card for detailed terms and conditions.

For technical support, service, or warranty claims, please contact the manufacturer:

Manufacturer: Imagine Marketing Ltd.

Address: Unit no. 204 & 205, 2nd floor, D-wing & E-wing, Corporate Avenue, Andheri Ghatkopar Link Road, Mumbai, Maharashtra-400093, India

Please visit the official boAt website for the most up-to-date support information and contact details.