

JMMO 5813

JMMO Wireless Bubblegum Keyboard Model 5813 User Manual

Ultra Sleek Ergonomic Wireless Keyboard

1. INTRODUCTION

Thank you for choosing the JMMO Wireless Bubblegum Keyboard, Model 5813. This ultra-sleek and ergonomic keyboard is designed to provide a comfortable and efficient typing experience with its reliable 2.4GHz wireless connectivity. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new keyboard to ensure optimal performance.

2. PRODUCT OVERVIEW

The JMMO Wireless Bubblegum Keyboard combines a modern design with practical functionality. Its compact size and ergonomic layout make it suitable for various environments, from home offices to on-the-go use.

2.1 Key Features

- **Ultra-Sleek Design:** Slim profile with a vibrant pink finish.
- **Ergonomic Layout:** Designed to reduce hand fatigue and strain during extended use.
- **2.4GHz Wireless Connectivity:** Stable and responsive connection up to 10 meters.
- **Quiet and Responsive Keys:** Low-profile keys for a comfortable and efficient typing experience.
- **Long Battery Life:** Extended usage on a single charge.
- **Plug-and-Play Setup:** Easy connection without additional software or drivers.
- **Wide Compatibility:** Supports Windows, macOS, and Linux operating systems.

2.2 Keyboard Components



Figure 1: The JMMO Wireless Bubblegum Keyboard in its entirety, showcasing its sleek pink design and rounded keycaps.




Figure 2: A close-up view of the keyboard's side, highlighting the Type-C charging port, the on/off switch, and a battery indicator light. The image also mentions a 300mAh battery life with auto-sleep technology.

SLIM AND BEAUTIFUL

Own your space with a keyboard that matches your favorite accessories. Your desk setup is now a design statement.



Figure 3: The keyboard positioned on a wooden desk next to a tablet, illustrating its compact dimensions of 11.2 inches (284mm) in length and 5.1 inches (129mm) in width.

COMFORTABLE LAPTOP-STYLE TYPING

The sculpted, rounded keys match the shape of your fingertips, for a fluid, quiet and familiar typing experience.



Figure 4: A user comfortably typing on the JMMO keyboard, demonstrating its ergonomic design and laptop-style keys that conform to fingertips for a fluid experience.

MINIMALIST LAYOUT

The small footprint lets you place your mouse closer for more comfort, and better body posture. The tight design fits in your bag.



Figure 5: The pink JMMO keyboard displayed alongside black and green versions, emphasizing its minimalist layout which allows for better body posture and portability.




Figure 6: The JMMO keyboard integrated into a modern, pink-themed workspace, showcasing its aesthetic appeal and compact form factor next to a laptop and mouse.

3. SPECIFICATIONS

Feature	Detail
Model Number	5813
Connectivity	2.4GHz Wireless
Color	Pink
Special Features	Ergonomic, Quiet Keys, Auto-sleep technology

Feature	Detail
Material	Plastic
Battery	300mAh (Rechargeable via Type-C)
Compatibility	Windows, macOS, Linux
Dimensions	Approx. 284mm (L) x 129mm (W)

4. SETUP

4.1 Unpacking

Carefully remove the keyboard and its accessories from the packaging. Ensure all components are present:

- JMMO Wireless Bubblegum Keyboard
- USB 2.4GHz Receiver
- USB Type-C Charging Cable
- User Manual (this document)

4.2 Charging the Keyboard

Before first use, it is recommended to fully charge the keyboard. Connect the supplied USB Type-C charging cable to the keyboard's Type-C port (refer to Figure 2) and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The battery indicator light will show charging status and turn off when fully charged.

4.3 Connecting the USB Receiver

1. Locate the USB 2.4GHz receiver. It may be stored in a compartment on the keyboard for safekeeping.
2. Insert the USB receiver into an available USB port on your computer or compatible device.
3. The operating system will automatically detect and install the necessary drivers. This is a plug-and-play process and typically requires no manual intervention.

4.4 Powering On/Off

Locate the power switch on the side or back of the keyboard (refer to Figure 2). Slide the switch to the 'ON' position to power on the keyboard. Slide it to the 'OFF' position when not in use to conserve battery life.

5. OPERATING INSTRUCTIONS

5.1 Basic Typing

Once connected, the keyboard functions like a standard keyboard. Simply begin typing. The low-profile, rounded keys are designed for a comfortable and quiet typing experience.

5.2 Function Keys

The keyboard includes various function keys (F1-F12) that may have secondary functions accessible by pressing the **Fn** key simultaneously with the desired function key. These functions typically include media controls, volume adjustment, and screen brightness, depending on your operating system and device.

5.3 Compatibility

The JMMO Wireless Bubblegum Keyboard is compatible with:

- Windows operating systems
- macOS operating systems
- Linux operating systems

Ensure your device has an available USB port for the receiver.

6. MAINTENANCE

6.1 Cleaning

To clean your keyboard:

- Power off the keyboard before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Avoid using harsh chemicals, abrasive cleaners, or spraying liquids directly onto the keyboard.
- For dust and debris between keys, use compressed air.

6.2 Storage

When not in use for extended periods, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the keyboard is powered off to preserve battery life.

6.3 Battery Care

To maximize battery lifespan:

- Avoid fully discharging the battery frequently.
- Charge the keyboard using the provided Type-C cable.
- If storing for a long time, charge the battery to about 50% before turning it off.

7. TROUBLESHOOTING

7.1 Keyboard Not Responding

- **Check Power:** Ensure the keyboard is powered on.
- **Check Battery:** Verify the keyboard has sufficient battery charge. Recharge if necessary.
- **Check Receiver:** Ensure the USB receiver is securely plugged into a working USB port on your device. Try a different USB port.
- **Re-establish Connection:** Turn off the keyboard, unplug the USB receiver, wait a few seconds, then plug the receiver back in and turn on the keyboard.
- **Interference:** Move the keyboard closer to the USB receiver. Avoid placing the receiver near other wireless devices or large metal objects that might cause interference.

7.2 Keys Not Functioning Correctly

- **Clean Keys:** Check for any debris or obstructions under the keys. Clean as per maintenance instructions.
- **Restart Device:** Sometimes restarting your computer or device can resolve minor software glitches.

7.3 Short Battery Life

- **Charging Cycle:** Ensure the keyboard is fully charged before use.

- **Power Off:** Remember to power off the keyboard when not in use to conserve battery.
- **Charging Cable:** Use the provided charging cable or a certified Type-C cable.

8. WARRANTY AND SUPPORT

8.1 Manufacturer's Warranty

This JMMO Wireless Bubblegum Keyboard Model 5813 comes with a **6-month manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, warranty claims, or further inquiries, please contact your retailer or the JMMO customer support team through the contact information provided at the point of purchase. Please have your model number (5813) and proof of purchase ready when contacting support.

© 2024 JMMO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

