

[Manuals.plus](#) /

› [VASAGLE](#) /

› VASAGLE Parsons Dining Chairs (Set of 2) - Model UKDC152W01 - Instruction Manual

VASAGLE UKDC152W01

VASAGLE Parsons Dining Chairs (Set of 2)

MODEL: UKDC152W01 - INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the VASAGLE Parsons Dining Chairs. This manual provides essential information for the safe assembly, proper use, and effective maintenance of your new chairs. Please read these instructions carefully before assembly and retain them for future reference.

These chairs are designed for dining room and kitchen use, offering a blend of comfort and durability. Each set includes two chairs with removable fabric covers for easy cleaning and a versatile aesthetic.

2. Safety Information

WARNING: This product requires assembly. Always follow the instructions provided. Do not exceed the maximum weight capacity of 264 pounds (120 kg) per chair to ensure stability and safety.

- Ensure all parts are present and undamaged before assembly.
- Assemble the chairs on a soft, clean surface to prevent scratches.
- Tighten all screws firmly, but do not overtighten. Re-tighten periodically.
- Keep small parts away from children during assembly.
- Do not stand on the chair or use it as a step stool.

3. Package Contents

Your package should contain the following items:

- 2 x Dining Chair (unassembled components)
- 1 x Instruction Manual
- 1 x Hardware Pack (screws, washers, Allen key, etc.)

4. Setup and Assembly Instructions

Assembly is designed to be straightforward and can be completed in approximately 5 steps. Please refer to the included diagram for visual guidance.




Figure 4.1: Chair Dimensions and Weight Capacity

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface. Identify each part (e.g., chair back, seat, legs, hardware) using the parts list in your hardware pack.
2. **Attach Front Legs:** Secure the front legs to the underside of the chair seat frame using the provided screws and washers. Ensure they are aligned correctly before tightening.

3. **Attach Rear Legs:** Similarly, attach the rear legs to the chair seat frame. The rear legs are typically integrated with the backrest structure.
4. **Connect Seat to Backrest:** If the backrest is separate, connect it to the seat frame using the designated hardware. Ensure a secure fit.
5. **Final Tightening:** Once all components are loosely assembled, gradually tighten all screws evenly. Do not overtighten. Check for stability.

Stable and Sturdy

Durable solid wood frame for long-term use



Adjustable Feet
for Stability



Solid Rubberwood
Legs for Strong
Support



Figure 4.2: Adjustable Feet for Stability

The chairs feature adjustable feet to compensate for uneven floors, ensuring optimal stability. Adjust each foot by

rotating it until the chair sits level.

5. Operating Instructions (Usage)


These dining chairs are designed for comfortable seating in dining rooms and kitchens. Their ergonomic high backrest and thick padded seat provide support for extended periods.



Figure 5.1: Seat Construction for Comfort

The 4.7-inch thick padded seat, combined with breathable linen-look fabric and high-resilience foam, ensures a comfortable seating experience. The 20.7-inch high curved backrest offers excellent lumbar support.

Removable Cover, Easy Cleaning



Use It with or without the Cover

Offers 2 different
looks



Figure 5.2: Chairs in a Dining Setting

6. Maintenance and Care

Proper care will extend the life and appearance of your VASAGLE dining chairs.

6.1. Cleaning the Removable Fabric Covers



Figure 6.1: Removable Cover for Easy Cleaning

- The fabric covers are removable for easy cleaning.
- They can be machine washed or hand washed. Follow the care label instructions on the cover for specific temperature and detergent recommendations.
- Do not bleach. Tumble dry on low heat or air dry.
- Iron on low heat if necessary.

6.2. Frame Care

- Wipe the rubberwood frame with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the wood finish.
- Periodically check and re-tighten all screws to ensure the chair remains stable.
- Keep the chairs away from direct sunlight and excessive moisture to prevent warping or fading.

7. Troubleshooting

If you encounter any issues with your chairs, please refer to the following common solutions:

Problem	Possible Cause	Solution
Chair wobbles after assembly	Screws are not evenly tightened; uneven floor surface.	Ensure all screws are tightened evenly. Adjust the leveling feet on the bottom of the chair legs until stable.
Parts do not align during assembly	Incorrect orientation of parts; pre-assembled hardware misalignment.	Double-check the instruction manual for correct part orientation. If pre-assembled hardware appears misaligned, gently adjust or contact customer support. Do not force parts together.
Fabric cover does not fit correctly	Cover is not fully stretched or aligned.	Ensure the cover is fully unzipped and stretched over the chair from top to bottom, aligning seams with chair edges before zipping up.

8. Specifications

- **Brand:** VASAGLE
- **Model Name:** Dining Chairs
- **Model Number:** UKDC152W01
- **Color:** Cream White
- **Material:** Rubberwood, Plywood, Foam, Linen-Look Fabric
- **Product Dimensions (D x W x H):** 22.8" x 18.9" x 39.4" (58 x 48 x 100 cm)
- **Seat Depth:** 22.8 inches (58 cm)
- **Seat Thickness:** 4.7 inches (12 cm)
- **Backrest Height:** 20.7 inches (52.5 cm)
- **Item Weight:** 15.6 pounds (7.1 kg) per chair
- **Maximum Weight Recommendation:** 264 pounds (120 kg) per chair
- **Included Components:** 2 x Dining Chair, 1 x Instructions
- **Indoor/Outdoor Usage:** Indoor

9. Warranty and Support

For warranty information or customer support, please refer to the documentation included with your purchase or contact VASAGLE customer service directly through their official website or the retailer where the product was purchased. Please have your model number (UKDC152W01) and purchase details ready when contacting support.



