

[Manuals.plus](#) /

› [ForeverPRO](#) /

› ForeverPRO 711315700 Wire Bracket/Glass-Line for Liebherr Appliance - Instruction Manual

ForeverPRO 711315700

ForeverPRO Wire Bracket/Glass-Line Instruction Manual

Model: 711315700

INTRODUCTION

This instruction manual provides important information for the proper installation, use, and care of your ForeverPRO Wire Bracket/Glass-Line, model 711315700. This product is a replacement part designed for compatibility with Liebherr appliances. Please read this manual thoroughly before installation and keep it for future reference.

PRODUCT OVERVIEW



Figure 1: The ForeverPRO 711315700 Wire Bracket/Glass-Line. This image displays the full length of the metal wire bracket, which is silver in color and has bends at both ends to facilitate attachment within an appliance.

The ForeverPRO 711315700 Wire Bracket/Glass-Line is a durable component designed to support glass shelves or

other internal structures within compatible Liebherr appliances. It is constructed from high-quality materials to meet or exceed OEM specifications, ensuring reliable performance.

SETUP AND INSTALLATION

Before beginning installation, ensure the appliance is disconnected from its power source to prevent electrical hazards. Refer to your specific Liebherr appliance's service manual for detailed instructions on accessing and replacing internal components.

- 1. Preparation:** Clear the area around the installation point within the appliance. Remove any existing damaged or broken brackets.
- 2. Positioning:** Carefully align the new ForeverPRO wire bracket with the designated mounting points inside the appliance. The bent ends of the bracket are designed to fit into specific slots or holes.
- 3. Securing:** Gently push or slide the bracket into place until it is firmly seated. Ensure both ends are securely engaged and the bracket is stable.
- 4. Verification:** Once installed, lightly tug on the bracket to confirm it is properly secured and does not wobble.

If you are unsure about any step, it is recommended to consult a qualified appliance technician.

OPERATING CONSIDERATIONS

This wire bracket is a static component and does not require active operation. Its function is to provide structural support for glass shelves or other items within the appliance. Ensure that any items placed on shelves supported by this bracket do not exceed the appliance's recommended weight limits.

- Always distribute weight evenly on supported shelves.
- Avoid sudden impacts or excessive force on shelves, as this could damage the bracket or the appliance.

MAINTENANCE

The ForeverPRO Wire Bracket/Glass-Line requires minimal maintenance. Regular cleaning of your appliance will help keep the bracket in good condition.

- **Cleaning:** Wipe the bracket with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically inspect the bracket for any signs of wear, bending, or corrosion. If damage is observed, consider replacing the bracket to maintain appliance integrity.

TROUBLESHOOTING

If you encounter issues related to the wire bracket, consider the following:

Problem	Possible Cause	Solution
Shelf is unstable or sagging.	Bracket not properly seated or damaged.	Ensure the bracket is fully inserted into its mounting points. Inspect the bracket for bends or breaks; replace if damaged.
Bracket appears loose.	Improper installation or wear on mounting points.	Re-install the bracket, ensuring a snug fit. If mounting points are worn, professional repair may be needed.

SPECIFICATIONS

- **Model Number:** 711315700
- **Part Number:** FP-711315700
- **Manufacturer:** ForeverPRO
- **Item Weight:** 8 ounces
- **Product Dimensions:** 9 x 6 x 4 inches
- **Included Components:** Wire Bracket/Glass-Line
- **Compatibility:** Designed for Liebherr Appliances (verify specific model compatibility)
- **Country of Origin:** China

WARRANTY AND SUPPORT

This ForeverPRO product comes with a **90-day manufacturer's warranty**. For warranty claims or technical support, please contact ForeverPRO directly. Ensure you have your purchase details and the product model number (711315700) available when contacting support.

For additional information or to check compatibility with specific Liebherr appliance models, please refer to the product description or contact the seller.

© 2024 ForeverPRO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DHC9QVY7>

More documents and user manuals: <https://manuals.plus/>