

[Manuals.plus](#) /

› [ForeverPRO](#) /

› ForeverPRO 727701900 Toughened Safety-Glass Plate for Liebherr Appliance User Manual

## ForeverPRO 727701900

# ForeverPRO 727701900 Toughened Safety-Glass Plate User Manual

Model: 727701900

## 1. PRODUCT OVERVIEW

The **ForeverPRO 727701900 Toughened Safety-Glass Plate** is a high-quality replacement component designed for compatibility with various *Liebherr Appliances*. This PRO Grade Premium Toughened Safety-Glass Plate is engineered to meet or exceed original equipment manufacturer (OEM) specifications for durability and safety, ensuring a reliable and long-lasting solution for your appliance needs.



An overhead view of the ForeverPRO 727701900 Toughened Safety-Glass Plate, a clear rectangular glass component with smooth edges, designed as a replacement part for Liebherr appliances.

## 2. SETUP

### 2.1 Unpacking

Carefully remove the glass plate from its packaging. Inspect the plate thoroughly for any signs of damage that may have occurred during transit. If any damage is observed, contact customer support before proceeding with installation.

### 2.2 Installation

1. Ensure the interior of your Liebherr appliance is clean and dry before installation. Remove any debris or moisture from the designated area for the glass plate.
2. Gently slide the glass plate into its designated slots or supports within the appliance. Ensure it is properly aligned with the existing structure.
3. Confirm that the plate is seated securely and level. Apply gentle pressure to ensure it is firmly in place and does not wobble.

## 3. OPERATING

---

### 3.1 General Use

The toughened safety-glass plate is designed to provide a stable and durable surface for items within your Liebherr appliance. To ensure its longevity and prevent damage:

- Avoid placing excessively heavy or sharp objects directly on the glass surface.
- Distribute weight evenly across the plate when storing items.
- Do not subject the glass plate to sudden temperature changes, as this can cause stress and potential breakage.

## 4. MAINTENANCE

---

### 4.1 Cleaning

Regular cleaning will help maintain the clarity and hygiene of your glass plate:

- Clean the glass plate regularly with a soft cloth or sponge.
- Use a mild glass cleaner or warm soapy water. Avoid harsh chemicals, abrasive cleaners, or scouring pads, as these can scratch or damage the surface.
- Rinse the plate thoroughly with clean water to remove all soap residue.
- Dry the plate completely with a clean, lint-free cloth to prevent water spots and streaks.

### 4.2 Storage

If you need to remove the glass plate for an extended period, store it properly to prevent damage:

- Store the plate in a safe, flat location where it will not be subject to impacts, bending, or excessive pressure.
- Ideally, use its original packaging or wrap it in a protective material (e.g., bubble wrap, soft cloth) to prevent scratches.

## 5. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your Toughened Safety-Glass Plate.

Issue	Possible Cause / Solution
Plate does not fit correctly in the appliance.	<ul style="list-style-type: none"><li>• Verify the model number of your appliance against the compatible models listed for the ForeverPRO 727701900 plate.</li><li>• Ensure the plate is oriented correctly within the appliance's designated slots or supports.</li></ul>

Issue	Possible Cause / Solution
Scratches or minor surface damage.	<ul style="list-style-type: none"> <li>• Minor scratches are typically cosmetic and do not affect the structural integrity or functionality of the toughened glass.</li> <li>• To prevent further scratches, avoid dragging rough objects across the surface and use soft cleaning materials.</li> </ul>
Plate appears cloudy or stained after cleaning.	<ul style="list-style-type: none"> <li>• Ensure all soap or cleaning agent residue has been thoroughly rinsed off.</li> <li>• Dry the plate completely with a clean, lint-free cloth to prevent water spots. Hard water can leave mineral deposits; consider using distilled water for final rinse if this is a recurring issue.</li> </ul>

## 6. SPECIFICATIONS

Attribute	Detail
Manufacturer	ForeverPRO
Part Number	FP-727701900
Item Weight	12 ounces
Product Dimensions	9 x 6 x 4 inches
Country of Origin	China
Item Model Number	727701900
Included Components	Toughened Safety-Glass Plate
Batteries Required?	No

## 7. WARRANTY AND SUPPORT

### 7.1 Warranty Information

This ForeverPRO product is covered by a **90 Days Manufacturer Warranty**. This warranty typically covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

### 7.2 Customer Support

For any questions, technical assistance, or warranty claims regarding your ForeverPRO 727701900 Toughened Safety-Glass Plate, please contact ForeverPRO customer service. Refer to the product packaging or the original seller's information for specific contact details and support channels.