



Manuals.plus /

› Tastyle /

› Tastyle Single Serve One Cup Coffee Maker Instruction Manual

Tastyle K302

Tastyle Single Serve One Cup Coffee Maker

Model: K302

1. INTRODUCTION

Thank you for choosing the Tastyle Single Serve One Cup Coffee Maker. This compact and versatile appliance is designed to provide a convenient coffee brewing experience for both K-cups and ground coffee. Its portable design makes it ideal for various settings, including home, office, travel, camping, RVs, and dorms. Please read this manual thoroughly before operation to ensure safe and efficient use of your coffee maker.

2. SAFETY INFORMATION

- Always operate the coffee maker on a stable, flat surface.
- Ensure the power supply matches the voltage requirements (120V). While camping, a power bank with at least 100V output and 500W power is required. Note that brewing may take longer at 100V.
- Do not immerse the coffee maker, cord, or plug in water or other liquids.
- Exercise extreme caution when handling hot water and steam. The brewing temperature is optimal for flavor.
- This appliance is ETL certified and BPA-free, ensuring safety standards are met.
- The coffee maker features water shortage alerts and overheat protection for safe operation. If the water reservoir is empty, the button light will flash quickly, and the machine will shut off.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

3. PRODUCT OVERVIEW

The Tastyle Single Serve Coffee Maker is designed for simplicity and portability. Key components include:

- Main Coffee Maker Unit
- K-Pod Holder
- Reusable Ground Filter Basket with Lid
- Portable Handle
- 12 Oz Visible Water Tank with 6, 8, 10, and 12 oz markings
- One-Button Operation (Power/Brew)



Figure 3.1: Tastyle Single Serve Coffee Maker with included K-cup holder and ground coffee filter.

Tastyle

PORTABLE MINI

Single Serve Coffee Maker



BREW K-POD



BREW GROUND COFFEE
reusable filter included



EASY-CARRY HANDLE
just 2.4lb, easy to take anywhere



**ONE-BUTTON
EASY USE**



BPA FREE



18-Month Commitment



Figure 3.2: Key features of the Tastyle Portable Mini Coffee Maker, including its ability to brew K-pods and ground coffee, easy-carry handle, one-button operation, and BPA-free construction.

Mini Design, Less than 2 Smartphones Tall

Brew up to 12 oz Coffee



Figure 3.3: Compact dimensions of the coffee maker, designed to fit mugs up to 5.7 inches tall and brew up to 12 ounces.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, wash the K-pod holder and ground filter basket with warm, soapy water. Wipe the exterior of the coffee maker with a damp cloth.
3. **Placement:** Place the coffee maker on a stable, level surface near a power outlet.
4. **First Brew (Cleaning Cycle):**
 - Open the top lid and fill the water reservoir with clean water up to the MAX (12 oz) line.
 - Close the lid securely.
 - Place an empty mug on the drip tray.
 - Press the power/brew button to start a cleaning cycle. Discard the hot water after brewing.



Figure 4.1: The integrated handle allows for easy portability, making it convenient for on-the-go use.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the ease of use, including filling the water tank, inserting a K-cup or ground coffee, and initiating the brewing process with a single button. It highlights the coffee maker's portability for various environments like camping, home, and office.

5. OPERATING INSTRUCTIONS

Brewing with K-Cups:

1. **Fill Water Tank:** Open the top lid and fill the water reservoir with fresh water. Use the visible markings (6, 8, 10, 12 oz) to adjust the volume according to your desired coffee strength and mug size. Do not exceed the MAX (12 oz) line.
2. **Insert K-Cup:** Place a K-cup into the K-pod holder. Ensure it is seated correctly.
3. **Close Lid:** Close the top lid firmly until it clicks into place.
4. **Place Mug:** Position your coffee mug on the drip tray. Ensure your mug is not taller than 5.7 inches.
5. **Start Brewing:** Press the power/brew button. The indicator light will illuminate, and brewing will begin. Coffee will be ready in approximately 3 minutes.
6. **Enjoy:** Once brewing is complete, the machine will automatically shut off. Carefully remove your mug and enjoy your coffee.

Brewing with Ground Coffee:

1. **Fill Water Tank:** Follow step 1 from "Brewing with K-Cups".
2. **Prepare Ground Filter:** Open the reusable ground filter basket. Add up to 20g of your preferred ground coffee. Ensure the filter lid is securely closed to prevent grounds from entering your coffee.
3. **Insert Ground Filter:** Place the filled ground filter basket into the coffee maker.
4. **Close Lid:** Close the top lid firmly until it clicks into place.
5. **Place Mug:** Follow step 4 from "Brewing with K-Cups".
6. **Start Brewing:** Press the power/brew button. The indicator light will illuminate, and brewing will begin.
7. **Enjoy:** Once brewing is complete, the machine will automatically shut off. Carefully remove your mug and enjoy your coffee.

2 Brew Ways

- ① Come with K pod holder and reusable ground basket
- ① The parts are easy to clean and **dishwasher safe**



Figure 5.1: The coffee maker supports two brewing methods: K-cups and ground coffee using the included reusable filter. Both accessories are dishwasher-safe for easy cleaning.

Easy to Use & Clean



One button
operaton



Descaling
Reminder



Self Cleaning



Figure 5.2: Simple one-button operation for brewing, descaling, and self-cleaning functions.

6. MAINTENANCE & CLEANING

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your Tastyle coffee maker.

- **Daily Cleaning:**

- After each use, discard the used K-cup or ground coffee.
 - Rinse the K-pod holder and ground filter basket under running water. Both accessories are dishwasher-safe for convenience.
 - Wipe the exterior of the coffee maker with a damp, soft cloth.
- **Self-Cleaning Function:** The coffee maker includes a self-cleaning function. Refer to the product's quick start guide or online resources for specific instructions on activating this feature.
 - **Descaling Reminder:** The coffee maker has a descaling reminder feature. When the descaling indicator light illuminates, it's time to descale the machine.
 - **Descaling Process:**
 - Mix a descaling solution according to the manufacturer's instructions (e.g., white vinegar and water).
 - Fill the water reservoir with the descaling solution.
 - Place a large empty mug on the drip tray.
 - Initiate the descaling cycle (usually by pressing and holding the brew button or a dedicated descaling button).
 - After the cycle, run several cycles with fresh water to rinse thoroughly.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee maker does not turn on.	No power; water reservoir empty.	Check power connection. Fill water reservoir. The machine has water shortage alerts and will shut off if empty.
Coffee is not brewing or brewing slowly.	Insufficient water; clogged needle/filter; machine needs descaling; low power supply (e.g., camping with 100V power bank).	Ensure sufficient water. Clean the K-cup holder/ground filter. Perform a descaling cycle. Ensure power supply is 120V for optimal speed; 100V will result in slower brewing.
Coffee grounds in cup.	Ground filter lid not closed properly; too much ground coffee; fine grind.	Ensure the ground filter lid is securely closed. Do not exceed 20g of ground coffee. Use a medium to coarse grind for best results.
Water leaks from the machine.	Water tank overfilled; K-cup/filter not seated correctly.	Do not overfill the water tank. Ensure K-cup or ground filter is properly inserted and the lid is closed.
No drip tray for excess drips.	Design feature.	Place a paper towel or small cloth beneath the mug to catch any residual drips after removing the cup.

8. SPECIFICATIONS

Feature	Detail
Brand	Tastyle
Model Name	K302
Color	Black and Gold
Product Dimensions	8.1"D x 4.6"W x 9.8"H
Item Weight	2.42 pounds
Coffee Maker Type	Drip Coffee Machine
Coffee Input Type	Capsule, Ground, Pod
Brew Size	6 to 12 Oz
Voltage	120 Volts
Wattage	800 Watts
Special Features	Descaling Reminder, Self-Cleaning Function, Portable Handle, Automatic Shut-off, Water Shortage Alerts, Overheat Protection
Certifications	ETL Certified, BPA-Free

9. WARRANTY & SUPPORT

Tastyle is committed to providing quality products and customer satisfaction.

- **Warranty:** This product comes with an 18-month care period. For specific warranty details and to register your product, please refer to the information provided with your purchase or scan the QR code on the product.
- **Customer Support:** If you encounter any issues or have questions regarding your Tastyle coffee maker, please contact our support team.
- **Email:** support@mytastyle.com
- **Phone:** 1-972-487-4636

Please have your Amazon order number ready when contacting support for warranty claims.

