

KXAUTO 3169

KXAUTO Men's Sports Outdoor Waterproof Military Wrist Watch

MODEL: 3169

User Instruction Manual

1. INTRODUCTION

Thank you for choosing the KXAUTO Men's Sports Outdoor Waterproof Military Wrist Watch. This watch combines a fashionable sporty design with robust functionality, making it ideal for various outdoor and daily activities. It features both analog and digital displays, offering multiple timekeeping options and additional functions.



Image: Front view of the KXAUTO Sports Watch, highlighting its large dial and rugged design.

Key Features:


- Analog and Digital Dual Dial: Supports two different time zones.
- Multi-Functionality: Includes Alarm, LED Backlight, Date, Stopwatch, and 12/24H format option.
- Durability: Shock Resistant and Water Resistant up to 5 ATM.
- Comfort: Soft and durable PU watch band designed for ergonomic wear.

2. SETUP

2.1 Button Identification



FEATURE SET



FUNCTION OVERVIEW

EACH FUNCTIONAL DESIGN, ALL FOR YOUR CARING SERVICE, RECORDING EVERY MOMENT OF LIFE.



2 TIME



STOPWATCH



WEEK



ALARM



DATE



EL LIGHT



WR 50M

12/24 12/24 HOUR

Image: Diagram illustrating the location and labels of the watch's buttons: Light, Mode, Start/Stop, and Reset.

- **LIGHT Button:** Activates the LED backlight.
- **MODE Button:** Cycles through different modes (Time, Alarm, Stopwatch).
- **START/STOP Button:** Used to start/stop functions like the stopwatch or adjust settings.
- **RESET Button:** Used to reset functions or confirm settings.

2.2 Setting Time and Date

To set the digital time and date, press the **MODE** button until you reach the time setting interface. Use the **START/STOP** and **RESET** buttons to adjust the hours, minutes, and date. The analog hands are typically synchronized automatically or can be adjusted manually by pulling out the crown (if applicable) and rotating it.

2.3 Adjusting the Watch Strap

The durable PU watch band is designed for comfort. To adjust the fit, use the buckle to secure the strap at a comfortable position on your wrist. Ensure it is snug but not too tight to allow for proper circulation.

COLD LIGHT DISPLAY

CONVENIENT READING TIME AT NIGHT



Image: Diagram illustrating the minimum (150mm) and maximum (230mm) perimeter for wrist circumference to ensure proper strap fit.

3. OPERATING INSTRUCTIONS

3.1 Using the LED Backlight

Press the **LIGHT** button (typically on the upper left side) to illuminate the digital display, allowing for clear reading in dark conditions.



Image: The KXAITO Sports Watch worn on a wrist, demonstrating the activated LED backlight for night visibility.

3.2 Alarm Function

To set the alarm, press the **MODE** button until the alarm setting appears on the digital display. Use the **START/STOP** and **RESET** buttons to set the desired alarm time. Press **MODE** again to confirm and exit the setting.

3.3 Stopwatch Function

Access the stopwatch mode by pressing the **MODE** button. Press the **START/STOP** button to begin timing. Press it again to pause, and press the **RESET** button to clear the stopwatch. This function is useful for timing runs or other activities.

3.4 12/24 Hour Format Option

In time display mode, you can typically toggle between 12-hour and 24-hour (military) formats by pressing a specific button, often the **RESET** button, while in the time setting interface.

4. MAINTENANCE

4.1 Water Resistance (5 ATM)

This watch is water resistant up to 5 ATM (50 meters), making it suitable for everyday use, splashes, and rain. **IMPORTANT:** Do not press any buttons underwater, as this can compromise the waterproof seal. Keep the watch away from steam and hot water to prevent damage to the waterproof ring.



Image: The KXAITO Sports Watch shown with water droplets, illustrating its water resistance feature.

4.2 Cleaning Your Watch

To clean your watch, wipe it gently with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, which can damage the watch's finish or components. For stubborn dirt, a mild soap solution can be used, followed by thorough rinsing and drying.

4.3 Battery Replacement

The watch is powered by a long-lasting battery. When the display dims or functions become erratic, it may be time for a battery replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the waterproof seal is maintained.

5. TROUBLESHOOTING

Common Issues and Solutions:

- **Digital Display Not Working:** Check battery level. If low, replace the battery. Ensure no buttons are stuck.
- **Time Inaccurate:** Re-set the time following the instructions in Section 2.2. If the issue persists, the battery may be weak or the movement may require servicing.
- **Water Inside Watch:** If moisture appears inside the watch, stop using it immediately and take it to a professional for inspection and repair to prevent further damage.
- **Buttons Not Responding:** Ensure the watch is not exposed to extreme temperatures or excessive force. Try pressing the buttons firmly. If unresponsive, contact customer support.

For issues not covered here, please refer to the Warranty and Support section for assistance.

6. SPECIFICATIONS

Feature	Specification
Brand	KXAITO
Model Number	3169
Movement	Japan Quartz (Analog & Digital)
Case Material	ABS + PU
Band Material	PU
Clasp Type	Buckle
Water Resistance	5 ATM (50 meters)
Case Width	56mm
Case Thickness	18mm
Band Width	22mm
Watch Length	260mm
Weight	3.21 ounces (approx. 91g)



PRODUCT PARAMETER



Basic Information

BRAND: SANDA

MODEL: 3169

WEIGHT: 74g

MOV' T: Quartz and Digital

CRYSTAL: Acrylic

CASE: ABS + PU

BAND: PU

BUCKLE: Stainless Steel

W / P : 5 Bar

FUNCTION: 2Time, Chrono, Alarm, Date, Week, LED light, 12/24 hour clock.

Manual measurement, if there is an error, please prevail in kind!
Each product sold to provide quality assurance and after-sales service!



Case width: 56mm



Case thickness: 18mm



Band Width: 22mm



Watch length: 260mm



Image: Detailed product parameter diagram, including dimensions and material information.

7. WARRANTY AND SUPPORT

KXAITO is committed to customer satisfaction. If you have any questions or encounter issues with your watch, please do not hesitate to contact us. We will do our best to ensure you are satisfied with your purchase.

For after-sale support, please reach out to the seller directly through the platform where you purchased the product. They will be able to provide assistance regarding warranty claims, returns, or technical support.

Please retain your proof of purchase for any warranty-related inquiries.