

ELEMARA XB-1038

ELEMARA Ride on Car 2 Seater with Sun Shade, Dump Bed, and Shovel

Model: XB-1038

Instruction Manual

1. IMPORTANT SAFETY INFORMATION

Please read this entire manual before assembly and operation. Failure to follow these instructions may result in serious injury or property damage. Keep this manual for future reference.

- **Adult Supervision Required:** This product is a toy and must be operated under direct adult supervision at all times.
- **Age and Weight Limits:** Suitable for children aged 36 months to 8 years. Maximum load capacity is 150 lbs (68 kg). Do not exceed these limits.
- **Protective Gear:** Always wear a helmet and appropriate safety gear when operating the ride-on car.
- **Operating Environment:** Use only on flat, level surfaces. Avoid slopes, stairs, public roads, or areas near swimming pools or other bodies of water.
- **Battery Safety:** For external use only. Avoid contact with eyes. Keep away from naked flame or direct heat sources. Do not modify the battery or charging system.
- **Moving Parts:** Keep hands, hair, and clothing away from moving parts.
- **Seat Belts:** Ensure children are properly secured with the seat belts provided.

2. PRODUCT OVERVIEW

The ELEMARA Ride on Car is a 2-seater electric vehicle designed for children, featuring a sun shade, functional dump bed, and shovel for interactive play. It is equipped with a 4WD system and a 12V 10AH battery for extended use.

- Multifunctional 2 Seater Ride on Car
- 4WD Powered, 12V 10AH Battery Car
- Built for Multiple Terrain
- Dual Control Fun (Manual and Remote)

- Safety Meets Style



Image 2.1: The ELEMARA Ride on Car in pink, showcasing its design and features.



Image 2.2: An overview of the ride-on car's key features and capabilities.

3. WHAT'S IN THE BOX

Carefully unpack all components and ensure all items are present before beginning assembly. If any parts are missing or damaged, contact customer support immediately.

- Ride on Car (main body and components) x 1
- Instruction Manual x 1
- Shovel x 1
- Sun Shade x 1

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 45-55 minutes. Follow the detailed diagrams and instructions provided in the included manual for specific steps. General steps include:

1. **Wheel Installation:** Attach all four wheels securely to the axles.
2. **Steering Wheel Assembly:** Connect the steering wheel to the steering column and secure it.
3. **Battery Connection:** Connect the battery terminals. Ensure proper polarity.
4. **Seat Installation:** Secure the seats into their designated positions.
5. **Sun Shade Attachment:** Install the sun shade frame and canopy onto the vehicle.
6. **Dump Bed Assembly:** Attach the dump bed to the rear of the vehicle.
7. **Accessory Placement:** Place the shovel in its designated holder.

After assembly, perform a full charge of the battery before first use.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- Locate the power button, typically on the dashboard. Press to turn the vehicle on or off.
- The vehicle may play a startup sound or illuminate lights when powered on.

5.2 Driving the Vehicle

- **Manual Operation:** The child can operate the vehicle using the steering wheel and foot pedal.
- **Remote Control Operation:** An adult can override manual controls using the included remote control. This is ideal for younger children or for guiding the vehicle.
- **Speed Selection:** The vehicle features multiple speed settings (e.g., low, medium, high) which can be selected via a switch on the dashboard or the remote control.
- **Soft Start Feature:** The vehicle is equipped with a soft start feature to ensure smooth acceleration, preventing sudden jolts.



Image 5.1: Illustration of the soft start feature for smooth acceleration.

Image 5.2: Demonstrating the dual driving modes for varied age groups and control preferences.

5.3 Charging the Battery

- Locate the charging port on the vehicle.
- Connect the charger to the port and then plug it into a standard wall outlet.
- Charging time is typically 8-12 hours for a full charge. Do not overcharge.
- Expected play time on a full charge is approximately 1.5 hours, depending on usage and terrain.
- The vehicle features a low battery reminder.



Image 5.3: Battery specifications and charging guidelines.

5.4 Using the Dump Bed and Shovel

- The rear dump bed can be manually tilted to unload items.
- Use the included shovel for interactive play, such as scooping and transporting lightweight materials.

5.5 Sun Shade Usage

- The integrated sun shade provides protection from direct sunlight during outdoor play.
- Ensure the sun shade is securely attached before use.

6. MAINTENANCE

6.1 Cleaning

- Wipe the vehicle with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Avoid spraying water directly onto electrical components.

6.2 Battery Care

- Charge the battery fully after each use.
- If storing the vehicle for an extended period, charge the battery every 30 days to maintain its lifespan.
- Do not store the battery in extreme temperatures.

6.3 Storage

- Store the vehicle in a dry, covered area away from direct sunlight and moisture.
- Protect the vehicle from dust and debris.

7. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

- **Vehicle Does Not Turn On:**
 - Check if the battery is connected properly.
 - Ensure the battery is fully charged.
 - Verify the power button is pressed.
- **Vehicle Does Not Move:**
 - Check if the foot pedal is fully depressed.
 - Ensure the forward/reverse switch is in the correct position.
 - If using remote control, ensure it is paired and has fresh batteries.
- **Remote Control Not Working:**
 - Replace batteries in the remote control.
 - Refer to the specific remote control pairing instructions in the full manual.
- **Reduced Power/Short Playtime:**
 - Ensure the battery is fully charged for the recommended duration.
 - Battery life can decrease over time; consider battery replacement if significantly degraded.

For persistent issues, please contact customer support.

8. SPECIFICATIONS



Image 8.1: Product dimensions and key specifications.

Specification	Value
Product Dimensions	51.5 x 29.5 x 42.1 inches

Specification	Value
Item Weight	66 pounds
Model Number	XB-1038
Manufacturer Recommended Age	36 months - 8 years
Battery Type	12V 10AH (rechargeable)
Max Load Capacity	150 lbs
Manufacturer	ELEMARA
Release Date	September 15, 2024

9. WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty against defects in materials and workmanship. Specific warranty terms and duration may vary. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please contact ELEMARA customer service through the retailer where the product was purchased or visit the official ELEMARA website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question