

**BOBLOV HD66-02/D7**

# BOBLOV D7 2K Body Camera Instruction Manual

Model: HD66-02/D7

## 1. INTRODUCTION

---

Thank you for choosing the BOBLOV D7 2K Body Camera. This device is designed to capture high-quality audio and video footage in various professional and personal settings. With its robust features, including 2K resolution, dual batteries, IP68 waterproof rating, and advanced night vision, the D7 ensures reliable performance for security, law enforcement, and outdoor activities. This manual provides detailed instructions for setup, operation, and maintenance to help you maximize your camera's capabilities.

## 2. WHAT'S IN THE BOX

---

Please verify that all items listed below are included in your package:

- 1x BOBLOV HD66-02/D7 Body Camera
- 1x Charging Base
- 2x 1950mAh Li-ion Batteries (one pre-installed in camera)
- 1x 180° Long Clip
- 1x 360° Short Clip
- 1x Car Charger
- 1x USB Cable
- 1x User Manual

# Capture Clear Footage, Even at Night

Equipped with night vision for low-light recording



Image: Contents of the BOBLOV D7 2K Body Camera package.

### 3. PRODUCT OVERVIEW

The BOBLOV D7 Body Camera features a compact and durable design with strategically placed buttons for easy operation. It is built to withstand challenging environments with an IP68 waterproof rating and 2.5m drop protection.



Image: Front view of the BOBLOV D7 2K Body Camera, showing the camera, charging dock, and two removable batteries.

## Key Features:

- **2K/1440P Video Resolution:** Captures clear and detailed footage.
- **40MP Photo Resolution:** For high-quality still images.
- **170° Wide-Angle Lens:** Provides a broad field of view.
- **Dual 1950mAh Batteries:** Ensures extended recording time.
- **IP68 Waterproof:** Protects against water ingress in various conditions.
- **2.5m Drop Protection:** Enhanced durability for rugged use.
- **Auto Infrared Night Vision:** Records clear footage in low-light or complete darkness.
- **Raised Button Design:** Allows for easy tactile operation.

## Button Layout:

The camera features distinct raised buttons for intuitive control:

- **Video Button:** Initiates and stops video recording.
- **Audio Button:** Starts and stops audio-only recording.
- **Photo Button:** Captures still images.

# Raised Button for Easy Access

User-friendly design for any operation




Image: Side view of the BOBLOV D7 2K Body Camera, illustrating the raised buttons for video, audio, and photo functions.

## 4. SETUP

### 4.1. Battery Installation and Charging

The BOBLOV D7 comes with two 1950mAh rechargeable batteries. One battery is typically pre-installed. To install or replace a battery:

1. Locate the battery compartment on the bottom of the camera.
2. Slide the battery compartment cover open.
3. Insert the Li-ion battery, ensuring the contacts align correctly.
4. Close the battery compartment cover securely.



Button to lock the video

## Lock Videos to Prevent Accidental Deletion



lock the  
video



Prevent  
Deletion

Image: Step-by-step instructions for battery replacement.

To charge the camera, place it on the included charging dock. The dock provides a convenient way to charge the camera without frequently plugging and unplugging cables. Alternatively, you can connect the USB cable directly to the camera for charging.

### 4.2. Memory Card (Micro SD)

The camera supports Micro SD cards for storage. Ensure a compatible Micro SD card is inserted before recording. The 128GB version comes with internal storage, but external Micro SD cards can be used for expanded capacity.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Power On/Off

Press and hold the Power button to turn the camera on or off. The screen will illuminate, indicating the camera is ready for use.

### 5.2. Video Recording

Press the dedicated **Video Button** to start recording video. Press it again to stop recording. The camera captures video in 2K/1440P resolution with a 170° wide-angle view, ensuring comprehensive coverage.

# 2K/1440P Resolution for Vivid Shots

Capture every detail in 1440P




Image: Visual representation of 2K/1440P resolution and wide-angle capture.

## 5.3. Audio Recording

Press the **Audio Button** to start recording audio only. Press it again to stop. This feature is useful for capturing verbal interactions without video.

## 5.4. Photo Capture

Press the **Photo Button** to take a still image. The camera captures photos at 40MP resolution.

## 5.5. Night Vision

The D7 camera is equipped with auto infrared night vision, allowing it to capture clear footage in complete darkness or low-light conditions from 3 to 15 meters away. The night vision activates automatically when light levels are low, or it can be manually toggled.

# Durable and Reliable Body Camera

Perfectly designed for long shifts




Image: Demonstration of the camera's night vision capabilities.

## 5.6. Locking Videos

To prevent accidental deletion of important footage, the camera allows you to lock videos. Refer to the on-screen menu or specific button combination (usually indicated by a lock icon) to secure your recordings.

## Record your catches and scenic moments effortlessly



## 6. CONNECTING TO COMPUTER

---

To transfer recorded files to your computer, connect the camera using the provided USB cable. The camera will appear as a removable disk drive, allowing you to access and copy your video, audio, and photo files.

## 7. MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the camera body. For the lens, use a specialized lens cleaning cloth and solution. Avoid abrasive materials or harsh chemicals.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** If storing for extended periods, charge the batteries to about 50% capacity. Avoid fully discharging batteries for long-term storage.

## 8. TROUBLESHOOTING

---

### **Camera does not power on:**

Ensure the battery is properly installed and charged. Connect the camera to the charging dock or directly via USB cable to confirm charging status.

### **Battery life is shorter than expected:**

Recording at higher resolutions (2K/1440P) or continuous use of night vision will consume more power. Ensure both batteries are fully charged. Consider reducing video resolution if extended recording time is critical.

### **Charging dock not charging the camera:**

Check the power connection to the dock. If the issue persists, try charging the camera directly using the USB cable.

### **Footage appears black and white:**

This indicates that the camera's night vision mode is active. This is normal behavior in low-light or dark conditions. You can typically disable auto night vision in the camera settings if desired, though color recording will not be possible in very low light.

### **Cannot transfer files to computer:**

Ensure the USB cable is securely connected to both the camera and the computer. Try a different USB port or cable. Verify that the camera is in the correct USB mode (e.g., Mass Storage) if prompted.

## 9. SPECIFICATIONS

---

Feature	Specification		
Brand	BOBLOV		
Model Number	HD66-02/D7		
Video Capture Resolution	2K (1440P)		
Photo Sensor Technology	CMOS		
Maximum Focal Length	20 Millimeters		
Maximum Aperture	f/2		
Flash Memory Type		Special Features	Night Vision, IP68 Waterproof, 2.5m Drop Protection
Screen Size	2 Inches		
Item Weight	1.25 pounds		
Package Dimensions	7.48 x 5.16 x 2.6 inches		

## 10. WARRANTY AND SUPPORT

BOBLOV provides a **24-month product warranty** for its supporters. We are committed to offering quick response within 24 hours and lifetime technical support for our products.

For any inquiries, technical assistance, or warranty claims, please contact BOBLOV customer support through the official BOBLOV Store on Amazon or visit our website. Additional protection plans may be available for purchase to extend coverage.

© 2024 BOBLOV. All rights reserved.

**BOBLOV®**

**BODY WORN CAMERA**

**Model: HD66-02/D7**



**User Manual**

[BOBLOV HD66-02/D7 Body Worn Camera User Manual](#)

Comprehensive user manual for the BOBLOV HD66-02/D7 body worn camera, detailing its features, operation, specifications, and troubleshooting for optimal use. lang:en score:37 filesize: 12.22 M page\_count: 34 document date: 2022-04-08

[\[pdf\]](#) User Manual Troubleshooting Guide Specifications Diagram

LYY1553 D7 Body Camera User Manual cdr Administrator Spy Shop ro When recording there is a red dot flashing slowly in the screen upper left corner and working indicator shows 07 support@boblov Page 11 HD66 2022 4 18 1 spy shop media custom upload srsItd

AfmBOopPJOLp73QwF5z7xDVZbxXdQ6pOWHwIhrTiEDNrFclAhTeujMod roLYY1553 roWhen 11 When 11 HD66 1HD66 1spy AfmBOopPJOLp73QwF5z7xDVZbxXdQ6pOWHwIhrTiEDNrFclAhTeujModspy

AfmBOooYdyi4pseyt1CfxqRMgO4lJkIE9oyH1GjeJh LG3 bgNDTowCg 11 5 pin Mini USB Port Card Slot PPT Button Optional need to pair 8 hours 2 batteries with 1080P IR Off Screen Night vision range

10MHD66 bgNDTowCgspy AfmBOoqgjJgNqZkS8bvCpRdaRnJoRMwiinDJ7k9Mif5PE5n0D5jhVuz1 10M5 intercom before purchase Video Power On Audio Photo Button HD66

AfmBOoqgjJgNqZkS8bvCpRdaRnJoRMwiinDJ7k9Mif5PE5n0D5jhVuz1spy AfmBOorJPfblUHSGA2QH qxkBaq6hPO3zo3BOKIkKdeDWxRmDG6wZT7x Button 5

qxkBaq6hPO3zo3BOKIkKdeDWxRmDG6wZT7xspy AfmBOoq2tSKCc2AfvZjPzvRa8T3mYlJc9CYEjsn8O H3PYS48e1AxYGF Button After connecting camera socket will be powered on auto start charging light

green charging HD66 H3PYS48e1AxYGFspy AfmBOoqeNQo1jOgeYw337ztHogZeF8up4Y37COWPnS RYzoxkD NqxIU charging After NqxIUspy AfmBOorQ6gX4 5nd7

eiGNAqnRnt9ys85y0itgNid4z8G4zPiP9zgBqT ||| ||| BODYWORNCAMERA Model:HD66-02/D7

UserManual CONTENT PREFACE 01 PART1STRUCTUREDIAGRAM 01 PART2LCDINDICATION 03

PART3BASICOPERATION 04 3.1Chargethedevic 04 3.2PowerOn/Off/StandbyMode 05 3.3PhotoTaking

06 3.4VideoRecording 07 3.5AudioRecording ||| BODYWORNCAMERA Model:HD66-02/D7 UserManual

CONTENT PREFACE 01 PART1STRUCTUREDIAGRAM 01 PART2LCDINDICATION 03

PART3BASICOPERATION 04 3.1Chargethedevic 04 3.2PowerOn/Off/StandbyMode 05 3.3PhotoTaking

06 3.4VideoRecording 07 3.5AudioRecording ||| BODYWORNCAMERA Model:HD66-02/D7 UserManual

CONTENT PREFACE 01 PART1STRUCTUREDIAGRAM 01 PART2LCDINDICATION 03

PART3BASICOPERATION 04 3.1Chargethedevic 04 3.2PowerOn/Off/StandbyMode 05 3.3PhotoTaking

06 3.4VideoRecording 07 3.5AudioRecording ||| BODYWORNCAMERA Model:HD66-02/D7 UserManual

CONTENT PREFACE 01 PART1STRUCTUREDIAGRAM 01 PART2LCDINDICATION 03

PART3BASICOPERATION 04 3.1Chargethedevic 04 3.2PowerOn/Off/StandbyMode 05 3.3PhotoTaking

06 3.4VideoRecording 07 3.5AudioRecording ||| BODYWORNCAMERA Model:HD66-02/D7 UserManual

CONTENT PREFACE 01 PART1STRUCTUREDIAGRAM 01 PART2LCDINDICATION 03

PART3BASICOPERATION 04 3.1Chargethedevic 04 3.2PowerOn/Off/StandbyMode 05 3.3PhotoTaking

06 3.4VideoRecording 07 3.5AudioRecording ||| BODYWORNCAMERA Model:HD66-02/D7 UserManual

CONTENT PREFACE 01 PART1STRUCTUREDIAGRAM 01 PART2LCDINDICATION 03

PART3BASICOPERATION 04 3.1Chargethedevic 04 3.2PowerOn/Off/StandbyMode 05 3.3PhotoTaking

06 3.4VideoRecording 07 3.5AudioRecording

BODYWORNCAMERA Model:**HD66-02/D7** UserManual CONTENT PREFACE 01

PART1STRUCTUREDIAGRAM 01 PART2LCDINDICATION 03

PART3BASICOPERATION 04 3.1Chargethedevic 04 3.2PowerOn/Off/StandbyMode

05 3.3PhotoTaking 06 3.4VideoRecording 07 3.5AudioRecording 10 3.6NightVision

12 3.7FilesView/P...

lang:en score:15 filesize: 287.79 K page\_count: 34 document date: 2023-06-16

