

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Wintem](#) /

› Wintem 2000W Electric Heater User Manual - Model 8056819051919

Wintem 8056819051919

Wintem 2000W Electric Heater User Manual

Model: 8056819051919

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before using this electric heater. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not use this heater in bathrooms, laundry areas, or similar indoor locations where water may be present.
- Always unplug the heater when not in use.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in any manner.
- Do not run power cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 1 meter (3 feet) from the front of the heater and away from the sides and rear.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Close supervision is necessary when any heater is used by or near children or invalids.

2. PRODUCT OVERVIEW

The Wintem 2000W Electric Heater is designed for efficient heating of small to medium-sized rooms. It features adjustable power settings, a thermostat, and safety mechanisms.



Figure 2.1: Wintem electric heater demonstrating its dual power settings (1000W/2000W) in a living room environment.

Key Components:

- **Power Selector Dial:** Controls the power output (Off, Fan Only, 1000W, 2000W).
- **Adjustable Thermostat Dial:** Sets the desired room temperature.
- **Power Indicator Light:** Illuminates when the heater is operating.
- **Integrated Carry Handle:** For easy portability.
- **Air Outlet Grille:** Where heated air is expelled.
- **Air Inlet:** Where air is drawn into the heater.



Figure 2.2: Close-up view of the integrated ergonomic handle, designed for convenient transport.

3. SETUP

1. **Unpack:** Carefully remove the heater from its packaging. Retain packaging for future storage.
2. **Placement:** Place the heater on a firm, level surface. Ensure it is at least 1 meter (3 feet) away from walls, furniture, and other objects. Do not place it on soft surfaces like carpets with long pile, or where it could be easily knocked over.
3. **Power Connection:** Ensure the heater's power selector is in the 'OFF' (0) position. Plug the power cord into a suitable 220-240V AC, 50Hz electrical outlet. Do not use extension cords or power strips.

4. OPERATING INSTRUCTIONS

1. **Power On:** Turn the Power Selector Dial to your desired setting:
 - **Fan Only (★):** For air circulation without heat.
 - **Low Heat (I - 1000W):** For gentle heating.
 - **High Heat (II - 2000W):** For rapid and powerful heating.

The power indicator light will illuminate when the heater is on.

2. **Set Thermostat:** Turn the Adjustable Thermostat Dial clockwise to the maximum setting. Once the room reaches your desired temperature, slowly turn the thermostat dial counter-clockwise until the heater turns off. The heater will now cycle on and off to maintain this temperature.



Figure 4.1: Heater in a bathroom setting, illustrating the use of the adjustable thermostat for precise temperature control.

Overheat Protection:

This heater is equipped with an advanced overheat protection system. If the heater's internal temperature exceeds a safe limit, it will automatically shut off to prevent damage or fire. If this occurs:

1. Turn the Power Selector Dial to 'OFF' (0).
2. Unplug the heater from the electrical outlet.
3. Allow the heater to cool down for at least 10-15 minutes.
4. Check for any obstructions blocking the air inlet or outlet grilles. Remove any obstructions.
5. Plug the heater back in and resume operation. If the heater continues to shut off, contact customer support.



Figure 4.2: Heater in a bedroom, demonstrating the safety feature of overheat protection.

5. MAINTENANCE

Cleaning:

- Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior surfaces of the heater with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Do not immerse the heater in water or allow water to drip into the interior of the heater.
- Periodically clean the air inlet and outlet grilles with a vacuum cleaner brush attachment to remove dust and lint.

Storage:

When not in use, store the heater in a cool, dry place. It is recommended to store it in its original packaging to protect it from dust and damage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit.	Check if the power cord is securely plugged into a working outlet. Ensure the power selector is not in the 'OFF' position.
Heater stops working suddenly.	Overheat protection activated.	Turn off, unplug, and let cool for 10-15 minutes. Check for and remove any obstructions. Re-plug and restart.
Insufficient heat output.	Incorrect power setting or thermostat setting.	Ensure the power selector is on 'High Heat' (II - 2000W). Turn the thermostat dial to a higher setting. Ensure the room size is appropriate for the heater's capacity.

7. SPECIFICATIONS



Figure 7.1: Dimensions of the Wintem electric heater.

Feature	Detail
Brand	Wintem
Model Number	8056819051919
Power Output	1000W / 2000W
Special Feature	Overheat Protection, Adjustable Thermostat
Color	White
Product Dimensions (L x W x H)	13 cm x 22 cm x 26 cm
Item Weight	1.03 Kilograms
Form Factor	Pedestal
Usage	Indoor
Power Source	Electric Cable
Room Type	Home Office, Bedroom, Living Room
Fuel Type	Electric

8. WARRANTY AND SUPPORT

This Wintem Electric Heater comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For technical support, warranty claims, or any questions regarding your product, please contact Wintem customer service:

- **Website:** www.wintem.com (placeholder)
- **Email:** support@wintem.com (placeholder)
- **Phone:** +1-XXX-XXX-XXXX (placeholder)