

[Manuals.plus](#) /

> [OOOK](#) /

> OOOK Potting Bench with Removable Sink, Potting Benches for Outside, Mud Kitchen for Kids Outdoor with Gardening Tools, Watering Can, Flower Pot, Ideal Gift for Boys and Girls 3+, Solid Fir Wood

OOOK B0DHDDZYV1

OOOK Potting Bench with Removable Sink

Model: B0DHDDZYV1

Brand: OOOK

INTRODUCTION

Thank you for choosing the OOOK Potting Bench with Removable Sink. This outdoor mud kitchen is designed to provide a safe and engaging environment for children aged 3 to 8 years to explore gardening and imaginative play. Crafted from natural fir wood, it encourages hands-on learning and fosters a connection with nature.

SAFETY INFORMATION

- Adult assembly is required.
- Ensure all screws and fasteners are securely tightened before use. Periodically check for tightness.
- Supervise children during play to prevent accidents.
- This product is made from real fir wood. It is recommended to wear gloves during assembly to avoid splinters.
- Do not allow children to climb on the bench.
- Place the potting bench on a stable, level surface.
- Keep small parts away from children under 3 years of age.

WHAT'S INCLUDED

The OOOK Potting Bench package includes the following components:

- Wooden Potting Bench Frame
- Removable Sink
- Watering Can
- Flower Pots (x4)
- Hand Trowel
- Hand Rake

- Transplanting Trowel
- Assembly Hardware (screws, etc.)
- Detailed Assembly Instructions



Image: The complete OOOK Potting Bench set, showcasing the wooden bench, removable sink, and all included gardening tools and pots.

ASSEMBLY INSTRUCTIONS

Assembly of the potting bench requires adult supervision and tools. Please follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the "What's Included" section are present. If any parts are missing, please contact customer support.
2. **Identify Parts:** Each wooden board is labeled with a sticker. Match these labels with the diagrams in the detailed assembly instructions provided in the box.

3. **Prepare for Assembly:** It is recommended to use a power drill for assembly, as the pre-drilled holes may be small and a manual screwdriver might require significant effort. Wear gloves to prevent splinters.
4. **Assemble Frame:** Follow the step-by-step diagrams in the provided manual to connect the main wooden frame pieces. Pay close attention to the orientation of each piece.
5. **Secure Connections:** When attaching pieces, if holes are not perfectly aligned, it can be helpful to insert the screw into one piece of wood first, then carefully align it with the corresponding hole in the second piece before fully driving it in. This ensures proper alignment.
6. **Install Shelves and Sink:** Attach the 3-tier storage shelf, two countertops, and the slatted bottom storage shelf as indicated in the instructions. Insert the removable sink into its designated slot.
7. **Attach Accessories:** Secure the side hanging hooks for tools.
8. **Final Check:** Once assembled, ensure all screws are tightened and the structure is stable.

Note: Assembly may take a few hours. Patience and careful attention to detail will ensure a successful build.



Image: Close-up views illustrating the diverse storage options of the potting bench, including the upper shelf, main countertop with sink, and

lower slatted shelf.

OPERATING INSTRUCTIONS & USAGE

The OOOK Potting Bench is designed for various outdoor activities, promoting creativity and learning in children.

Gardening Activities:

- **Planting:** Use the provided flower pots and gardening tools to plant seeds or small plants. The removable sink can be used for mixing soil or holding water.
- **Watering:** Utilize the watering can to water plants.
- **Observation:** Encourage children to observe the growth of their plants, fostering an understanding of nature.



Image: A child's hands are shown planting a small seedling in the removable sink, demonstrating the hands-on gardening experience.

Explore a variety of plant types

Four pots allow for planting different types of plants at the same time



4 Removable Pots



Fruits



Vegetables



Flowers



Herbs

Image: The potting bench filled with different types of plants, including herbs, flowers, and small vegetables, highlighting its versatility for various planting activities.

Imaginative Play (Mud Kitchen):

- The removable sink can be filled with water, sand, or mud for sensory play.
- Children can use the tools to "cook" and "create" with natural elements.

The bench features a big platform and ample storage space, including flower pot stands, shelves, a bottom shelf, and side hanging hooks, to keep tools and materials organized.

Unleash Kids' Potential

Help kids learn life skills during gardening activities with creativity



Responsibility



Patience



Science Skills



Creativity



Motor Skills

Image: A young child interacting with the potting bench, holding a watering can, illustrating the product's use in fostering responsibility and engagement.

Fun and Interactive Nature Education

Plant a small garden with your child to strengthen your connection



Parent-Child
Interaction



Image: An adult and child collaboratively engaging in planting activities at the potting bench, highlighting the opportunity for parent-child interaction and shared learning experiences.

Product Video:

Your browser does not support the video tag.

Video: This video demonstrates children actively using the OOOK Potting Bench for gardening and play, showcasing its features and interactive elements.

MAINTENANCE AND CARE

- **Cleaning:** Wipe down the wooden surfaces with a damp cloth. The removable sink can be easily cleaned with water and mild soap.
- **Wood Care:** As the bench is made of natural fir wood, regular maintenance can extend its lifespan. Consider applying a child-safe wood sealant or stain annually, especially if exposed to harsh weather conditions.
- **Storage:** If possible, store the potting bench in a covered area during extreme weather or off-season to protect the wood.

- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Tighten as needed.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Missing parts or hardware	Carefully check all packaging materials. If parts are genuinely missing, contact OOOK customer support with your purchase details.
Difficulty with screw insertion / Misaligned holes during assembly	<p>Ensure you are using the correct screw for the designated hole as per the instructions.</p> <p>A power drill is highly recommended for easier and more precise screw insertion.</p> <p>Try inserting the screw into one piece of wood first, then carefully align it with the corresponding hole in the second piece before fully driving it in.</p> <p>Slight adjustments to wood alignment may be necessary.</p>
Splinters from wood	Wear gloves during assembly. The wood is natural fir and may have rough edges.
Bench feels wobbly after assembly	Ensure all screws are fully tightened. Check that the bench is placed on a flat, stable surface.

SPECIFICATIONS

- **Product Dimensions:** 27.5 x 16.1 x 36.2 inches (Length x Width x Height)
- **Item Weight:** 16.91 pounds
- **Material:** Natural Fir Wood
- **Recommended Age:** 36 months - 8 years
- **Model Number:** B0DHDDZYV1
- **Manufacturer:** TOOKYTOY (Brand: OOOK)



Image: A visual representation of the potting bench's dimensions, indicating its height, width, and depth for easy reference.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official OOOK brand website. Please have your model number (B0DHDDZYV1) and purchase date ready when contacting support.