Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Casaottima SPCB02021501004USDF

Casaottima L-Shaped Desk Instruction Manual

Model: SPCB02021501004USDF

Introduction

Thank you for choosing the Casaottima L-Shaped Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use of your new desk. Please read this manual carefully before beginning assembly and retain it for future reference.

Safety Information

Always ensure that the desk is not overloaded with heavy items. Use the power outlet with caution and follow the manufacturer's instructions to prevent electrical hazards.

- Do not stand or sit on the desk.
- Keep small parts away from children during assembly.
- Ensure all screws and fasteners are securely tightened before use.
- Place the desk on a level surface to prevent instability.

Package Contents

Please verify that all components are present before starting assembly. If any parts are missing or damaged, please contact customer support.

- Desk Boards (L-shaped main top, side panel)
- Metal Frame Components
- 4 Fabric Drawers
- Built-in Power Outlet Unit (3 AC outlets, 2 USB ports)
- CPU Stand

- 2 Iron Hooks
- Assembly Hardware (screws, bolts, nuts)
- Assembly Tools (e.g., Allen wrench)
- Instruction Manual

Setup and Assembly

Assembly is designed to be straightforward with clearly labeled parts and instructions. It is recommended to assemble the desk with two people.

Reversible Design



A visual representation showing how the L-shaped desk can be assembled in two orientations, allowing the drawer unit to be placed on either the left or right side to suit different room layouts.

The Casaottima L-Shaped Desk features a reversible design, allowing you to configure the drawer unit on either the left or right side to best fit your space and preferences. Follow the specific instructions in the included assembly guide for your desired orientation.

Step-by-Step Assembly

1. **Unpack and Identify:** Carefully unpack all components and lay them out. Identify each part using the provided labels and the parts list in the assembly guide.
2. **Assemble the Metal Frame:** Connect the metal frame components according to the diagrams in the assembly guide. Ensure all screws are finger-tightened initially.
3. **Attach Desk Boards:** Secure the main L-shaped desk boards to the assembled metal frame. Once all boards are in place, fully tighten all screws with the provided tools.
4. **Install Power Outlet:** Carefully place the built-in power outlet unit into its designated slot on the desk surface.
5. **Install Drawers:** Assemble the fabric drawers as described below and insert them into the drawer unit frame.
6. **Attach CPU Stand and Hooks:** Position the CPU stand under the desk and attach the iron hooks to the desired locations on the desk frame.
7. **Adjust Foot Pads:** Adjust the foot pads at the bottom of the desk legs to ensure stability on uneven floors.



An image showing the Casaottima L-shaped desk integrated into a home office environment, highlighting its spacious design and how it accommodates multiple monitors, a laptop, and other office essentials.

Drawer Installation

The fabric drawers are designed for easy assembly:

1. **Step 1: Unfold the Drawer.**



Unfold the fabric drawer from its collapsed state.

2. **Step 2: Insert Bottom Panel.**



Place the rigid bottom panel into the base of the unfolded drawer to provide stability.

3. **Step 3: Complete Assembly.**



Ensure the drawer is fully formed and ready to be inserted into the desk's drawer unit.



A close-up image of the four-tier fabric drawer unit. Two drawers are partially open, revealing organized storage for items such as stationery, gaming accessories, and personal belongings, demonstrating the ample storage capacity.


CPU Stand and Iron Hooks



This image highlights two key features: a dedicated CPU stand designed to elevate the computer tower off the floor, protecting it from dust and moisture, and a convenient iron hook attached to the desk frame, ideal for hanging headphones or other accessories.

The dedicated CPU stand elevates your computer tower, protecting it from dust and moisture. The two iron hooks can be attached to the desk frame to hang headphones, cables, or other accessories, keeping your workspace tidy.

Adjustable Foot Pads




A detailed image of the adjustable foot pads located at the base of the desk legs. These pads can be rotated to stabilize the desk on uneven floors and prevent damage to the flooring.

The desk is equipped with adjustable foot pads. Rotate these pads clockwise or counter-clockwise to level the desk on

uneven surfaces, ensuring stability and preventing wobbling.

Operating Instructions

Built-in Power Outlets and USB Ports



An infographic illustrating the features of the built-in power outlet, including two 5V/2A USB ports, three 125V/12A AC outlets, and a 6.6-foot power cord, providing convenient power access.


The desk includes a recessed power outlet with 3 AC outlets (125V/12A) and 2 USB ports (5V/2A). Plug the desk's power cord into a wall outlet. You can then plug in your devices directly to the desk for convenient power access and charging.

Storage Features

Utilize the four fabric drawers for organizing documents, stationery, gaming accessories, and personal items. The two iron hooks provide a convenient spot for hanging headphones or other small items, helping to keep your desktop clear and organized.

Maintenance

Cleaning and Care



A graphic displaying samples of the desk board material, emphasizing its waterproof, scratch-resistant, and easy-to-clean properties, ensuring durability and ease of maintenance.

- **Surface Cleaning:** The desk boards are waterproof and scratch-resistant. Wipe surfaces with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals.
- **Drawer Care:** The fabric drawers can be spot cleaned with a damp cloth. Do not machine wash.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain desk stability.

Troubleshooting

Common Issues and Solutions

- **Desk is Wobbly:**
  Ensure the desk is on a level surface. Adjust the foot pads at the bottom of each leg until the desk is stable. Double-check that all assembly screws are fully tightened.
- **Missing Parts:**
  Refer to the 'Package Contents' section and the assembly guide to confirm all parts. If parts are missing, contact Casaottima customer support immediately.
- **Power Outlet Not Working:**
  Verify that the desk's power cord is securely plugged into a functional wall outlet. Check if the wall outlet itself is receiving power. Ensure the power outlet unit is correctly seated in its slot.
- **Difficulty Assembling:**
  Review the assembly instructions carefully, paying close attention to the orientation of parts. Some steps may require two people. If issues persist, contact customer support.

Specifications

Feature	Detail


Brand	Casaottima
Model Number	SPCB02021501004USDF
Product Dimensions (D x W x H)	18.9"D x 53.2"W x 29.9"H
Color	Black
Material	Engineered Wood (Top), Metal (Base)
Item Weight	39.33 Pounds
Number of Drawers	4
Power Outlet	3 AC Outlets (125V/12A), 2 USB Ports (5V/2A)
Special Features	Reversible Design, CPU Stand, Iron Hooks, Adjustable Foot Pads
Assembly Required	Yes (Tools Included)

Warranty and Support

Warranty Information

This Casaottima L-Shaped Desk comes with a Limited Warranty. Please refer to your purchase documentation for specific terms and conditions of the warranty.

Customer Support



A graphic outlining the steps to contact Casaottima customer service through Amazon for assistance with missing parts or product issues, emphasizing the company's commitment to product responsibility.

For any questions, missing parts, or issues with your Casaottima desk, please contact our customer service team. You can typically find support information through your purchase platform (e.g., Amazon):

1. Go to your 'Returns & Orders' section.
2. Locate your order for the Casaottima L-Shaped Desk and click 'View order details'.
3. Click the 'store name' (Casaottima Store) following 'Sold by' below the product title.

4. Click the 'Ask a question' button to send a message to our support team.

We are committed to providing support for our products and ensuring customer satisfaction.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHGRBV94

More documents and user manuals: **https://manuals.plus/**