

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Klipsch](#) /

> [Klipsch Flexus SURR 200 Surround Speakers User Manual](#)

Klipsch Flexus SURR 200

Klipsch Flexus SURR 200 Surround Speakers User Manual

Model: Flexus SURR 200 | Brand: Klipsch

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Klipsch Flexus SURR 200 Dolby Atmos Enhanced Surround Speakers. These speakers are designed to work exclusively with Klipsch Flexus Sound Bars to deliver an immersive, multidimensional audio experience for movies, music, and games.

WHAT'S IN THE BOX

Verify that all components are present:

- Surround Sound Speakers (2 units)
- Power Cables (2 units)
- User Manual (this document)

SETUP INSTRUCTIONS

1. Placement

The Flexus SURR 200 speakers can be placed on a flat surface or wall-mounted for optimal sound dispersion. Ensure they are positioned to the sides or slightly behind your primary listening area for the best surround sound effect.



Image: Front view of two Klipsch Flexus SURR 200 speakers, showing their compact design.






Image: Side view of a single Klipsch Flexus SURR 200 speaker, highlighting its angled top for Dolby Atmos effects.



Image: Rear view of two Klipsch Flexus SURR 200 speakers, illustrating the power input and the 1/4-20 threaded insert for wall mounting.

2. Power Connection

Each Flexus SURR 200 speaker is independently powered. Connect each speaker directly to a wall outlet using its dedicated power cable. No additional adapters or speaker wires are required between the speakers or to the soundbar.

3. Pairing with Klipsch Flexus Sound Bar

The Flexus SURR 200 speakers are designed to work exclusively with Klipsch Flexus CORE 100, CORE 200, and CORE 300 Sound Bars. The speakers utilize a USB pre-paired dongle for wireless connectivity. Refer to your Klipsch Flexus Sound Bar manual for specific pairing instructions. Generally, the speakers should automatically connect to your soundbar once powered on and within range.

4. Klipsch Connect Plus App Setup

For advanced control and customization, download the Klipsch Connect Plus app on your smartphone or tablet. The app allows you to:

- Customize your personal EQ settings.
- Explore various sound modes.
- Enhance dialogue clarity.
- Control individual channel levels, including height and surround.

Your browser does not support the video tag.

Video: An official Klipsch video demonstrating the features and setup of the Flexus sound system, including the Connect Plus app.

OPERATING INSTRUCTIONS

Dolby Atmos Experience

The Flexus SURR 200 speakers feature Dolby Atmos technology with two 3-inch up-firing drivers and two 3-inch front-firing drivers. This configuration creates a three-dimensional soundstage, placing audio effects above and around you for a truly immersive experience. Ensure your content supports Dolby Atmos for the full effect.

Sound Customization

Use the Klipsch Connect Plus app to fine-tune your audio. Adjust individual speaker levels, experiment with different sound modes (e.g., Movie, Music, Game), and utilize the EQ settings to match your personal preferences and room acoustics.

MAINTENANCE

To ensure the longevity and optimal performance of your Klipsch Flexus SURR 200 speakers, follow these simple maintenance guidelines:

- **Cleaning:** Gently wipe the speaker surfaces with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or sprays directly on the speakers.
- **Placement:** Keep speakers away from direct sunlight, heat sources, and excessive moisture. Ensure adequate ventilation around the units.
- **Cables:** Periodically check power cables for any signs of damage. Do not use damaged cables.

TROUBLESHOOTING

If you encounter issues with your Flexus SURR 200 speakers, refer to the following common solutions:

- **No Sound from Speakers:**

- Ensure both speakers are properly plugged into a power outlet and powered on.
- Verify that the speakers are successfully paired with your Klipsch Flexus Sound Bar. Check the soundbar's display or app for connection status.
- Confirm that the volume levels for the surround channels are not set to minimum in the Klipsch Connect Plus app.
- Check the audio output settings on your TV or source device to ensure surround sound is enabled.

- **Low Volume from Speakers:**

- Adjust the individual channel levels for the surround speakers using the Klipsch Connect Plus app.
- Ensure the soundbar's overall volume is at an appropriate level.
- Some content may have lower surround channel output; try different audio sources to confirm.

- **Intermittent Connection/Audio Dropouts:**

- Ensure the speakers are within the recommended wireless range of your Klipsch Flexus Sound Bar.
- Minimize interference from other wireless devices (e.g., Wi-Fi routers, cordless phones) by repositioning them or the speakers.
- Restart both the speakers and the soundbar.

SPECIFICATIONS

Brand	Klipsch
Model Name	Flexus SURR 200
Model Number	1072090
Speaker Maximum Output Power	200 Watts
Frequency Response	20 Hz
Connectivity Technology	USB Pre-Paired Dongle
Audio Output Mode	Surround
Mounting Type	Tabletop Mount, Wall Mountable
Enclosure Material	Plastic Or Metal
Speaker Type	Surround Sound
Color	Black

Control Method	Touch (via soundbar/app)
Item Dimensions (D x W x H)	4.31"D x 4.13"W x 8.75"H
Wireless Technology	Wi-Fi, Flexus Transport 5 GHz
Number of Items	2
UPC	743878066753

WARRANTY INFORMATION

The Klipsch Flexus SURR 200 speakers come with a **2-Year Limited Warranty**. For detailed terms and conditions, please refer to the warranty documentation included with your product or visit the official Klipsch website.

CUSTOMER SUPPORT

For further assistance, technical support, or to explore other Klipsch products, please visit the official Klipsch Store:

[Visit the Klipsch Store on Amazon](#)