

## LIVOWALNY Cordless Leaf Blower (B0DHHCV7Y3)

# LIVOWALNY Cordless Leaf Blower

Model: B0DHHCV7Y3

Instruction Manual

## 1. SAFETY INSTRUCTIONS

Read all safety warnings and instructions before operating this product. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- **Work Area Safety:** Keep the work area clean and well-lit. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- **Electrical Safety:** This tool is battery-operated. Ensure the battery pack is compatible with the tool. Do not handle battery packs or tools with wet hands.
- **Personal Safety:** Always wear eye protection, hearing protection, and appropriate clothing. Do not overreach. Maintain proper footing and balance at all times.
- **Tool Use and Care:** Do not force the power tool. Use the correct power tool for your application. Disconnect the battery pack from the tool before making any adjustments, changing accessories, or storing power tools.
- **Battery Pack Use and Care:** This tool is compatible with Dewalt 20V lithium-ion batteries (DCB206, DCB204, DCB181, DCB182, DCB200, DCB203, etc.). Always use the specified charger for the battery pack.

## 2. PRODUCT OVERVIEW

The LIVOWALNY Cordless Leaf Blower is designed for efficient outdoor and indoor cleaning tasks. It features a powerful brushless motor and adjustable speed settings for versatile use.

### Key Components

# LIVOWALNY CORDLESS LEAF BLOWER



Image: Labeled diagram of the leaf blower showing its main parts.

1. **6-Speed Dial:** Adjusts the airflow speed.
2. **Locking Button:** Maintains the selected speed without continuous trigger pressure.
3. **On/Off Switch:** Powers the unit on and off.
4. **Non-Slip Handle:** Ergonomically designed for comfortable and secure grip.
5. **Blower Tube:** Directs the airflow.
6. **Extension Tube:** Provides extended reach for various tasks.
7. **Copper Brushless Motor:** Delivers high performance, efficiency, and longer service life.

## Features

- **High Performance Brushless Motor:** Copper brushless motor with no-load speeds up to 15,700 RPM for reduced noise, increased power, and greater efficiency.
- **6 Adjustable Wind Speeds:** Offers up to 500CFM/150MPH airflow with a locking button for flexible operation.
- **Ergonomic Design:** Features a rubberized non-slip handle and a lightweight body (6.5 pounds) for comfortable single-hand operation.
- **Wide Application:** Suitable for cleaning patios, lawns, gardens, garages, sidewalks, porches, decks, and for clearing wet leaves and snow.
- **Cordless Compatibility:** Designed for use with Dewalt 20V lithium-ion batteries (battery not

included).

### 3. SETUP

Follow these steps to assemble and prepare your leaf blower for use.

#### Assembly



Image: Visual guide for assembling the leaf blower.

1. **Attach Extension Nozzle:** Align the widest end of the extension tube with the front opening on the blower.
2. **Secure Blower Tube:** Slide the blower tube over the blower outlet opening until the lock button on the blower is inserted into the opening on the tube, securing it in place.

#### Battery Installation (Battery Not Included)

# COMPATIBLE WITH DEWALT 20V BATTERY

Battery and charger not included

**2.9  
KG**  
COMPACT AND  
LIGHTWEIGHT



Image: Demonstrates inserting a Dewalt 20V battery into the blower.

- Ensure the leaf blower is turned off.
- Slide a charged Dewalt 20V lithium-ion battery (e.g., DCB206, DCB204, DCB181, DCB182, DCB200, DCB203) into the battery port on the tool until it clicks securely into place.
- To remove, press the battery release button and slide the battery out.
- **Note:** For optimal performance, a 4.0AH or higher capacity battery is recommended.

## 4. OPERATING INSTRUCTIONS

Learn how to effectively use your LIVOWALNY Cordless Leaf Blower for various cleaning tasks.

### Powering On and Off

- To turn on, press the On/Off switch.
- To turn off, release the On/Off switch.

### Adjusting Speed



Image: Diagram illustrating the 6-speed dial and lock button.

- Use the 6-speed dial to select your desired airflow intensity, from low (1) to high (6).
- The blower offers up to 500CFM/150MPH at maximum speed.
- To maintain a constant speed without holding the trigger, press the locking button while the blower is running at your desired speed. Press the trigger again to release the lock.

## Applications



Image: Collage showing the leaf blower in use for clearing leaves, snow, and debris.

- **Leaves:** Use higher speeds for dry leaves and lower speeds for delicate areas or small piles.
- **Snow:** Effective for light, powdery snow on pathways and vehicles.
- **Debris:** Clear grass clippings, dust, and small stones from hard surfaces.
- **Household Cleaning:** Can be used for clearing sawdust in workshops or dust from car interiors.

## Demonstration Video

Your browser does not support the video tag.

Video: A short demonstration of the LIVOWALNY Cordless Leaf Blower in action, showcasing its power and versatility for clearing leaves and snow.

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your leaf blower.

- **Cleaning:** After each use, wipe down the exterior of the blower with a clean, damp cloth. Ensure the air intake vents are free from debris to prevent overheating.
- **Storage:** Store the leaf blower in a dry, secure location away from children and direct sunlight.

Remove the battery pack before storing for extended periods.

- **Inspection:** Periodically check for loose screws, damaged parts, or excessive wear. Do not use the tool if any parts are damaged.
- **Battery Care:** Always charge batteries in a well-ventilated area. Do not store batteries in extreme temperatures.

## 6. TROUBLESHOOTING

If you encounter issues with your leaf blower, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Blower does not start	Battery not installed correctly or discharged.	Ensure battery is fully charged and properly seated.
Low airflow/power	Battery low, speed setting too low, or air intake/nozzle blocked.	Charge battery, increase speed setting, clear any obstructions. Use a 4.0AH or higher battery for best performance.
Blower stops during operation	Battery overheated or discharged, or motor overload protection activated.	Allow battery to cool, recharge battery, or reduce load on the motor.

## 7. SPECIFICATIONS

Detailed technical specifications for the LIVOWALNY Cordless Leaf Blower.

- **Brand:** LIVOWALNY
- **Model:** B0DHHCV7Y3
- **Power Source:** Battery Powered (Compatible with Dewalt 20V batteries)
- **Voltage:** 20 Volts
- **Maximum Airflow:** 500 CFM
- **Maximum Air Speed:** 150 MPH
- **Maximum Motor Speed:** 15700 RPM
- **Form Factor:** Handheld
- **Special Features:** Adjustable Speed, Brushless Motor
- **Product Dimensions:** 80 x 15 x 22 cm
- **Item Weight:** 2.7 kg
- **Material:** Copper, Plastic
- **Included Components:** Extension Nozzle
- **Country of Origin:** China

## 8. WARRANTY AND SUPPORT

Information regarding product warranty and how to obtain support.

### Manufacturer Warranty

This LIVOWALNY product comes with a **6-month manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, abuse, accidents, unauthorized repairs, or normal wear and tear.

### Customer Support

For technical assistance, warranty claims, or general inquiries, please contact LIVOWALNY customer support through the retailer's platform where the product was purchased. Please have your purchase receipt and product model number (B0DHHCV7Y3) available when contacting support.