



Manuals.plus /

› Energy Sistem /

› Energy Sistem Tower 5 MAX Audio Tower Instruction Manual

## Energy Sistem Tower 5 MAX

# Energy Sistem Tower 5 MAX Audio Tower Instruction Manual

Model: Tower 5 MAX

## 1. INTRODUCTION

---

This manual provides essential information for the safe and efficient operation of your Energy Sistem Tower 5 MAX audio tower. Please read these instructions carefully before using the device and retain them for future reference. The Tower 5 MAX is a 100W 2.1 sound system featuring Bluetooth 5.3, True Wireless Stereo (TWS) functionality, USB and microSD playback, FM Radio, and an auxiliary input.



Image 1.1: Front view of the Energy Sistem Tower 5 MAX with the remote control.

## 2. WHAT'S IN THE BOX

---

Verify that all components are present upon unpacking:

- Energy Sistem Tower 5 MAX unit
- Remote control + batteries
- Quick start guide
- FM antenna
- Power cable



Image 2.1: Product packaging illustrating included items and features.

### 3. PRODUCT OVERVIEW

#### 3.1. Front Panel

The front panel features the main speaker drivers and a display for current mode and settings.





ENERGY SYSTEM

Image 3.1: Front view of the audio tower.

### 3.2. Top Panel

The top panel provides access to various input ports and control buttons.





Image 3.2: Top panel with USB ports, microSD slot, AUX input, and FM antenna connection.

- **USB Ports:** For playing MP3 files from USB drives.
- **MicroSD Slot:** For playing MP3 files from microSD cards.
- **AUX Input:** 3.5mm jack for connecting external audio devices.
- **FM Antenna Port:** For connecting the included FM antenna.
- **Control Buttons:** Power, Mode, Play/Pause, Track Skip, Volume.

### 3.3. Remote Control

The included remote control allows for convenient operation of all functions from a distance.



Image 3.3: Remote control unit.

- **Power Button:** Turns the device on or off.
- **Mode Button:** Cycles through input modes (Bluetooth, USB, SD, FM, AUX).
- **Volume +/-:** Adjusts the master volume.
- **Play/Pause:** Controls media playback.
- **Previous/Next Track:** Skips tracks or tunes FM radio frequencies.
- **EQ Button:** Selects different equalization presets.

## 4. SETUP

---

### 4.1. Unpacking

Carefully remove the audio tower and all accessories from the packaging. Retain the packaging for potential future transport or storage.

### 4.2. Placement

Place the Tower 5 MAX on a stable, flat surface. Ensure there is adequate ventilation around the unit. Avoid placing it near heat sources, direct sunlight, or in areas with high humidity.

### 4.3. Connecting Power

Connect the provided power cable to the power input on the rear of the tower, then plug the other end into a suitable wall outlet.

### 4.4. Connecting FM Antenna

For optimal FM radio reception, connect the included FM antenna to the designated port on the top panel of the tower. Extend the antenna fully for better signal quality.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Power On/Off

Press the Power button on the top panel or the remote control to turn the device on or off.

### 5.2. Mode Selection

Press the 'Mode' button on the top panel or remote control to cycle through available input sources: Bluetooth, USB, SD, FM Radio, and AUX Input.

### 5.3. Bluetooth Connection

1. Switch the tower to Bluetooth mode. The display will show 'BT' and flash, indicating it's in pairing mode.
2. Enable Bluetooth on your mobile device (smartphone, tablet, etc.).
3. Search for 'Energy Sistem Tower 5 MAX' in your device's Bluetooth list.
4. Select the device to pair. Once connected, the 'BT' indicator will stop flashing.

### 5.4. USB/SD Playback

The Tower 5 MAX supports MP3 playback from USB drives and microSD cards up to 128 GB.

1. Insert a USB drive into a USB port or a microSD card into the microSD slot on the top panel.
2. Switch the tower to USB or SD mode using the 'Mode' button. Playback will begin automatically.
3. Use the Play/Pause, Previous/Next Track buttons on the top panel or remote to control playback.




Image 5.1: USB and MicroSD playback options.

## 5.5. FM Radio Operation

1. Switch the tower to FM Radio mode.
2. **Auto-scan:** Press and hold the Play/Pause button to automatically scan and save available FM stations.
3. **Manual Tuning:** Use the Previous/Next Track buttons to manually tune to desired frequencies or navigate through saved stations.

## 5.6. AUX Input

Connect any external audio device (e.g., MP3 player, TV) to the 3.5mm AUX input port on the top panel using a 3.5mm audio cable (not included). Switch the tower to AUX mode.

## 5.7. True Wireless Stereo (TWS) Pairing

To achieve a stereo sound experience, two Energy Sistem Tower 5 MAX units can be paired wirelessly.

1. Ensure both Tower 5 MAX units are powered on and in Bluetooth mode, but not yet paired with any mobile device.
2. On one of the towers (this will be the master unit), press and hold the TWS button (if available, or a specific pairing button as per quick guide) until you hear a confirmation tone.
3. The two towers will automatically connect. Once connected, the master unit's Bluetooth indicator will flash, and the slave unit's indicator will be solid.
4. Now, pair your mobile device with the master unit as described in section 5.3.



Image 5.2: True Wireless Stereo pairing for enhanced sound.

## 5.8. Sound Equalization

Use the 'EQ' button on the remote control to cycle through various preset equalization modes (e.g., Rock, Pop, Classic, Jazz, Flat) to adjust the sound characteristics according to your preference. Some models may also feature separate bass and treble controls, typically located on the rear panel.

## 6. MAINTENANCE

---

### 6.1. Cleaning

Wipe the exterior of the tower with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents. Ensure the device is unplugged before cleaning.

### 6.2. Storage

If storing the device for an extended period, unplug it from the power outlet and store it in a cool, dry place, away from direct sunlight and extreme temperatures.

### 6.3. Safety Guidelines

- Do not expose the device to water or moisture.
- Do not open the casing; refer all servicing to qualified personnel.
- Keep out of reach of children.
- Ensure proper ventilation to prevent overheating.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active.	Check power cable connection; Try a different outlet.
No sound	Volume too low; Incorrect input mode; Device not paired (Bluetooth).	Increase volume; Select correct input mode; Repair Bluetooth device.
Bluetooth pairing fails	Tower not in pairing mode; Device too far; Interference.	Ensure tower is in BT pairing mode; Move device closer; Turn off other Bluetooth devices.
Poor FM reception	Antenna not connected or extended; Weak signal.	Connect and extend FM antenna; Reposition antenna or tower.
USB/SD playback issues	Unsupported file format; Corrupt files; Drive/card not inserted correctly.	Ensure files are MP3; Check drive/card for errors; Reinsert drive/card.

## 8. SPECIFICATIONS

<b>Model Name</b>	Tower 5 MAX
<b>Output Power</b>	100 W
<b>Sound Configuration</b>	2.1 (with 5-inch subwoofer)
<b>Connectivity</b>	Bluetooth 5.3, USB, MicroSD, FM Radio, AUX-in (3.5mm)
<b>USB/MicroSD Capacity</b>	Up to 128 GB (MP3 playback)
<b>Wireless Range</b>	Up to 20 meters (Bluetooth)
<b>Frequency Response</b>	Up to 18 KHz
<b>Control Method</b>	Remote control, On-device buttons
<b>Compatible Devices</b>	Mac, PC Windows, Smartphone, Tablet, TV
<b>Dimensions (W x D x H)</b>	15 cm x 17 cm x 100 cm
<b>Weight</b>	5.5 kg
<b>Power Source</b>	AC Power Cable
<b>Color</b>	Black

## 9. WARRANTY AND SUPPORT

---

### 9.1. Warranty Information

This product comes with a limited warranty. Please refer to the warranty card included in your package or visit the official Energy Sistem website for detailed terms and conditions regarding your product's warranty coverage.

### 9.2. Customer Support

For technical assistance, product inquiries, or service requests, please contact Energy Sistem customer support. You can find contact information and frequently asked questions on the official Energy Sistem website: [www.energysistem.com](http://www.energysistem.com).