**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## RCA RC-CAF5

# RCA RC-CAF5 Professional 2-in-1 Coffee Maker User Manual

Model: RC-CAF5

## 1. Introduction

Thank you for choosing the RCA RC-CAF5 Professional 2-in-1 Coffee Maker. This appliance is designed to provide a versatile coffee experience, allowing you to prepare beverages using both ground coffee and capsules. It features a smart display, a professional frother, and a 1.5-liter removable water tank for convenience. Please read this manual thoroughly before first use to ensure safe operation and optimal performance.

## 2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Extreme caution must be used when moving an appliance containing hot liquids.

## 3. Product Components

Familiarize yourself with the parts of your RCA RC-CAF5 coffee maker before operation.




**Image:** Overview of the RCA RC-CAF5 coffee maker with key components labeled.

- **Support Plate:** Top surface for cup warming.
- **Water Tank:** Removable 1.5L tank for water.
- **Steam Knob:** Controls steam for frothing.
- **Smart Display:** Intuitive interface for selecting functions.

- **Frother:** Steam wand for milk frothing.
- **Capsule Filter:** Specific filter for coffee capsules.
- **Espresso Filters:** Filters for single or double espresso shots using ground coffee.
- **Portafilters:** Holders for ground coffee and capsule filters.
- **Tamper Spoon:** Measures and tamps ground coffee.




**Image:** Detailed view of the smart display, indicating functions like Espresso, Double Espresso, Espresso Cool, Americano, and Steam.

## 4. Setup and First Use

Before using your coffee maker for the first time, follow these steps:

1. **Unpack:** Carefully remove all packaging materials and ensure all components are present and undamaged.

2. **Clean:** Wash the water tank, portafilters, and filters with warm soapy water. Rinse thoroughly and dry. Wipe the exterior of the machine with a damp cloth.
3. **Fill Water Tank:** Fill the removable water tank with fresh, cold water up to the MAX level. Ensure the tank is properly seated.
4. **Initial Rinse Cycle:** Plug the coffee maker into a grounded electrical outlet. Place a large cup or container under the coffee spout. Turn on the machine. Select the 'Espresso' function without any coffee in the filter. Allow water to run through the system to clean internal components. Repeat this process 2-3 times.
5. **Steam Rinse:** After the water cycle, activate the steam function briefly to clear any residue from the frother wand.




**Image:** Visual guide demonstrating the initial steps for preparing coffee, including adding water, adding ground coffee, installing the portafilter, selecting 'Espresso', selecting 'Steam', and combining for a latte.

## 5. Operating Instructions

Your RCA RC-CAF5 offers 5 intelligent functions for various coffee preparations.

### 5.1. Preparing Coffee (Ground Coffee)

1. Ensure the water tank is filled with fresh water.
2. Select the appropriate espresso filter (single or double) and place it into the ground coffee portafilter.
3. Add desired amount of finely ground coffee to the filter. Use the tamper spoon to level and gently tamp the coffee.
4. Attach the portafilter to the brewing head by aligning it and twisting firmly to the right until secure.
5. Place a cup(s) on the drip tray directly under the portafilter spouts.
6. Turn on the machine using the OFF/ON button on the smart display.
7. Select your desired coffee function from the smart display:

- **Espresso:** For a single shot of espresso.
- **2x Espresso:** For a double shot of espresso.
- **Americano:** For a diluted espresso.
- **Espresso Cool:** For a cold espresso preparation.

8. The machine will begin brewing. Wait for the process to complete.

## 5.2. Preparing Coffee (Capsules)

1. Ensure the water tank is filled with fresh water.
2. Place a coffee capsule into the capsule filter.
3. Attach the capsule portafilter to the brewing head by aligning it and twisting firmly to the right until secure.
4. Place a cup(s) on the drip tray directly under the portafilter spouts.
5. Turn on the machine using the OFF/ON button on the smart display.
6. Select your desired coffee function (Espresso, 2x Espresso, Americano, Espresso Cool) from the smart display.
7. The machine will begin brewing. Wait for the process to complete.

## 5.3. Using the Professional Frother (Steam Function)

The integrated frother allows you to create lattes, cappuccinos, and other milk-based beverages.

1. Fill a pitcher with cold milk (dairy or non-dairy). Do not fill more than one-third of the pitcher.
2. Ensure the water tank is filled.
3. Turn on the machine. Select the 'Steam' function on the smart display. The machine will heat up to generate steam.
4. Once the steam icon is stable, position the frother wand into the milk, just below the surface.
5. Slowly turn the steam knob counter-clockwise to release steam.
6. Move the pitcher up and down gently to create foam. For more foam, keep the wand closer to the surface; for hotter milk, submerge it deeper.
7. Once desired texture and temperature are reached, turn the steam knob clockwise to close the steam.
8. Remove the pitcher and immediately wipe the frother wand with a damp cloth to prevent milk residue from drying.




**Image:** A hand holding a milk pitcher under the frother wand, demonstrating the milk frothing process.




**Image:** Detail of the steam knob, used to adjust milk texture for creamy and professional coffee at home.

## 6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

### 6.1. Daily Cleaning

- **Drip Tray:** Empty and clean the drip tray after each use or when the indicator shows it is full. Wash with warm soapy water and rinse.
- **Portafilters and Filters:** Remove and rinse the portafilters and filters immediately after use to remove coffee grounds or capsule residue.
- **Frother Wand:** Immediately after frothing milk, wipe the frother wand with a damp cloth to prevent milk from drying and clogging. Purge steam briefly to clear any internal milk residue.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or scourers.

### 6.2. Water Tank Cleaning

The 1.5L removable water tank should be cleaned regularly, especially if you notice any residue or mineral buildup.

- Remove the water tank from the machine.
- Wash with warm soapy water and a soft brush.
- Rinse thoroughly to remove all soap residue.
- Refill with fresh water before placing it back on the machine.

### 6.3. Descaling

Depending on water hardness, descaling should be performed every 2-3 months to prevent mineral buildup, which can affect performance and taste.

- Use a commercial descaling solution specifically designed for coffee machines, following the manufacturer's instructions.
- Alternatively, you can use a solution of white vinegar and water (1:1 ratio).
- Fill the water tank with the descaling solution.
- Run several brewing cycles without coffee until the tank is empty.
- Run several cycles with fresh water to rinse out any descaling solution residue.

## 7. Troubleshooting

If you encounter issues with your coffee maker, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| No water dispenses / Machine does not brew. | Water tank empty or not properly seated. Pump airlock. Clogged filter. | Ensure water tank is full and correctly inserted. Perform an initial rinse cycle to prime the pump. Clean the filter and portafilter. Descale the machine if mineral buildup is suspected. |
| Coffee is too weak or watery. | Coffee ground too coarse. Not enough coffee. Insufficient tamping. | Use finer ground coffee. Increase the amount of coffee. Tamp coffee more firmly. |
| Coffee drips slowly or not at all. | Coffee ground too fine. Too much coffee. Over-tamping. Clogged filter. | Use coarser ground coffee. Reduce the amount of coffee. Tamp coffee less firmly. Clean the filter and portafilter. Descale the machine. |
| Milk frother not producing steam or foam. | Frother wand clogged with dried milk. Insufficient heating. | Clean the frother wand immediately after each use. Use a needle or pin to clear any blockages in the steam nozzle. Ensure the machine has fully heated up for the steam function. |
| Machine turns off unexpectedly. | Overheating protection. Power supply issue. | Unplug the machine and let it cool down for 30 minutes before restarting. Ensure the power outlet is functioning correctly. |

If the problem persists after attempting these solutions, please contact customer support.

## 8. Specifications

Detailed technical specifications for the RCA RC-CAF5 Professional 2-in-1 Coffee Maker.

- **Brand:** RCA
- **Model Number:** RC-CAF5
- **Color:** Black
- **Capacity:** 1.5 Liters

- **Material:** Stainless Steel
- **Special Features:** Milk Frother, Smart Display
- **Product Dimensions:** 54 cm (Depth) x 33 cm (Width) x 38 cm (Height)
- **Product Weight:** 3 Kilograms
- **Power:** 120V~, 60Hz, 1350W
- **Included Components:** Milk Frother (integrated), Tamper Spoon, Ground Coffee Portafilter, Capsule Portafilter, Espresso Filters, Capsule Filter.




**Image:** Detailed dimensions of the RCA RC-CAF5 coffee maker and its accessories, including portafilters and capsule filters.

## 9. Warranty and Support

Your RCA RC-CAF5 Professional 2-in-1 Coffee Maker is backed by a warranty and customer support.

## 9.1. Warranty Information

The product is insured for 1 year against manufacturing defects or damage during shipping. Please retain your proof of purchase for warranty claims.




**Image:** Information regarding the 1-year warranty against factory defects or shipping damage, and instructions for requesting an invoice.

## 9.2. Customer Support

For technical assistance, warranty claims, or any questions regarding your product, please contact RCA customer support. Refer to your purchase documentation for specific contact details.
For invoicing, please send your details via message through your order platform.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0DHHZDJK5**

More documents and user manuals: **https://manuals.plus/**