

[manuals.plus](#) /

› [Sauder](#) /

› [Sauder Craft Works Craft Workstation with Storage, Khaki Pine Finish 22.25" - Instruction Manual](#)

Sauder 435234

Sauder Craft Works Craft Workstation with Storage, Khaki Pine Finish 22.25" - Instruction Manual

Model: 435234

Brand: Sauder

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Sauder Craft Works Craft Workstation with Storage. This workstation is designed to provide an organized and functional space for crafting activities. It features a compact design that expands to offer a work surface and integrated storage solutions.



Image: The Sauder Craft Works Craft Workstation in its closed, compact form, situated in a room setting.

IMPORTANT SAFETY INFORMATION

- Always follow general safety precautions when assembling and using furniture.
- Keep the workstation away from direct heat sources to prevent damage to the material.
- Do not overload shelves or surfaces beyond their intended capacity.
- Exercise caution when using sharp tools near the workstation surfaces.
- **California Proposition 65 Warning:** This product may expose you to chemicals including Formaldehyde, which is known to the State of California to cause cancer. For more information, go to www.p65warnings.ca.gov.

INCLUDED COMPONENTS

Your Sauder Craft Works Craft Workstation package includes the following:

- All necessary materials for the furniture structure.
- Required hardware for assembly.
- Detailed assembly instructions.

Please verify all components are present before beginning assembly. If any parts are missing or damaged, please contact Sauder customer support.

SETUP AND ASSEMBLY

Assembly of the Sauder Craft Works Craft Workstation is required. Follow the included detailed assembly instructions carefully. It is recommended to assemble the unit in the room where it will be used due to its weight.

Assembly Tips:

- Lay out all parts and hardware before starting.
- Use a soft surface to prevent scratching furniture pieces during assembly.
- Do not overtighten screws.
- For cam and dowel connections, ensure the cam arrow aligns with the edge of the board before turning to lock.

Assembly Video: Cam and Dowel Connections

This video demonstrates the proper technique for assembling components using cam and dowel fasteners, a common method in Sauder furniture.

Your browser does not support the video tag.

Video: Instructions on how to assemble Cam and Dowel connections for Sauder furniture.

OPERATING INSTRUCTIONS

The Craft Works Workstation is designed for versatility and efficient space utilization. It transforms from a compact cabinet into an expansive work area with integrated storage.

Expanding the Workstation:

1. **Open Doors:** Gently open the two swing-out doors. These doors feature pegboard backs for additional hanging storage.
2. **Extend Work Surface:** The center storage area includes a section that slides out. This section supports a drop-leaf extension, which can be lifted and secured to create an additional work surface.
3. **Access Interior Storage:** The slide-out section beneath the drop-leaf provides access to further storage. This includes three adjustable shelves on one side and three small, fixed shelves with metal retainer bars on the reverse side.



Image: The workstation fully expanded, revealing the large work surface and accessible storage compartments.

Storage Features:

- **Adjustable Shelves:** Three adjustable shelves allow customization for various craft supplies.
- **Fixed Shelves with Retainer Bars:** Three fixed shelves with metal retainer bars securely hold items in place.
- **Pegboard Doors:** The interior of the swing-out doors features pegboards, complete with two metal hooks, ideal for hanging tools or spools of ribbon.



Image: A detailed view of the workstation's interior storage, showcasing shelves and pegboard functionality.

Product Overview Video:

This video provides a visual demonstration of the Sauder Craft Works Craft Workstation, highlighting its transformation from a compact unit to an expanded workspace with storage.

Your browser does not support the video tag.

Video: A brief overview of the Sauder Craft Works Craft Workstation, demonstrating its expanding features.

MAINTENANCE

To ensure the longevity and appearance of your workstation, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the Khaki Pine finish.
- **Spills:** Clean up spills immediately to prevent staining or moisture damage.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Movement:** When moving the workstation, ensure the doors are closed and secured. Utilize the integrated wheels for easy repositioning.

TROUBLESHOOTING

If you encounter issues with your Sauder Craft Works Craft Workstation, consider the following common solutions:

- **Assembly Difficulties:** Review the assembly instructions carefully. Ensure all parts are correctly oriented and fasteners are properly installed. Refer to the "Cam and Dowel" assembly video if issues arise with these specific fasteners.
- **Missing Parts:** If any components or hardware are missing from your package, contact Sauder customer support for assistance. Do not attempt to substitute parts with non-approved items.
- **Stability Issues:** Ensure the workstation is placed on a level surface. Verify all assembly hardware is securely tightened.
- **Doors or Drawers Not Operating Smoothly:** Check for any obstructions. Ensure hinges and slides are properly aligned and free of debris.

SPECIFICATIONS

Feature	Detail
Brand	Sauder
Model Name	Craft Works
Model Number	435234
Color	Khaki Pine
Product Dimensions (Closed)	23.5"D x 22.25"W x 36"H
Material	Engineered Wood
Item Weight	119.4 Pounds
Special Feature	Wheeled
Number of Shelves	7 (3 adjustable, 3 fixed, plus pegboard storage)
Assembly Required	Yes

WARRANTY AND SUPPORT

Warranty: This Sauder Craft Works Craft Workstation is covered by a**5-Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support: For assistance with assembly, missing parts, or warranty inquiries, please visit the official Sauder website or contact their customer service department. Contact information can typically be found on the Sauder website or within the packaging materials.

