

Apple iPhone 16

Apple iPhone 16 (Renewed) User Manual

Model: iPhone 16, 128GB, Teal

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Apple iPhone 16 (Renewed). Please read it carefully to ensure optimal performance and longevity of your device.

Your renewed iPhone 16 has undergone a thorough inspection and testing process to ensure full functionality. While it may show minor cosmetic imperfections, it is certified to work like new.



Image: Front view of the Teal Apple iPhone 16.

What's in the Box:

- Apple iPhone 16 (Renewed)
- USB Cable

2. GETTING STARTED: SETUP

2.1 Powering On/Off

- **To Power On:** Press and hold the Side button until the Apple logo appears.
- **To Power Off:** Press and hold the Side button and either Volume button simultaneously. Drag the 'Slide to Power Off' slider. Alternatively, go to *Settings > General > Shut Down*

2.2 Initial Setup

Follow the on-screen instructions to set up your iPhone. This includes selecting your language and region, connecting to Wi-Fi, setting up Face ID, creating a passcode, and transferring data from a previous device or setting up as new.

2.3 eSIM Activation

The iPhone 16 US Version supports Dual eSIM. There is no physical SIM card slot. To activate cellular service:

1. Contact your carrier to obtain an eSIM profile.
2. Go to *Settings > Cellular > Add eSIM*
3. Follow the prompts to scan a QR code provided by your carrier or enter details manually.

2.4 Charging Your iPhone

Connect the provided USB cable to your iPhone's charging port and to a compatible USB power adapter (sold separately) or computer. The iPhone 16 also supports wireless charging.

3. OPERATING YOUR iPhone 16

3.1 Display and Navigation

Your iPhone 16 features a 6.1-inch Super Retina XDR OLED touchscreen display. Navigate using intuitive gestures:

- **Home Screen:** Swipe up from the bottom edge of the screen.
- **App Switcher:** Swipe up from the bottom edge and pause in the middle of the screen.
- **Control Center:** Swipe down from the top-right corner of the screen.
- **Notifications:** Swipe down from the top-center of the screen.

3.2 Camera Functions

The iPhone 16 is equipped with advanced camera systems:

- **Rear Camera:** 48MP wide lens (f/1.6) and 12MP ultrawide lens (f/2.2).
- **Front Camera:** 12MP wide lens (f/1.9).

Open the Camera app to access various modes like Photo, Portrait, Video, Cinematic, and more. Tap the shutter button to capture photos or start/stop video recording.

3.3 Connectivity

Your iPhone 16 supports a range of connectivity options:

- **Wi-Fi:** Connect to wireless networks for internet access. Go to *Settings > Wi-Fi*.
- **Bluetooth:** Pair with wireless accessories like headphones or speakers. Go to *Settings > Bluetooth*.
- **Cellular Data:** Utilize 4G LTE and 5G networks for mobile internet. Manage settings in *Settings > Cellular*.

4. MAINTENANCE

4.1 Battery Care

The iPhone 16 features a 3561 mAh battery. To maximize battery lifespan:

- Avoid extreme temperatures.
- Enable Optimized Battery Charging (*Settings > Battery > Battery Health & Charging*).
- Keep software updated.

4.2 Cleaning Your iPhone

Use a soft, lint-free cloth to clean your iPhone. Avoid abrasive materials, sprays, or solvents. For stubborn smudges, slightly dampen the cloth with water. Do not submerge your iPhone in cleaning agents.

4.3 Software Updates

Your iPhone runs on iOS 18, upgradable to iOS 18.5 and future versions. Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Go to *Settings* > *General* > *Software Update*.

5. TROUBLESHOOTING

5.1 Common Issues

- **Device Unresponsive:** Perform a force restart. Quickly press and release the Volume Up button, then quickly press and release the Volume Down button, then press and hold the Side button until the Apple logo appears.
- **Overheating:** If your device feels warm, especially during intensive tasks or initial setup, close background apps and allow it to cool down. Avoid direct sunlight.
- **Connectivity Problems:** Toggle Wi-Fi or Bluetooth off and on. Restart your iPhone. For cellular issues, ensure your eSIM is properly activated and contact your carrier.

5.2 Factory Reset

If you experience persistent issues, you may need to factory reset your iPhone. **Warning: This will erase all data on your device.** Back up your iPhone before proceeding.

1. Go to *Settings* > *General* > *Transfer or Reset iPhone*
2. Tap *Erase All Content and Settings*.
3. Follow the on-screen instructions.

6. SPECIFICATIONS

Feature	Detail
Model Name	Apple iPhone 16
Operating System	iOS 18 (upgradable to iOS 18.5)
Display	6.1-inch Super Retina XDR OLED, 2556 x 1179 resolution, 60 Hz refresh rate
Processor	Apple A18 (3nm), Hexa-core (2x4.04 GHz + 4x2.20 GHz)
RAM	8 GB
Storage	128 GB
Rear Camera	48MP (wide, f/1.6) + 12MP (ultrawide, f/2.2)
Front Camera	12MP (wide, f/1.9)
Battery Capacity	3561 mAh (typical)
Connectivity	5G, 4G LTE, Wi-Fi, Bluetooth, Dual eSIM
Dimensions	5.81 x 2.82 x 0.31 inches

Feature	Detail
Weight	5.9 ounces
Special Features	Wireless Charging

7. UNDERSTANDING YOUR RENEWED iPhone

Your Apple iPhone 16 is a renewed product, meaning it has been professionally inspected, tested, and cleaned to work and look like new. While fully functional, renewed products may have minor cosmetic imperfections.

Amazon Renewed conditions

All Amazon Renewed products are fully functional, and come with generic or original accessories and packaging.

Example body scratches and dents – not actual products



Image: Overview of Amazon Renewed product conditions.

Common conditions for renewed products include:

- **Excellent:** No cosmetic damage visible from 12 inches away. Screen and battery life (greater than 80%) are excellent.
- **Good:** Light scratches, barely visible from 12 inches away. Screen and battery life (greater than 80%) are good.
- **Acceptable:** Light scratches, clearly visible from 12 inches away. Screen may have scratches invisible when turned on. Battery life (greater than 80%) is acceptable.



Image: Visual examples of cosmetic conditions for renewed products.

8. WARRANTY AND SUPPORT

8.1 Amazon Renewed Guarantee

Your renewed iPhone 16 is backed by the Amazon Renewed Guarantee, which provides a refund or replacement within 90 days of receipt if the product does not work as expected. This guarantee is in addition to your statutory rights.

8.2 Apple Support

For technical assistance, software issues, or information regarding Apple's limited warranty for renewed products (if applicable), please visit the official [Apple Support website](#).

9. PRODUCT VIDEOS

9.1 iPhone 16 Overview

Video: A comprehensive overview of the Apple iPhone 16's features and design. (Duration: 4:18)

9.2 iPhone 16 Quick Look

Video: A quick demonstration of key functionalities and user interface of the Apple iPhone 16. (Duration: 1:37)

© 2026 Apple Inc. All rights reserved. This manual is for informational purposes only.