

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [NutriBullet](#) /

> [NutriBullet SmartSense Blender Combo NBF50700AK Instruction Manual](#)

NutriBullet NBF50700AK

NutriBullet SmartSense Blender Combo NBF50700AK Instruction Manual

Model: NBF50700AK | Brand: NutriBullet

INTRODUCTION

This comprehensive instruction manual provides essential information for the safe and effective use of your NutriBullet SmartSense Blender Combo. Designed for ease and precision, this 1400W blender features multiple attachment sizes, 5 variable speed settings, and a smart auto cycle. Please read this guide thoroughly before operating your appliance.

WHAT'S INCLUDED

Your NutriBullet SmartSense Blender Combo package includes the following components:

- 1400-Watt Motor Base
- 64 oz Blender Pitcher
- Pitcher Lid with Pour Spout
- Deluxe Easy-Twist Extractor Blade
- 32 oz Cup
- 24 oz Handled Cup
- 2 To-Go Lids
- Tamper
- Recipe Book
- User Guide (this document)

**Dishwasher-
safe pitcher,
cups, and
lids.**



nutribullet.



Image: A visual representation of all components included in the NutriBullet SmartSense Blender Combo package.

SETUP

Before first use, ensure all components are clean. Place the motor base on a clean, dry, and level surface. Attach your desired blending vessel (64oz pitcher or personal cup) to the motor base. For personal cups, twist the deluxe easy-twist extractor blade onto the cup, then invert and place onto the motor base. For the 64oz pitcher, simply place it onto the motor base and ensure it locks into place.



Image: The NutriBullet SmartSense Blender Combo displayed with both the large 64oz pitcher and a personal cup attached to the motor base, showcasing its versatility.

Video: This video demonstrates the assembly of the NutriBullet Triple Prep System, including how to attach the various blending vessels and accessories to the motor base.

OPERATING INSTRUCTIONS

The NutriBullet SmartSense Blender Combo offers both manual speed control and a smart auto cycle for optimal blending.

Power and Speed Settings

- **5 Variable Speeds:** Use the '+' and '-' buttons on the intuitive dot-matrix display to select speeds from 1 to 5. This dynamic range allows for precision blending, from delicate nut flours (Speed 1-2) to fully-emulsified nut milk (Speed 5).
- **Pulse Function:** For quick bursts of power, use the pulse button.
- **Smart Auto Cycle:** Press the 'AUTO' button. The blender will sense the ingredient load and automatically adjust speed, time, and function to deliver the smoothest possible results. This mode is ideal for smoothies, soups, and other consistent blends.

**Intuitive
interface
with dot
matrix
display.**



nutribullet.



Image: A close-up view of the blender's control panel, highlighting the intuitive dot-matrix display for easy navigation and setting adjustments.

Blending Tips

- For best results, add liquids first, then soft ingredients, and finally harder ingredients or ice.
- When using personal cups, the blender will automatically shut off after 60 seconds for safety. It also limits single-serve blending to 3 consecutive cycles in a 6-minute period.
- Utilize the tamper with the 64oz pitcher for thicker blends to push ingredients towards the blades.

Video: This video showcases the NutriBullet SmartSense Blender in action, demonstrating its powerful blending capabilities and the effectiveness of its auto mode for various ingredients.

Video: A user demonstrates the NutriBullet SmartSense Blender's auto mode, highlighting its convenience and efficiency in achieving desired blending consistency.

CLEANING & MAINTENANCE

Proper cleaning ensures the longevity and hygiene of your NutriBullet SmartSense Blender Combo:

- The pitcher, pitcher lid, and single-serve cups are all dishwasher safe.
- The extractor blades and to-go lids are top-rack dishwasher-safe.

- The Tamper and Motor Base are NOT dishwasher safe.
- Hand-wash the tamper with soap and water.
- The motor base should never be submerged in water; wipe any spots off the motor base with a damp cloth.

64-oz Blender Pitcher with integrated blade.



nutribullet.



Image: Various cups and lids from the NutriBullet SmartSense Blender Combo are shown, emphasizing their dishwasher-safe design for easy cleaning.

TROUBLESHOOTING

If you encounter any issues with your NutriBullet SmartSense Blender Combo, please refer to the following general advice:

- **Blender not turning on:** Ensure the unit is properly plugged into a working outlet and that the blending vessel is correctly assembled and locked onto the motor base.
- **Inconsistent blending:** Check that ingredients are not overfilling the vessel. For thicker mixtures, use the tamper (with the pitcher) or add more liquid.
- **Motor overheating:** If the motor stops unexpectedly, it may be due to overheating. Unplug the unit and let it cool down for at least 15 minutes before attempting to use it again.

For more detailed troubleshooting or persistent issues, please contact NutriBullet customer support.

SPECIFICATIONS

Feature	Specification
Brand	NutriBullet
Model	NBF50700AK
Power	1400 Watts
Capacity (Pitcher)	64 Fluid Ounces
Number of Speeds	5
Special Feature	Dishwasher Safe (select parts)
Product Dimensions	16.08"D x 8.88"W x 11.36"H
Item Weight	7.28 Pounds
Blade Material	Stainless Steel
Controls Type	Push Button

WARRANTY & SUPPORT

Your NutriBullet SmartSense Blender Combo comes with a 1-Year Limited Warranty. For warranty claims, product support, or any questions not covered in this manual, please contact NutriBullet customer service. Refer to the official NutriBullet website or your purchase documentation for contact details.