

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [uscce](#) /

> [uscce M01-1 Wooden Digital Alarm Clock Instruction Manual](#)

uscce M01-1

uscce M01-1 Wooden Digital Alarm Clock Instruction Manual

Model: M01-1 | Brand: uscce

[Instructions](#) [Maintenance](#) [Introduction](#) [What's in the Box](#) [Features](#) [Setup](#) [Operating](#)
[Troubleshooting](#) [Specifications](#) [Warranty & Support](#) [Product Videos](#)

1. INTRODUCTION

Thank you for choosing the uscce M01-1 Wooden Digital Alarm Clock. This manual provides essential information for setting up and operating your new alarm clock. Please read it thoroughly to ensure proper use and to enjoy all its features.

2. WHAT'S IN THE BOX

- uscce M01-1 Wooden Digital Alarm Clock
- Power Adapter
- User Manual

Note: 3 AAA batteries are required for battery backup (not included).

3. KEY FEATURES

- **Large, Dimmable Display:** 1.8-inch bold numbers with 0-100% customizable brightness.
- **Dual Alarms:** Set two independent alarms for different schedules.
- **Adjustable Alarm Volume:** 5 levels, ranging from 45dB to 105dB.
- **Easy Snooze:** Touch-activated snooze for an extra 9 minutes of rest.
- **USB Charging Port:** Conveniently charge devices (5V/1A output).
- **Battery Backup:** Maintains time settings and alarm function during power outages (requires 3

AAA batteries, not included).

- **12/24-Hour Format:** Easily switch between time display modes.
- **Manual DST Function:** Simple adjustment for Daylight Saving Time.
- **Stylish Wooden Design:** Natural and minimalist aesthetic.

4. SETUP GUIDE

4.1 Powering the Clock

1. **Connect Power:** Plug the included power adapter into the DC 5V port on the back of the clock and then into a wall outlet. The display will light up.
2. **Install Battery Backup (Optional):** Open the battery compartment on the back. Insert 3 AAA batteries (not included), ensuring correct polarity. This will maintain time settings and alarm function during power interruptions, but the display will not stay on when powered only by batteries.

4.2 Setting the Time

1. Press and hold the **TIME SET** button on the back of the clock. The hour digits will flash.
2. Use the **HOUR** and **MIN** buttons to adjust the hour and minute respectively.
3. Press **TIME SET** again to confirm and exit time setting mode.
4. To switch between 12-hour and 24-hour formats, briefly press the **12H/24H** button.



Image: Rear view of the clock with clearly labeled buttons for Time Set, Alarm Set, Min, Hour, DST, and Volume. A dimmer slider, DC 5V input, and USB output are also visible.

5. OPERATING INSTRUCTIONS

5.1 Setting Alarms

1. Press and hold **AL.1 SET** (for Alarm 1) or **AL.2 SET** (for Alarm 2). The hour digits will flash.
2. Use the **HOUR** and **MIN** buttons to set the desired alarm time.
3. Press **AL.1 SET** or **AL.2 SET** again to confirm.
4. To activate/deactivate an alarm, briefly press **AL.1 ON/OFF** or **AL.2 ON/OFF**. An alarm icon will appear/disappear on the display.

Works When Plugged in for Normal Time Display

Features a USB port
for charging your electronic device



Image: The uscce M01-1 clock displaying two different alarm times, 7:30 AM and 10:30 AM, indicating its dual alarm capability.

5.2 Adjusting Alarm Volume


1. While the alarm is sounding, press the **VOL** button repeatedly to cycle through 5 volume levels (L01 to L05).
2. The selected volume level will be saved for future alarms.

0-100% Dimmer Dial


Ours

Dimmer Dial

Fine-tune brightness for any environment
—never too bright or too dim



VS



0% 100%

- ✓ Full Range
- ✓ Smooth Slide
- ✓ Noiseless

Others

Dimmer Button

Fixed brightness levels
—no perfect light for your unique needs

Fixed Level
Repeated Press
Noise

Image: The uscce M01-1 clock illustrating five adjustable volume levels (L01 to L05) for the alarm, ranging from 45dB for light sleepers to 105dB for heavy sleepers.

5.3 Snooze Function

When the alarm sounds, gently touch the **SNOOZE** area on the top of the clock to activate snooze. The alarm will pause for 9 minutes and then sound again.

5 Adjustable Volume Levels



Image: A hand gently touching the "SNOOZE" area on top of the uscce M01-1 clock, demonstrating the easy touch-activated snooze function.

5.4 Dimmable Display

Use the **DIMMER** slider on the back of the clock to adjust the display brightness from 0% (off) to 100% (brightest). This allows for personalized comfort, especially in dark environments.

Wooden Design with Large Bold Number

Easy to read time from your bed, couch,
or across the room with 1.8-inch bold digits



Image: The uscce M01-1 clock displaying large, bold amber digits, highlighting its easy-to-read design and wooden aesthetic.

5.5 USB Charging Port

A built-in USB port (5V/1A output) on the back of the clock allows you to conveniently charge your smartphone or other small electronic devices while the clock is plugged into power.

Battery Backup During Power Outages

Save all settings and the alarm still works



Requires 3 AAA Batteries
(Not Included)

Touching top will light up
clock display for 10s



Image: The uscce M01-1 clock on a nightstand, with a smartphone connected to its integrated USB port for charging, demonstrating its convenience.

5.6 Daylight Saving Time (DST)

To manually adjust for Daylight Saving Time, briefly press the **DST ON/OFF** button on the back of the clock. The time will adjust by one hour forward or backward.

6. MAINTENANCE

- Clean the clock with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- Keep the clock away from direct sunlight, extreme temperatures, and moisture.
- If using battery backup, replace batteries annually or when they are depleted to ensure continuous functionality during power outages.

7. TROUBLESHOOTING

Problem	Solution
Display does not light up.	Ensure the power adapter is securely plugged into both the clock and a working wall outlet. The display only stays lit when plugged in.
Alarm does not sound during power outage.	Check if 3 AAA batteries are installed correctly in the battery compartment. The alarm function relies on battery backup during power outages.
Cannot set time/alarm.	Ensure you are pressing and holding the correct SET button (TIME SET, AL.1 SET, AL.2 SET) until the digits flash. Settings must be confirmed within 15 seconds.
Alarm is too loud/quiet.	Adjust the volume using the VOL button while the alarm is sounding. There are 5 adjustable levels.

8. PRODUCT SPECIFICATIONS

Specification	Detail
Model Number	M01-1
Dimensions	5.9"W x 2.8"H
Item Weight	8 ounces
Display Type	Digital
Power Source	Corded Electric (Adapter included)
Battery Backup	3 AAA batteries (not included)
USB Output	5V/1A
Material	Wood
Color	Brown - Amber Digits

9. WARRANTY & SUPPORT

For any questions or issues with your uscce M01-1 Wooden Digital Alarm Clock, please contact our customer support team:

Email: support@uscce.com

We are committed to providing excellent service and ensuring your satisfaction.

10. PRODUCT VIDEOS

uscce Wooden Digital Alarm Clock for Bedroom

Your browser does not support the video tag.

Video: An official product video from USCCE showcasing the wooden digital alarm clock in various settings, highlighting its design and features.

Don't buy until you see this Digital Alarm Clocks !

Your browser does not support the video tag.

Video: A detailed review of the uscce digital alarm clock, demonstrating its features, ease of use, and dimmable display. The reviewer highlights the clear buttons and adjustable brightness for nighttime use.