

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GRIFEMA](#) /

› [GRIFEMA GA1003-2 Key Lock Box Instruction Manual](#)

### GRIFEMA GA1003-2

# GRIFEMA GA1003-2 Key Lock Box Instruction Manual

Model: GA1003-2

## 1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your GRIFEMA GA1003-2 Key Lock Box. This key lock box is designed to securely store keys and small valuables, featuring a durable construction and a customizable 4-digit combination lock.

## 2. SAFETY INFORMATION

**Please read all safety information before assembly and use.**

- Use caution when assembling and using the key lock box.
- Do not exceed the allowed weight capacity of 558 grams.
- Be careful to avoid pinching fingers when closing or opening the lock box.
- Only use tools and mounting methods that comply with safety requirements.

## 3. PRODUCT OVERVIEW

The GRIFEMA GA1003-2 Key Lock Box is constructed primarily from a durable zinc alloy and steel, ensuring maximum durability and security. It features a 4-digit combination padlock, offering 9999 possible combinations for enhanced security. The design includes a dust cover to protect the combination dials from rain, dust, and snow, making it weather-resistant and robust for outdoor use.

# HOW TO SET NEW PASSWORD

High security, offers you 9999 possible combinations



1. Initial password 0-0-0-0  
to open the box.



2. Push the RESET BUTTON  
from A to B.



3. Set your own password.



4. Push the RESET BUTTON  
back to A.

Image: Key Lock Box features including durable construction and weather protection.

# GREATER STORAGE SPACE

External: 120x100x40mm / Internal: 90x80x30mm



Access Card



About 8-12 Keys



2-3 Car Key

Image: Detailed dimensions of the key lock box, external and internal.

## 4. SETUP AND INSTALLATION

The GRIFEMA GA1003-2 Key Lock Box offers two primary installation methods: Hook Installation and Wall-mounted Installation.

### 4.1. Hook Installation

This method allows for portable and flexible placement, ideal for hanging on doorknobs or other suitable fixtures. It helps prevent rain from entering the lock box when hung correctly.

# KEY SAFE BOX

Premium Outdoor Wall Mounted Combination Key Lock



Image: Visual guide for hook installation.

- Push the button up:** Locate the release button on the side of the lock box and push it upwards.
- Pull the lock shackle upward:** While holding the button, pull the shackle (the U-shaped hook) upwards to open it.
- Hang the lock box:** Place the open shackle over a doorknob, gate handle, or other secure fixture. Close the shackle by pushing it down until it locks into place.

## 4.2. Wall-mounted Installation

This method provides a permanent and secure attachment to a wall, preventing the lock box from scratching doors and offering a fixed storage solution.

# HOOK INSTALLATION

 **Fashionable**

 **Portable**

 **Safe**



**1** Push the button up.



**2** Pull the lock shackle upward.



**3** Hang it on doorknobs or anywhere you need.

Image: Visual guide for wall-mounted installation.

- 1. Open the lock box:** Open the lock box and remove the shackle if it's in place. The back of the box has pre-drilled holes.
- 2. Mark drilling points:** Hold the lock box against the desired wall surface and mark the positions for the drilling holes using a pencil.
- 3. Drill holes:** Use an appropriate drill bit to drill holes at the marked positions.
- 4. Insert wall anchors:** Insert the provided wall anchors into the drilled holes.
- 5. Secure the lock box:** Align the lock box with the anchors and secure it to the wall using the provided screws. Ensure it is firmly attached.

## TWO INSTALLATION METHODS



### Hook Installation

Prevents rain from entering the lock box



### Wall-mounted installation

Prevents the lock box from scratching the door



Image: Overview of the two installation methods.

## 5. OPERATING INSTRUCTIONS: SETTING YOUR COMBINATION

The GRIFEMA GA1003-2 Key Lock Box comes with an initial password of **0-0-0-0**. You can easily set your own personalized 4-digit combination.



Image: Steps for setting a new combination password.

1. **Open the box:** Rotate the dials to the initial password **0-0-0-0** and pull the latch to open the lock box.
2. **Locate the reset button:** Inside the lock box, find the reset button (usually a small lever or pin).
3. **Push the reset button:** Push the reset button from position 'A' to position 'B'.
4. **Set your new password:** While the reset button is in position 'B', rotate the combination dials to your desired 4-digit code. Make sure to remember this code.
5. **Return the reset button:** Push the reset button back from position 'B' to position 'A'. Your new combination is now set.
6. **Test the new combination:** Close the lock box, scramble the dials, and then try opening it with your new combination to ensure it works correctly.

**Important: Do not forget your new combination. There is no master key or override to reset the**

code if it is forgotten.

## 6. MAINTENANCE

---

To ensure the longevity and proper functioning of your GRIFEMA GA1003-2 Key Lock Box, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Lubrication:** Periodically apply a small amount of silicone-based lubricant to the moving parts of the shackle and the combination dials to ensure smooth operation.
- **Inspection:** Regularly check for any signs of wear, damage, or corrosion. Ensure the dust cover is intact and properly sealing the combination dials.
- **Environmental Protection:** While the lock box is weather-resistant, prolonged exposure to extreme conditions may affect its lifespan. Consider placing it in a sheltered location if possible.

## 7. TROUBLESHOOTING

---

If you encounter issues with your key lock box, refer to the following common troubleshooting tips:

- **Lock box won't open:**
  - Ensure the correct 4-digit combination is entered.
  - Check that each dial is precisely aligned with the indicator marks.
  - Apply slight pressure to the latch while entering the code, then release.
- **Dials are stiff:**
  - Apply a small amount of silicone lubricant to the dials and rotate them several times.
  - Clean any dirt or debris from around the dials.
- **Shackle is difficult to open/close:**
  - Ensure the combination is correctly set and the latch is fully disengaged.
  - Lubricate the shackle mechanism.
- **Reset button stuck:**
  - Ensure the dials are set to the current correct combination before attempting to move the reset button.
  - Gently try to move the button with a small, non-sharp object.

## 8. SPECIFICATIONS

---

Feature	Specification
Model Number	GA1003-2
Manufacturer	Ibergrif Griferias, S.L
Product Dimensions	11.5 x 9.5 x 9.5 cm

Feature	Specification
Product Weight	380 g
Material	Zinc Alloy, Steel
Color	Grey
Maximum Supported Weight	558 Grams
Installation Method	Freestanding (Hook) / Surface Mount (Wall)
Special Features	Weather-resistant, Frost-resistant, Robust
Number of Pieces	1

## 9. WARRANTY AND SUPPORT

For warranty information or if you require further assistance with your GRIFEMA GA1003-2 Key Lock Box, please contact GRIFEMA customer support through their official channels. Keep your purchase receipt as proof of purchase.