Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

pitaka SP10US-ABIHABAA

Pitaka Adjustable Lanyard Instruction Manual

Model: SP10US-ABIHABAA

Introduction

The Pitaka Adjustable Lanyard is a versatile accessory designed to securely carry your phone with convenience and style. This multifunctional strap offers three distinct wearing styles: crossbody, wrist strap, and neck lanyard, adapting to various situations and personal preferences. Crafted from high-quality materials, it ensures durability and comfort for extended use.



Image: The Pitaka Adjustable Lanyard in Ocean Blue, shown with a compatible phone case and the included attachment patch.

Product Features

- **1 to 3 Phone Strap:** Easily adjust the lanyard length to switch between crossbody, wrist, or neck wearing styles, offering flexibility for any occasion.
- **Sturdy & Durable:** Constructed from high-quality nylon material, ensuring the lanyard is robust and resistant to wear and tear, keeping your phone secure.
- **Stress-Free, Worry-Free:** The 6.5mm thick braided rope is made from premium, hypoallergenic material, providing comfort even during prolonged wear.
- **Keep Your Essentials Handy:** Features a convenient PU leather loop, allowing you to attach small items like AirPods, keys, or sunglasses, keeping them within easy reach.
- **Wide Compatibility:** Designed to work seamlessly with PITAKA's ultra-slim, tactile woven, and military-grade protective cases, as well as most full-coverage phone cases from other brands.

Setup Instructions

1. **Prepare Your Phone Case:** Ensure your phone case has a charging port opening that is not obstructed and is a full-coverage type. Refer to the compatibility section for suitable case types.
2. **Insert the Attachment Patch:** Take the small attachment patch with the metal loop. Insert the flat part of the patch into the charging port opening of your phone case, ensuring the metal loop protrudes slightly from the opening.
3. **Secure the Patch:** Place your phone inside the case, ensuring the patch is securely held between the phone and the case. The metal loop should remain accessible at the bottom of the case.
4. **Attach the Lanyard:** Clip the carabiner of the Pitaka Adjustable Lanyard onto the metal loop of the attachment patch. Ensure the connection is secure.
5. **Adjust Length:** To adjust the lanyard's length, slide the adjustable buckle along the rope until you reach your desired length for comfortable wear.



Image: Step-by-step visual guide demonstrating the process of inserting the attachment patch into a phone case and connecting the lanyard.




Image: Detailed view of the adjustable buckle and how to slide it to modify the lanyard's length.

Operating Instructions (Wearing Styles)

The Pitaka Adjustable Lanyard offers three primary ways to carry your phone:

Crossbody Style:

Adjust the lanyard to a longer length, allowing it to comfortably drape across your body, from one shoulder to the opposite hip. This style keeps your phone secure and easily accessible while leaving your hands free.

Neck Lanyard Style:

Shorten the lanyard to a suitable length to wear it around your neck. This is ideal for quick access to your phone, especially when you need to keep it visible and within immediate reach.

Wrist Strap Style:

Adjust the lanyard to a very short length, forming a loop that can be worn around your wrist. This provides a secure grip and prevents accidental drops while keeping your phone close at hand.




Image: Visual examples of the three versatile wearing styles: crossbody, neck, and wrist, demonstrating how the lanyard adapts to different needs.

Maintenance

To ensure the longevity and appearance of your Pitaka Adjustable Lanyard, follow these simple maintenance guidelines:

- **Cleaning:** For light dirt, gently wipe the nylon rope and PU leather loop with a damp cloth. For more stubborn stains, use a mild soap solution and a soft brush, then rinse thoroughly with clean water. Allow to air dry completely before re-using.
- **Avoid Harsh Chemicals:** Do not use strong detergents, bleach, or abrasive cleaners, as these can damage the material and color of the lanyard.
- **Storage:** Store the lanyard in a clean, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspect Regularly:** Periodically check the lanyard, attachment patch, and carabiner for any signs of wear, fraying, or damage. Discontinue use if significant wear is observed to prevent accidental drops.

Troubleshooting

Problem	Possible Cause	Solution
Lanyard does not attach securely to phone case.	Phone case is not compatible or attachment patch is not inserted correctly.	Ensure your phone case is a full-coverage type with an open charging port. Re-insert the attachment patch, making sure the metal loop is fully accessible and the patch is flat against the inside of the case. Refer to the "Compatibility" image.  Image: Visual guide illustrating suitable phone case designs for lanyard attachment versus unsuitable ones.
Lanyard feels uncomfortable or too tight/loose.	Lanyard length is not adjusted correctly for the chosen wearing style.	Use the adjustable buckle to lengthen or shorten the lanyard until it feels comfortable and secure for your desired wearing style (crossbody, neck, or wrist).
Lanyard shows signs of wear or fraying.	Normal wear and tear, or exposure to abrasive surfaces.	Regularly inspect the lanyard. If significant wear or damage is observed, it is recommended to replace the lanyard to ensure the safety of your device.

Specifications

Brand	Pitaka
Model Number	SP10US-ABIHABAA
Color	Ocean Blue
Material	High-quality Nylon, PU Leather (loop)
Rope Thickness	6.5mm
Item Weight	4.8 ounces
Package Dimensions	8.6 x 4 x 1 inches

Warranty and Support

For detailed warranty information regarding your Pitaka Adjustable Lanyard, please refer to the product packaging or visit the official Pitaka website. Pitaka stands behind the quality of its products and offers customer support for any

inquiries or issues you may encounter.
If you require assistance, please contact Pitaka customer service through their official channels. Keep your purchase receipt or order number handy for faster service.
Official Pitaka Website: Visit the Pitaka Store on Amazon

© 2024 Pitaka. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHK7LNDZ

More documents and user manuals: **https://manuals.plus/**