

[manuals.plus](#) /› [FOHERE](#) /› [FOHERE Food Processors HB-JR07 Instruction Manual](#)

FOHERE HB-JR07

FOHERE Food Processors HB-JR07 Instruction Manual

INTRODUCTION

Thank you for choosing the FOHERE Food Processors HB-JR07. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read all instructions carefully before first use and retain this manual for future reference.

Safety Precautions

- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Keep hands and utensils out of the bowl while processing food to prevent injury.
- Do not operate the appliance with a damaged cord or plug.
- Avoid contact with moving parts. Blades are sharp; handle with extreme care.
- Do not immerse the motor unit in water or other liquids.
- This appliance is not intended for use by children. Close supervision is necessary when any appliance is used near children.
- Ensure the lid is securely locked in place before operating the food processor.

PRODUCT COMPONENTS

The FOHERE Food Processors HB-JR07 includes the following parts:

- **Motor Unit:** The main power component.
- **Bowl's Lid:** Secures the contents during operation.
- **Stainless Steel Blades (2 sets):** Bi-level S-blades for efficient chopping.
- **Glass Bowl (1.8L capacity):** Suitable for various food types.
- **Stainless Steel Bowl (2L capacity):** Ideal for meat and other specific uses.

- **Non-slip Rubber Mat:** Provides stability during operation.

What's in the box?

Get everything you need inside the package.



Figure 1: All components of the FOHERE Food Processor HB-JR07. This image displays the motor unit, bowl's lid, two sets of stainless steel blades, the glass bowl, the stainless steel bowl, and the non-slip rubber mat, clearly labeled for identification.

SETUP AND ASSEMBLY

Follow these steps to assemble your FOHERE Food Processor:

1. **Place Non-slip Mat:** Position the non-slip rubber mat on a clean, dry, and stable surface.
2. **Select Bowl:** Choose either the glass bowl or the stainless steel bowl based on your food preparation needs and place it on the non-slip mat.
3. **Install Blades:** Carefully insert the blade assembly into the spindle pin located at the bottom of the chosen bowl. Ensure the blades are securely seated. (*Refer to Figure 2 for blade assembly details. Wear gloves when handling blades to avoid injury.*)
4. **Add Ingredients:** Place your pre-cut ingredients into the bowl. Do not exceed the 'MAX' fill line.
5. **Attach Lid:** Place the bowl's lid onto the bowl, ensuring it is properly aligned and securely closed.
6. **Position Motor Unit:** Match the pure copper motor unit with the knife pin on the cover. The separated design ensures food hygiene. Clockwise rotation locks the motor unit, while anticlockwise rotation separates it.
7. **Connect Power:** Plug the power cord into a suitable electrical outlet.

User-friendly Details, Please Protect Yourself




Figure 2: Detailed steps for blade assembly. This image illustrates how to correctly assemble the bi-level blades, twist them tight, confirm they are secure, and remove any protective plastic parts, with a safety reminder to wear gloves.



Figure 3: Four easy steps for initial setup and operation. This visual guide covers placing the non-slip ring, inserting the blade assembly, adding ingredients, and plugging in the unit to begin processing.

OPERATING INSTRUCTIONS

The FOHERE Food Processors HB-JR07 is designed for efficient chopping, mincing, and pureeing of various ingredients. It features a simple push-to-start operation.

General Operation

1. After assembly and adding ingredients, press and hold the button on top of the motor unit to start processing.
2. Release the button to stop the motor. Continuously check the consistency of your food and continue processing if a finer texture is desired.
3. The appliance features a hidden safety switch that prevents operation if the motor unit is not correctly matched with the lid and bowl.

Processing Different Food Types

- **Meat:** Cut meat into small, even pieces before placing it in the bowl. The stainless steel bowl is recommended for meat to prevent cross-contamination with other foods.
- **Vegetables & Fruits:** For best results, cut larger vegetables and fruits into smaller chunks.
- **Nuts:** Process nuts in short pulses to achieve desired consistency, from coarsely chopped to finely ground.
- **Baby Food:** The powerful motor and sharp blades can quickly puree cooked fruits and vegetables for baby food.

Faster and Smoother

For soft food



Garlic



Chili



Vegetables Fruits

For hard food



Beef



Pumpkin



Nut

Figure 4: Examples of food processing capabilities. This image demonstrates the processor's effectiveness with both soft ingredients such as garlic, chili, vegetables, and fruits, and hard ingredients like beef, pumpkin, and nuts.

Stainless steel bowl(Capacity 2L)

Glass bowl(Capacity 1.8L)



Figure 5: The two included bowls. This image displays the 1.8L glass bowl and the 2L stainless steel bowl, highlighting their different capacities and materials for varied food preparation tasks.

Efficient & Powerful Full-Copper Motor

Faster and Smoother



Figure 6: Efficient motor and safety features. This diagram illustrates the powerful full-copper motor and the integrated safety switch, demonstrating the processor's ability to chop, mince, and puree effectively.

Demonstration Videos

Your browser does not support the video tag.

Video 1: This video demonstrates the FOHERE Food Chopper's ability to process meat and onions, showcasing its efficiency and ease of use for various ingredients.

CARE AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your food processor.

Cleaning

- **Unplug:** Always unplug the appliance before cleaning.
- **Disassemble:** Carefully remove the motor unit, lid, and blade assembly from the bowl.
- **Wash Components:** The bowls, lid, and blade assemblies are dishwasher safe or can be washed by hand with warm, soapy water. Rinse thoroughly.
- **Clean Motor Unit:** Wipe the motor unit with a damp cloth. **Do not immerse the motor unit in water.**
- **Dry:** Ensure all parts are completely dry before reassembling or storing.

Your Food Hygiene, We Care

Two 2L Bowls made from different materials avoid confusion between bowls for different uses



Figure 7: Hassle-free cleaning. This image demonstrates the ease of cleaning the FOHERE Food Processor, showing a bowl being rinsed under a faucet and the motor unit being wiped with a cloth.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not start.	Not plugged in; motor unit not correctly assembled; safety switch not engaged.	Ensure power cord is securely plugged in. Reassemble the motor unit, lid, and bowl, ensuring they are properly aligned and locked.
Food is not chopped evenly.	Too much food in the bowl; ingredients are too large; insufficient processing time.	Reduce the amount of food. Cut ingredients into smaller, more uniform pieces. Process for longer or use pulse function.
Motor stops during operation.	Overheating protection activated; motor unit lifted from lid.	Unplug and let the motor cool down for 15-20 minutes. Ensure the motor unit remains pressed down firmly during operation.
Loud noise or vibration.	Blades not properly installed; uneven load in the bowl.	Check that the blade assembly is securely seated. Distribute ingredients evenly in the bowl.

SPECIFICATIONS

Feature	Detail
Brand	FOHERE
Model Number	HB-JR07
Product Dimensions	17.7" L x 17.7" W x 24" H
Item Weight	3.2 pounds
Voltage	120 Volts
Material	Glass, Stainless Steel
Glass Bowl Capacity	Approximately 7 cups (1.8L)
Stainless Steel Bowl Capacity	Approximately 8 cups (2L)
Blades	2 Sets of Bi-Level Stainless Steel Blades



WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact FOHERE customer service directly. Keep your purchase receipt as proof of

purchase for any warranty claims.

© 2024 FOHERE. All rights reserved.

Related Documents - HB-JR07

	<p>FOHERE Meat Grinder MG-2950R User Manual</p> <p>User manual for the FOHERE Meat Grinder MG-2950R, providing essential safety instructions, operation guides, cleaning procedures, and troubleshooting tips for household use.</p>
	<p>FOHERE HY-1428S Coffee Grinder Instruction Manual</p> <p>Comprehensive instruction manual for the FOHERE HY-1428S Coffee Grinder, covering safety precautions, operating instructions, care and maintenance, parts identification, and troubleshooting. Learn how to use and maintain your coffee grinder for optimal performance.</p>
	<p>FOHERE SL-519N Electric Slicer Machine: Instruction Manual & Safety Guide</p> <p>Comprehensive instruction manual for the FOHERE SL-519N Electric Slicer Machine. Learn about safe operation, maintenance, troubleshooting, and usage suggestions for home use.</p>
	<p>FOHERE SNJ-159B Yogurt Maker User Manual and Guide</p> <p>Comprehensive user manual for the FOHERE SNJ-159B Yogurt Maker. Includes setup instructions, operation guide, basic yogurt recipes, advanced uses for cheese, fermented rice, and natto, troubleshooting tips, maintenance advice, and product specifications.</p>
	<p>Foheré Electric Kettle Instruction Manual - Safety, Usage, and Maintenance Guide</p> <p>This comprehensive instruction manual for the Foheré electric kettle provides essential safety guidelines, operating instructions, temperature settings, and cleaning and maintenance procedures. Learn how to safely use and care for your appliance.</p>
	<p>FOHERE HK-C016 Cookware: Use, Care, and Safety Instructions</p> <p>Detailed guide for FOHERE HK-C016 cookware, covering usage, maintenance, cleaning (hand wash & dishwasher), energy saving, and safety precautions. Includes product contents and manufacturer information.</p>