

## Bear QSJ-H02H6

# Bear Baby Food Maker QSJ-H02H6 Instruction Manual

Model: QSJ-H02H6 | Brand: Bear

## 1. INTRODUCTION

Thank you for choosing the Bear Baby Food Maker. This comprehensive set is designed to simplify the preparation of fresh and nutritious meals for your baby. It includes a powerful food maker, four baby food storage containers with a tray, and two soft silicone spoons, providing everything you need for a convenient and healthy feeding routine.

This manual provides essential information on the safe operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

## 2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Keep the appliance out of reach of children.
- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Do not immerse the motor unit in water or any other liquid. Wipe with a damp cloth only.
- Handle blades with extreme care as they are very sharp. Always use the blade guards when storing or handling.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use the appliance outdoors.
- Ensure the lid is securely locked in place before operating.
- Never leave the appliance unattended while in use.

### 3. PRODUCT COMPONENTS

The Bear Baby Food Maker set includes the following parts:

- **Motor Unit:** The main power unit with a 200W motor.
- **Glass Bowl (0.6L):** Food-grade glass container for blending.
- **Blades Set:** Three-leaf stainless steel blades for efficient pureeing.
- **Lid:** Secure lid for the glass bowl.
- **Baby Food Storage Cups (4x):** Glass containers with silicone lids for storing prepared food.
- **Storage Cup Plate:** Tray to hold the storage cups.
- **Silicone Spoons (2x):** Soft spoons for feeding.



Figure 1: Exploded view of the Bear Baby Food Maker and its accessories. This image shows the motor unit, lid, blades set, 0.6L glass bowl, four storage cups with lids, a storage cup plate, and two silicone spoons.

### 4. SETUP AND ASSEMBLY

- Unpack:** Carefully remove all components from the packaging.
- Clean:** Wash the glass bowl, blades set, lid, storage cups, and silicone spoons with warm, soapy water before first use. Rinse thoroughly and dry.
- Assemble Blades:** Place the blades set onto the central shaft inside the glass bowl. Ensure it is seated correctly.
- Add Food:** Place your prepared ingredients into the glass bowl. Do not fill more than 2/3 full to allow for proper blending.
- Secure Lid:** Place the lid onto the glass bowl and ensure it is properly aligned and sealed.
- Attach Motor Unit:** Position the motor unit on top of the lid, aligning the drive shaft with the blade assembly.

## EASY TO USE (PRESS DOWN) & SMOOTHER PURÉE



Figure 2: Demonstrates the easy 'press down' operation of the food maker for smoother purees. Various food types like bananas, avocado, carrots, sweet potato, pears, and garlic paste are shown as examples of what can be processed.

## 5. OPERATING INSTRUCTIONS

- Prepare Ingredients:** Cut fruits, vegetables, or cooked meats into small pieces (less than 2cm

recommended).

2. **Load Bowl:** Place the cut ingredients into the glass bowl, ensuring it is not overfilled (max 2/3 capacity).
3. **Assemble:** Follow the setup steps to securely place the blades, lid, and motor unit.
4. **Power On:** Plug the appliance into a suitable power outlet.
5. **Blend:** Press down on the top of the motor unit to start blending. Release to stop. Use short pulses for coarse chopping or hold down for a smoother puree.
6. **Check Consistency:** Lift the motor unit and lid to check the food consistency. If needed, stir the contents with a spatula and re-blend.
7. **Serve or Store:** Once the desired consistency is achieved, carefully remove the motor unit, lid, and blades. Transfer the baby food to the provided storage containers or serve immediately.



Figure 3: Illustrates the smooth puree consistency achievable with the food maker, suitable for various ingredients including fruits, vegetables, meat, and sauces.

### Video Demonstration: Bear Baby Food Maker in Action

Your browser does not support the video tag.

Video 1: A demonstration of the Bear Baby Food Maker, showcasing its ease of use and ability to quickly process ingredients into smooth purees.

### Video Demonstration: Baby Food Processing for Fruits

Your browser does not support the video tag.

Video 2: This video illustrates the process of using the baby food maker to prepare fruit purees, highlighting its efficiency and the smooth texture achieved.

## Video Demonstration: Quick Baby Food Preparation

Your browser does not support the video tag.

Video 3: A short preview video demonstrating the quick and easy preparation of baby food using the Bear Baby Food Maker.

## 6. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and hygienic operation of your Bear Baby Food Maker.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Disassemble:** Carefully remove the motor unit, lid, and blades from the glass bowl.
3. **Clean Blades:** The stainless steel blades are sharp. Use caution when cleaning. Rinse under running water and use a brush if necessary to remove food residue.
4. **Clean Bowl and Lid:** Wash the glass bowl, lid, storage cups, and silicone spoons with warm, soapy water. These parts are detachable for easy cleaning.
5. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water.
6. **Dry:** Ensure all parts are completely dry before reassembling or storing.
7. **Storage:** Store the appliance in a clean, dry place.

## EASY TO CLEAN



Figure 4: Shows the easy-to-clean design with detachable parts, making maintenance simple and hygienic.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not properly plugged in or assembled.	Ensure the power cord is securely plugged in and the motor unit is correctly aligned and pressed down on the lid.
Food is not blending smoothly.	Bowl is overfilled or ingredients are too large.	Reduce the amount of food in the bowl. Cut ingredients into smaller pieces. Add a small amount of liquid if necessary.
Motor sounds strained.	Too much food or hard ingredients.	Reduce the load. Ensure ingredients are soft enough for blending (e.g., steamed vegetables).

## 8. SPECIFICATIONS

- **Brand:** Bear
- **Model Name:** QSJ-H02H6
- **Product Dimensions:** 8.82"D x 13.9"W x 6.78"H
- **Color:** Green
- **Wattage:** 200 watts
- **Special Feature:** Removable Parts, Shock Resistant
- **Product Care Instructions:** Hand Wash (Not Dishwasher Safe)
- **Blade Material:** Stainless Steel
- **Item Weight:** 4.62 pounds
- **UPC:** 198715166774
- **Manufacture Year:** 2024

## 9. WARRANTY AND SUPPORT

The Bear Baby Food Maker comes with a **1-year warranty**. For any questions, concerns, or technical support, please contact our customer service team. We are available **24/7** to assist you and provide lifetime technical support.

For assistance, please refer to the contact information provided in your product packaging or visit the official Bear website.