

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [KZF](#) /
- › [KZF 15L Large Room Humidifier \(Model KZF-563\) - User Manual](#)

**KZF KZF-563**

# KZF 15L Large Room Humidifier (Model KZF-563) - User Manual

Brand: KZF | Model: KZF-563

## INTRODUCTION

Thank you for choosing the KZF 15L Large Room Humidifier. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your humidifier. Please read it thoroughly before use and retain it for future reference.





*Image: The KZF 15L Large Room Humidifier, a tall white unit with a digital display and a remote control shown beside it.*

## **IMPORTANT SAFETY INSTRUCTIONS**

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions:

- Read all instructions before using the appliance.
- Always place the humidifier on a firm, flat, water-resistant surface.
- Do not operate the humidifier if the cord or plug is damaged.
- Keep the power cord away from heated surfaces.
- Do not immerse the humidifier in water or other liquids.
- Unplug the humidifier before filling, cleaning, or moving it.
- Do not block air vents or mist outlets.
- Use only clean, cool tap water or distilled water. Avoid hot water.
- Keep out of reach of children and pets.

# 15L Humidifiers for Bedroom



Image: An illustration highlighting key features of the KZF 15L Humidifier: 1-8H Timer, Touch/Remote Control, Top-fill Design, Auto Shut-off Protection, Humidity Setting, and Whisper Quiet operation.

## Package Contents:

- KZF 15L Humidifier Unit
- Remote Control
- User Manual

## SETUP

### 1. Placement

Place the humidifier on a flat, stable surface at least 6 inches (15 cm) away from walls and furniture. Ensure the mist outlet is not directed at walls or electronics.

### 2. Filling the Water Tank

The KZF 15L Humidifier features a convenient top-fill design. You can fill the tank in two ways:

1. **Direct Top Fill:** Remove the top cover and pour water directly into the tank up to the 'MAX' line. Ensure no water enters the mist outlet or control panel.
2. **Removable Tank Fill:** Carefully lift the top section (containing the control panel and pump) off the water tank. Fill the water tank separately up to the 'MAX' line. Ensure the power plug of the pump does not get wet. Reattach the top section, ensuring the pump is properly seated at the bottom of the tank.

# TOP FILL & NO LEAKAGE

Add water from top easily.

3.9GAL =  x30  
500ml

Can be used for 72 hours



*Image: A hand pouring water into the top of the KZF 15L Humidifier, demonstrating the top-fill feature. The water level indicator shows the 'MAX' line.*

**Note:** Use distilled or purified water to minimize mineral buildup and extend the device's lifespan.

## OPERATING INSTRUCTIONS

Your KZF humidifier can be operated via the touch control panel on the unit or the included remote control.

# Remote Control

The remote control function allows you to control the device from a distance, convenient and fast.



Image: A hand holding the remote control, pointing it towards the KZF 15L Humidifier's digital display and control panel.

## 1. Power On/Off

- Press the **Power** button (  ) on the control panel or remote to turn the unit on or off.

## 2. Mist Levels

Adjust the mist output intensity to your preference. There are 3 mist levels available.

- Press the **Mist Level** button (  ) repeatedly to cycle through Low, Medium, and High mist settings.

# Adjustable 3 Spray Levels

Customize your humidity between 40%RH-90%RH



Image: The KZF 15L Humidifier with visual representations of its three adjustable mist levels: Low, Medium, and High, indicating varying mist output.

## 3. Humidity Setting

Set your desired humidity level between 40% and 90% Relative Humidity (RH).

- Press the **Humidity** button (📊) to adjust the target humidity. The unit will automatically maintain this level.

## 4. Timer Function

Set the humidifier to operate for a specific duration (1-8 hours).

- Press the **Timer** button (🕒) to select the desired operating time. The unit will automatically shut off after the set time.

## 5. Aromatherapy Function

Enhance your environment with essential oils.

- Add 3-5 drops of your favorite essential oil directly into the water tank.
- **Caution:** Clean the tank weekly with mild soap after adding oils to prevent residue buildup.

## MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your humidifier.

### 1. Cleaning the Water Tank and Base

- Clean the water tank and base every 2-3 weeks.
- Unplug the unit and remove the top section.
- Empty any remaining water.
- Wipe down the interior of the tank and base with a soft cloth and mild soap. Rinse thoroughly to remove all soap residue.
- For stubborn mineral deposits, use a solution of white vinegar and water. Let it soak for 30 minutes, then scrub and rinse.
- Ensure all parts are completely dry before reassembling.

### 2. Filter Replacement

Replace filters every 2-3 months for optimal performance. Refer to the product packaging or KZF website for compatible replacement filters.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist or low mist output.	Low water level; mineral buildup on transducer; mist outlet blocked.	Refill water tank; clean the transducer with a soft brush; ensure mist outlet is clear.
Water leakage.	Improper assembly; damaged tank/seal.	If leaking occurs during initial use, empty the tank and base, then reassemble carefully. Check for cracks or damage.
Unpleasant odor.	Stagnant water; dirty tank.	Empty and clean the water tank thoroughly. Use fresh water daily.
PM2.5 detector shows high readings.	PM2.5 detectors may misinterpret mist as particles.	This is normal and does not indicate air pollution from the humidifier.
Humidifier is noisy.	Unit not on a flat surface; internal component issue.	Ensure the unit is on a stable, flat surface. If noise persists, contact customer support.

## SPECIFICATIONS

Brand	KZF
Model Name	KZF-563
Capacity	15 Liters (3.9 Gallons)
Coverage Area	Up to 2000 Sq.ft
Runtime	Up to 72 hours (on low mist setting)

<b>Noise Level</b>	26dB (on low mist setting)
<b>Product Dimensions</b>	9.45"D x 9.45"W x 21.2"H
<b>Item Weight</b>	5.7 Pounds
<b>Voltage</b>	120 Volts
<b>Wattage</b>	45 watts
<b>Special Features</b>	Remote Control, Timer, 3 Mist Levels, Aromatherapy Diffuser, Auto Shut-Off, Top Fill Design

## WARRANTY AND SUPPORT

---

KZF offers a **360-day hassle-free product replacement** for any issues you may encounter. Our professional customer service team is available 24 hours a day to assist with product problems or questions.

For support, please refer to the contact information provided with your purchase or visit the official KZF website.