WINNY POOL CLEANER WPC-200

WINNY POOL CLEANER WPC-200 Cordless Robotic Pool Cleaner

Instruction Manual

1. Product Overview

The WINNY POOL CLEANER WPC-200 is a cordless robotic pool cleaner designed for efficient and hassle-free pool maintenance. It features a dual-layer filtration system and intelligent navigation to ensure thorough cleaning of your pool's floor.



Image 1.1: The WINNY POOL CLEANER WPC-200 Cordless Robotic Pool Cleaner.

2. Setup

1. **Unboxing and Initial Inspection:** Carefully remove all components from the packaging. Inspect the cleaner for any visible damage. Ensure all parts, including the retrieval hook, are present. Remove any desiccant packets before use.
2. **Charging the Device:** Connect the charging cable to the cleaner's charging port. The charging port is designed for enhanced waterproof performance without a sealing strip. A full charge takes approximately 4 hours. The device provides up to 75 minutes of runtime on a full charge.

Image 2.1: Detail of the charging port. This component is optimized for waterproofing, so no sealing strip is included.

Image 2.2: The robotic pool cleaner connected to its charger, indicating a full charge in 3-4 hours.

3. **Attaching the Retrieval Hook:** The cleaner comes with a hook for easy retrieval. Attach this hook to a standard pool pole (pole not included).

3. Operating Instructions

1. **Turning On:** Locate the single power button on the underside of the cleaner. Press and hold the button until you hear a beep, indicating the device is ready for operation.
2. **Placing in Pool:** Gently lower the cleaner into the pool. It will gradually fill with water and sink to the bottom. Once submerged, it will perform an auto-calibration sequence before beginning its cleaning cycle.
3. **Cleaning Cycle:** The WPC-200 operates for approximately 75 minutes on a full charge. Its high-speed safety motor and dual scrapers work together to effectively clean the pool floor, capturing dirt and debris.
4. **Auto-Parking:** When the battery is low, the cleaner will automatically move to the edge of the pool for easy retrieval.

Image 3.1: The cordless robotic pool cleaner operating in a pool, highlighting its ease of use.

Image 3.2: The robotic cleaner's auto-parking feature, showing it moving to the pool edge when the battery is low.

4. Maintenance

1. **Retrieving the Cleaner:** Use the provided hook attached to a pool pole to carefully lift the cleaner out of the water.
2. **Cleaning the Filtration System:** The WPC-200 features a dual-layer filtration system, combining a 180µm filter with a textured foam layer. Regularly clean both layers to maintain optimal performance. For heavily soiled pools, clean the filter every 30 minutes to prevent clogging.
3. **Drying:** After cleaning, allow the filter components to dry completely before reassembling the unit.

Image 4.1: Exploded view of the dual-layer filtration system, showing the cotton foam and 180µm filter tray.

Image 4.2: The lightweight design of the cleaner makes it convenient to lift and move for maintenance.

5. Troubleshooting

- **Device Not Moving/Stuck:** If the cleaner stops or appears stuck, it may be low on power or the filter may be clogged. Retrieve the device, clean the filter, and ensure it is fully charged before re-deploying.
- **Ineffective Cleaning:** A reduction in cleaning effectiveness often indicates a clogged filter. Follow the maintenance steps to clean the dual-layer filter.
- **Short Runtime:** Ensure the device is fully charged for 4 hours before each use to achieve the maximum 75-minute runtime. Battery performance can be affected by debris load and pool conditions.

6. Specifications

Feature	Detail
Model Name	WPC-200

Brand	WINNY POOL CLEANER
Power Source	Battery Powered
Item Weight	9.42 pounds (4.28 Kilograms)
Special Features	Cordless, Waterproof
Assembly Required	No
Control Method	Touch
Battery Type	Lithium-Ion (1 included)
Lithium Battery Energy Content	34.56 Watt Hours
Charging Time	4 Hours
Runtime	75 Minutes
Product Dimensions	13 x 12 x 9 inches
Material	Plastic
Color	Light green white

7. Warranty

The WINNY POOL CLEANER WPC-200 comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

8. Support

For further assistance, technical support, or inquiries regarding your WINNY POOL CLEANER WPC-200, please visit the official WINNY POOL CLEANER Store or contact customer service through the details provided in your product documentation.

© 2025 WINNY POOL CLEANER. All rights reserved.