

Diofox M8

Diofox M8 MP3/MP4 Player User Manual

Model: M8

1. INTRODUCTION

Welcome to the user manual for your Diofox M8 MP3/MP4 Player. This device is a versatile portable media player designed for music, video, and app usage. This manual provides essential information on setting up, operating, and maintaining your player to ensure optimal performance and longevity.

2. SAFETY INFORMATION

- Do not expose the device to extreme temperatures (above 45°C or below -5°C).
- Avoid dropping or subjecting the device to strong impacts.
- Keep the device away from water, moisture, and high humidity environments.
- Use only approved chargers and cables to prevent damage and ensure safety.
- Do not attempt to disassemble, repair, or modify the device yourself. Contact customer support for assistance.
- Avoid listening to audio at high volumes for extended periods to prevent hearing damage.

3. PRODUCT OVERVIEW

The Diofox M8 is a portable media player featuring a 5-inch full-touch IPS screen, Wi-Fi, and Bluetooth connectivity. It runs on an Android operating system, allowing access to various applications for entertainment and productivity.

Large Capacity Multi-function Mainstream Media Music Player

Support you listening music&watch video online and offline.



Figure 3.1: Multi-music Player Interface. This image illustrates the main interface of the Diofox M8 player, showcasing its multi-functional capabilities with pre-installed and downloadable applications for music, video, and other media.

4" Full-Touch IPS Screen

Video Format supported

RM, RMVB, FLV, MP4, DAT, MKV, MPG, MOV, TS



Figure 3.2: Full-Touch IPS Screen. The device features a 5-inch full-touch IPS screen, providing a clear and responsive display for video playback and navigation. It supports various video formats including RM, RMVB, FLV, MP4, DAT, MKV, MPG, MOV, and TS.

4. SETUP

4.1 Charging the Device

Before first use, fully charge your Diofox M8 player. Connect the device to a power source using the provided USB cable. The built-in 2500 mAh battery offers extended playback times. Expect up to 19 hours of music playback with wired headphones and approximately 6 hours via Bluetooth. Charging time may vary.

Fast charging & long battery life

Up to 50 hours of playback at medium volume when connected to a computer or adapter charger
(Note: Power consumption increases in Bluetooth mode)



Figure 4.1: Fast Charging & Long Battery Life. This image emphasizes the device's 2500 mAh battery, which supports fast charging and offers long playback times. Note that battery life varies with usage, volume, and Bluetooth activity.

4.2 Powering On/Off

- To turn on: Press and hold the power button located on the side of the device until the screen lights up.
- To turn off: Press and hold the power button, then select 'Power off' from the options that appear on the screen.

4.3 Wi-Fi Connection

To access online content and download applications, connect your device to a Wi-Fi network:

1. Go to **Settings** from the home screen.
2. Tap on **Network & Internet**.
3. Select **Wi-Fi** and toggle it on.
4. Choose your desired Wi-Fi network from the list.
5. Enter the network password if prompted, then tap **Connect**.

4.4 Bluetooth Pairing

Pair your Diofox M8 with Bluetooth headphones, speakers, or car audio systems for wireless audio:

1. Ensure the Bluetooth device you wish to pair is in pairing mode.
2. On your Diofox M8, go to **Settings**.
3. Tap on **Connected devices**, then select **Bluetooth**.
4. Toggle Bluetooth on. The device will automatically scan for nearby Bluetooth devices.
5. Select your device from the list of available devices to initiate pairing.
6. The Diofox M8 supports automatic connection for previously paired accessories, simplifying future connections.



Bluetooth

Wider Bluetooth Compatibility quickly and car stereo Stable and paired with Bluetooth headphonespeaker




Figure 4.2: Wider Bluetooth Compatibility. The Diofox M8 offers broad Bluetooth compatibility, allowing quick and stable connections to different types of Bluetooth headphones, speakers, and car audio systems.

5. OPERATING

5.1 Music Playback

The Diofox M8 supports a wide range of lossless audio formats, including MP3, WMA, OGG, APE, FLAC, WAV, AAC-LC, and ACCEP. You can enjoy music through:

- **Pre-installed Apps:** Use applications like Spotify, Amazon Music, Apple Music, Deezer, or Tidal for streaming and offline playback.
- **Local Files:** Transfer your own music files to the device's internal 80GB storage or an external microSD card (up to 128GB, not included).




Figure 5.1: HiFi Sound Quality. Experience high-fidelity sound quality with the Diofox M8. This image shows the player in music playback mode, emphasizing its support for various audio formats like MP3, OGG, FLAC, AAC, WAV, and APE.

5.2 Video Playback

The 5-inch IPS screen is ideal for video playback. The device supports full-format video playback (720p/1080p) for various formats including RMVB, AVI, MKV, WMV, VOB, MOV, FLV, ASF, DAT, MP4, 3GP, MPG, and MPEG. Videos can be played directly without prior conversion.

5.3 Application Usage

Leverage the Android operating system to download and install additional applications from the Google Play Store. This includes apps for e-books (Kindle), social media (Facebook, Twitter), and other utilities.

5.4 File Transfer

To transfer music, videos, photos, or other files to your Diofox M8, connect the device to your computer using a USB cable. The Android system simplifies file management, allowing you to drag and drop files directly to the device's storage folders.

6. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the device. Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in active use.

7. TROUBLESHOOTING

- **Device not turning on:** Ensure the battery is sufficiently charged. Connect the device to a charger for at least 30 minutes before attempting to power it on again.
- **Cannot connect to Wi-Fi/Bluetooth:** Check that Wi-Fi/Bluetooth is enabled in settings. Ensure the network/device is within range and correctly configured. Try restarting the player and the external device.
- **Applications not downloading or crashing:** Verify your Wi-Fi connection. Check for sufficient internal storage space. Try clearing the cache of the problematic app or the Google Play Store.
- **Poor audio quality:** Ensure headphones are properly connected or Bluetooth devices are correctly paired. Check the audio settings on the player. Try different headphones or speakers to isolate the issue.
- **Device is unresponsive:** If the device becomes unresponsive, press and hold the power button for approximately 10-15 seconds to force a restart.

8. SPECIFICATIONS

Feature	Detail
Model Number	M8
Brand	Diofox
Memory Storage Capacity	80 GB (expandable up to 128GB via microSD)
Screen Size	5 Inches
Special Feature	Touchscreen
Included Components	MP3 Player
Item Weight	80 Grams
Battery	1 Lithium-polymer (included)
Manufacturer	Diofox

9. WARRANTY AND SUPPORT

The Diofox M8 MP3/MP4 Player comes with **atwo-year quality guarantee** from the date of purchase. This warranty covers manufacturing defects under normal use.

For technical assistance, troubleshooting, or any questions regarding your device, please contact our dedicated customer service team. Contact information can typically be found on the product packaging or the official Diofox website.