

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Itel](#) /

› [itel Buds Ace ANC Wireless Earbuds User Manual](#)

Itel Buds Ace ANC

itel Buds Ace ANC Wireless Earbuds User Manual

Model: Buds Ace ANC | Brand: Itel

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your itel Buds Ace ANC Wireless Earbuds. Please read this manual thoroughly before using the product and retain it for future reference.

WHAT'S IN THE Box

- itel Buds Ace ANC Earbuds (Left and Right)
- Charging Case
- C-type Charging Cable
- User Manual (This document)
- Ear Tips (Various sizes, usually pre-installed or in a small bag)

PRODUCT OVERVIEW

The itel Buds Ace ANC are true wireless stereo (TWS) earbuds designed for an immersive audio experience with Active Noise Cancellation (ANC) and clear call quality.

Image: itel Buds Ace ANC Wireless Earbuds in their charging case. The earbuds are a cranberry color, matching the case interior, with a small LED indicator on the front of the case.

Earbud Components:

- **Touch Control Area:** For playback, calls, and ANC modes.
- **Microphone:** For calls and Environmental Noise Cancellation (ENC).
- **Charging Contacts:** Connects to the charging case.
- **Ear Tip:** Provides a secure fit and passive noise isolation.

Charging Case Components:

- **Earbud Charging Slots:** Holds and charges the earbuds.
- **LED Indicator:** Shows charging status and battery level.
- **USB-C Charging Port:** For charging the case.

SETUP

1. Initial Charging

1. Place both earbuds into the charging case.
2. Connect the provided C-type charging cable to the charging port on the case and a USB power source (e.g., wall adapter, computer USB port).
3. The LED indicator on the case will illuminate to show charging status. Ensure the case and earbuds are fully charged before first use. A full charge typically takes approximately 2 hours.

Image: The itel Buds Ace ANC charging case being charged via a USB-C cable. This illustrates the charging process for the device.

2. Pairing with a Device

1. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED on the earbuds.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "itel Buds Ace ANC" from the list.
4. Once connected, the earbud LEDs will stop flashing, and you will hear a confirmation tone.
5. If pairing fails, place the earbuds back in the case, close the lid, wait a few seconds, then repeat the steps.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Open the charging case, or take the earbuds out of the case. They will power on automatically.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically.

Music Playback Controls

Action	Control
Play/Pause	Single tap either earbud
Next Track	Double tap the right earbud
Previous Track	Double tap the left earbud
Volume Up	Triple tap the right earbud
Volume Down	Triple tap the left earbud

Call Management

Action	Control
Answer/End Call	Single tap either earbud
Reject Call	Press and hold either earbud for 2 seconds

Image: Two itel Buds Ace ANC earbuds, highlighting their dual microphone setup for Environmental Noise Cancellation (ENC) to ensure clear voice calls.

Active Noise Cancellation (ANC) / Transparency Mode

- **Toggle ANC/Transparency Mode:** Press and hold the touch control area on the left earbud for 2 seconds to cycle between ANC On, Transparency Mode, and ANC Off.

Image: A single itel Buds Ace ANC earbud against a cosmic background, illustrating the Active Noise Cancellation feature, capable of reducing noise by approximately 25dB.

Voice Assistant

- **Activate Voice Assistant:** Press and hold the touch control area on the right earbud for 2 seconds to activate your device's voice assistant (e.g., Google Assistant).

CHARGING

The itel Buds Ace ANC offer extended playtime and fast charging capabilities.

Charging the Earbuds

- Place the earbuds into the charging case. They will automatically begin charging.
- The LED indicators on the earbuds (if present) or case will show charging status.

Charging the Case

- Connect the USB-C cable to the charging port on the case and a power source.
- The case's LED indicator will show its charging status.

Battery Life and Fast Charging

- **Total Playtime:** Up to 50 hours with the charging case.
- **Fast Charging:** A 10-minute charge provides approximately 180 minutes (3 hours) of playback.

Image: The itel Buds Ace ANC earbuds and charging case, illustrating the extended battery life of up to 50 hours of total playtime.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.

- Ensure charging contacts on both earbuds and case are clean and free of debris to maintain proper charging.

Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

Water Resistance (IPX5)

The earbuds are rated IPX5 water-resistant, meaning they can withstand splashes of water and sweat. They are suitable for workouts and light rain. Do not submerge the earbuds in water or expose them to heavy rain.

Image: A close-up of an itel Buds Ace ANC earbud with water droplets splashing on it, indicating its IPX5 waterproof rating, making it suitable for workouts and light exposure to moisture.

TROUBLESHOOTING

Problem	Solution
Earbuds not pairing	<ul style="list-style-type: none"> • Ensure earbuds are charged. • Place earbuds back in the case, close, then reopen to re-enter pairing mode. • Turn off and on Bluetooth on your device. • Forget "itel Buds Ace ANC" from your device's Bluetooth list and re-pair.
No sound from one earbud	<ul style="list-style-type: none"> • Ensure both earbuds are charged. • Place both earbuds back in the case, close, then reopen. • Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise, re-pairing often resolves this).
Charging issues	<ul style="list-style-type: none"> • Check the charging cable and power adapter. • Ensure charging contacts on earbuds and case are clean. • Verify the USB-C cable is fully inserted into the charging port.
ANC not working effectively	<ul style="list-style-type: none"> • Ensure ANC mode is activated (press and hold left earbud). • Adjust earbud fit and try different ear tip sizes for a better seal.

SPECIFICATIONS

Feature	Detail
Model Name	Buds Ace ANC
Noise Control	Active Noise Cancellation (~25dB)
Connectivity Technology	Wireless (Bluetooth v5.3)
Bluetooth Range	10 Metres
Audio Driver Size	10 Millimetres Dynamic Drivers

Feature	Detail
Battery Life (Earbuds)	Up to 51 Hours (Total with case)
Charging Time	Approx. 2 Hours (Case)
Fast Charging	10 min charge = 180 min playback
Microphones	2-Mic Environmental Noise Cancellation (ENC)
Water Resistance	IPX5
Control Type	Touch, Voice (Google Assistant)
Material	Polycarbonate (PC)
Item Weight	45 Grams
Product Dimensions	6.5 x 2.9 x 5.3 cm
Manufacturer	Shenzhen Muke Technology Co.,Ltd
Country of Origin	China

SAFETY INFORMATION

- Do not disassemble, repair, or modify the product.
- Keep the product away from extreme temperatures, humidity, and corrosive substances.
- Avoid exposing the product to fire or high heat.
- Do not use the product at high volume for extended periods to prevent hearing damage.
- Keep out of reach of children and pets.
- Dispose of the product and its batteries responsibly according to local regulations.

WARRANTY AND SUPPORT

Your Itel Buds Ace ANC Wireless Earbuds are covered by a limited warranty. For detailed warranty terms, conditions, and support, please refer to the warranty card included with your product or visit the official Itel website. If you encounter any issues not covered in this manual, please contact Itel customer support for assistance.