

[Manuals.plus](#) /

› [Blink](#) /

› Blink Outdoor 4 Wireless HD Security Camera User Manual

Blink Outdoor 4

Blink Outdoor 4 Wireless HD Security Camera User Manual

Model: Outdoor 4

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Blink Outdoor 4 Wireless HD Security Camera. The Blink Outdoor 4 is a 4th generation wireless security camera designed for both indoor and outdoor surveillance, accessible via the Blink application on your smartphone. It features 1080p HD live video, infrared night vision, and two-way audio communication.

The camera is powered by two AA lithium batteries, offering up to two years of battery life, which can be extended to four years with an optional battery extension module (sold separately). Advanced features include dual-zone motion detection, customizable privacy zones, and optional person detection with a Blink subscription.

blink

an **amazon** company



Autonomie de
deux ans



Vision HD de jour
comme de nuit



Système audio
bidirectionnel



Détection de
mouvements avancée

Image: The Blink Outdoor 4 camera highlighting its key features: two-year battery life, HD day and night vision, two-way audio, and advanced motion detection.

WHAT'S IN THE BOX

The Blink Outdoor 4 package typically includes the following components:

- One Blink Outdoor 4 Camera
- One Blink Sync Module Core (if purchased as a system)
- Two AA 1.5V Metallic Lithium Batteries (non-rechargeable)
- Mounting Kit (screws and wall anchors)
- USB Cable
- Power Adapter (for Sync Module Core, not included with add-on camera only)



Image: The Blink Outdoor 4 camera and Sync Module Core, alongside a smartphone showing the Blink Home Monitor app.

SETUP GUIDE

Follow these steps to set up your Blink Outdoor 4 camera system.

1. Download the Blink Home Monitor App

1. Download the **Blink Home Monitor** app from your smartphone's app store.
2. Create a new account or log in to your existing Blink account.
3. Ensure your smartphone meets the minimum requirements: iOS 15.0, Android 9.0, or Fire 9.0.

2. Set Up the Sync Module Core (if applicable)

The Sync Module Core acts as a hub for your Blink cameras.

1. Plug the Sync Module Core into a power outlet using the provided USB cable and power adapter.

2. Open the Blink app and follow the on-screen instructions to add the Sync Module to your system.
3. Connect the Sync Module to your 2.4 GHz Wi-Fi network (802.11b/g/n). A high-speed internet connection (broadband, fiber, or DSL) is required.

3. Install the Blink Outdoor 4 Camera

1. Insert the two AA 1.5V metallic lithium batteries into the camera.
2. In the Blink app, add the Outdoor 4 camera to your system and link it to your Sync Module.
3. Choose a suitable location for your camera. It can be mounted indoors or outdoors.
4. Use the included mounting kit to secure the camera. Ensure the camera has a clear field of view (143° diagonal).



**Installation sans fil facile et jusqu'à
deux ans d'autonomie**

Image: A Blink Outdoor 4 camera discreetly mounted on a tree, illustrating its wireless installation capability.

OPERATING YOUR CAMERA

Live View and Two-Way Audio

- Open the Blink app and select your camera to view live 1080p HD video.
- Use the microphone icon in the app to activate two-way audio, allowing you to speak and listen through the camera.




Image: A smartphone screen showing the Blink app's live view feature, allowing users to communicate with visitors or pets.

Motion Detection and Notifications

- The camera features advanced dual-zone motion detection.
- Customize motion detection settings within the Blink app to receive notifications on your smartphone.
- **Person Detection:** With an optional Blink subscription, the camera can differentiate between people and other motion, sending specific notifications when a person is detected.

Privacy Zones

- Create up to two privacy zones in the Blink app to exclude specific areas from the camera's field of view. This prevents recording or detection in sensitive areas.



Excluez jusqu'à 2 zones de confidentialité du champ de vision de la caméra

Image: A smartphone screen showing the Blink app's privacy zone configuration, allowing users to define areas not to be monitored.

Cloud Video Storage

- A Blink subscription (30-day free trial included) provides unlimited cloud storage for event clips for up to 30 days.
- To save important videos beyond this period, download them to your mobile device.

Alexa Integration

- The Blink Outdoor 4 camera is compatible with Alexa-enabled devices.
- Link your Blink account to Alexa to view live feeds or receive announcements on compatible Echo devices. For example, say "Alexa, show me the garden."

fonctionne
avec




« Alexa, montre-moi le jardin. »

Image: An Amazon Echo Show device displaying a live feed from the Blink Outdoor 4 camera, demonstrating Alexa integration.

MAINTENANCE

Battery Replacement

- The Blink Outdoor 4 camera uses two AA 1.5V metallic lithium batteries. These are non-rechargeable.
- Expected battery life is up to two years under normal usage.
- When the battery level is low, you will receive a notification in the Blink app. Replace both batteries simultaneously with new metallic lithium AA batteries.
- An optional battery extension module (sold separately) can double the battery life to up to four years.

Cleaning

- Gently wipe the camera lens and body with a soft, dry cloth to remove dust or smudges.
- Avoid using harsh chemicals or abrasive materials, as these can damage the camera.

TROUBLESHOOTING

Issue	Possible Solution
Camera offline	<ul style="list-style-type: none">• Check if the Sync Module Core is powered on and connected to Wi-Fi.• Ensure the camera is within range of the Sync Module and your Wi-Fi network.• Replace camera batteries if low.• Restart the Sync Module by unplugging and replugging it.
Poor video quality	<ul style="list-style-type: none">• Ensure a stable Wi-Fi connection with a minimum upload speed of 3.5 Mb/s.• Clean the camera lens.• Move the camera closer to the Sync Module or Wi-Fi router.
Motion detection not working	<ul style="list-style-type: none">• Check motion detection settings in the Blink app.• Ensure privacy zones are not blocking the desired detection area.• Verify camera is armed in the app.
Two-way audio issues	<ul style="list-style-type: none">• Check microphone and speaker settings in the Blink app.• Ensure your smartphone's volume is up.• Verify a strong internet connection.

SPECIFICATIONS

Feature	Detail
Model	Blink Outdoor 4
Generation	4th Generation
Field of View	143° diagonal
Camera Resolution	1080p HD video
Image Resolution	640 x 360
Frames Per Second	Up to 30 fps
Dimensions	70 x 70 x 41 mm
Weight	141 g (camera only)
Power	Two AA 1.5V metallic lithium batteries (non-rechargeable)
Wi-Fi Connectivity	2.4 GHz 802.11b/g/n
Internet Requirements	High-speed internet (broadband, fiber, or DSL). Minimum 3.5 Mb/s upload speed.
Sync Module Compatibility	Blink Sync Module Core and Blink Sync Module 2

Feature	Detail
Minimum Smartphone OS	iOS 15.0, Android 9.0, or Fire 9.0
Application	Blink Home Monitor
Audio System	Two-way audio
Operating Temperature	-20 °C to 45 °C
Software Security Updates	Guaranteed for at least four years from product retirement.
Cloud Video Storage	Up to 30 days with Blink subscription (after trial).

WARRANTY AND SUPPORT

Warranty Information

This device is covered by a legal conformity warranty for consumer goods, as per French consumer code articles L.217-3 et seq., covering defects appearing within 24 months from the delivery date. You are entitled to free repair or replacement for non-conforming devices. Additionally, a hidden defects warranty applies for 2 years following the discovery of a defect, allowing for a price reduction or product refund.

A one-year commercial warranty is also provided by the manufacturer. Details are available in the product packaging and the commercial warranty section. This commercial warranty applies even when purchasing Amazon devices from authorized resellers.

Customer Support

For further assistance, troubleshooting, or detailed information, please visit the official [Blink help page](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question