

[Manuals.plus](#) /

› [4 EVER WINNER](#) /

› User Manual: 4 EVER WINNER Fireplace TV Stand with Electric Fireplace

4 EVER WINNER FTS 241108

User Manual: Fireplace TV Stand with Electric Fireplace

Brand: 4 EVER WINNER

Model: FTS 241108

1. INTRODUCTION

Thank you for choosing the 4 EVER WINNER Fireplace TV Stand. This 70-inch entertainment center is designed to accommodate TVs up to 80 inches and features an integrated 40-inch electric fireplace. It combines functional storage with the ambiance of a fireplace, making it a central piece for your living room.

This manual provides essential information for the safe assembly, operation, and maintenance of your new fireplace TV stand. Please read it thoroughly before beginning assembly or operation and retain it for future reference.



Figure 1.1: The 4 EVER WINNER Fireplace TV Stand with an 80-inch TV, showcasing its design and integrated electric fireplace.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions before using this appliance.

- Ensure all electrical connections comply with local codes and national electrical codes.
- Do not operate the fireplace with a damaged cord or plug, or if the heater malfunctions or has been dropped or damaged in any manner.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater.
- The electric fireplace features overheat protection. If the heater overheats, it will automatically shut off. Unplug the unit and allow it to cool before restarting.
- This unit is designed for indoor use only. Do not use outdoors.
- The TV stand is made of medium density fiberboard and can support up to 300 pounds. Ensure the weight of your TV and other items does not exceed this limit.

- Always use the product on a flat, stable surface to prevent tipping.
- Keep children and pets away from the fireplace and ensure the child lock feature is engaged when necessary.

3. PACKAGE CONTENTS

Your 4 EVER WINNER Fireplace TV Stand will be delivered in two separate packages, which may arrive on different days. Please ensure you have received both packages and all components before beginning assembly. Carefully unpack all items and compare them with the parts list provided in the separate assembly instructions. All hardware and required components are clearly numbered for easy identification.



Figure 3.1: The TV stand and electric fireplace are shipped in two separate packages.

Expected Components:


- TV Stand Panels (top, side, bottom, shelves, drawer parts, door frames)
- Electric Fireplace Insert
- Hardware Pack (screws, dowels, cam locks, hinges, drawer slides, handles)
- Remote Control for Fireplace
- Assembly Instructions Manual

4. SETUP AND ASSEMBLY

Assembly of the 4 EVER WINNER Fireplace TV Stand is designed to be straightforward with detailed instructions provided in a separate manual. Please follow these general guidelines:

1. **Prepare Your Space:** Choose a clear, flat, and spacious area for assembly. Lay down a blanket or cardboard to protect the furniture pieces and your floor.
2. **Identify Parts:** Refer to the numbered parts list in your assembly manual. Each component is labeled to match the instructions.
3. **Gather Tools:** Basic tools such as a Phillips head screwdriver and a hammer are typically required.
4. **Follow Instructions:** Assemble the TV stand frame first, then integrate the electric fireplace unit. Ensure all connections are secure before moving the assembled unit.
5. **Adjustable Shelves:** The storage cabinets feature adjustable shelves, allowing you to customize the space for various items.

Product Dimensions



The item will be delivered in 2 Packages and may NOT arrived on same day



Figure 4.1: Product dimensions for planning your space and assembly.

Fireplace TV Stand for 80" TV



Figure 4.2: The TV stand is designed to accommodate TVs up to 80 inches.

5. OPERATING INSTRUCTIONS (ELECTRIC FIREPLACE)

The integrated 40-inch electric fireplace provides both warmth and ambiance. It features a three-sided tempered glass display for an immersive view of the flames.

Fireplace Features:

- **Flame Brightness:** 5 adjustable settings (L1-L5) to suit your preference.
- **Flame Colors:** 12 distinct flame color options to match your mood or decor.
- **Heat Output:** 1500 Watts, capable of heating a room up to 300 square feet.
- **Temperature Control:** Adjustable thermostat from 60°F to 99°F.
- **Timer Function:** Set the fireplace to automatically turn off after 0.5 to 12 hours.
- **Safety Features:** Includes child lock and overheat protection for safe operation.
- **Realistic Effects:** Features crystal stones and wood burning effects for an authentic fireplace experience.



Figure 5.1: Key features and controls of the electric fireplace.

Using the Remote Control:

The electric fireplace comes with a remote control for convenient operation. Use the remote to power on/off, adjust flame settings, temperature, and set the timer.



Remote control

Remote control makes it easier for you to control the fireplace

Adequate Storage Space

Open shelf provide additional storage space



Adjustable Shelf

Adjustable shelves allow for flexible storage

Figure 5.2: The fireplace can be controlled via its panel or the included remote control.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your fireplace TV stand.

- **Cleaning the Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the engineered wood finish.
- **Cleaning the Fireplace:** Ensure the fireplace is turned off and unplugged before cleaning. Wipe the glass and exterior surfaces with a soft, lint-free cloth. Do not spray cleaners directly onto the unit.
- **Dusting:** Regularly dust the unit to prevent buildup, especially around the fireplace vents.
- **Cord Care:** Periodically inspect the power cord for any signs of damage. If damaged, do not use the unit and contact customer support.

7. TROUBLESHOOTING

If you encounter issues with your fireplace TV stand, please refer to the following common troubleshooting tips:

- **Fireplace Not Turning On:**

- Check if the power cord is securely plugged into a working electrical outlet.
- Ensure the main power switch on the fireplace unit is in the "ON" position.
- Verify that the circuit breaker has not tripped.

- **No Heat Output:**

- Confirm the heat function is activated on the control panel or remote.
- Check if the temperature setting is higher than the current room temperature.
- The overheat protection may have activated. Unplug the unit, wait 10-15 minutes, and plug it back in.

- **Remote Control Not Working:**

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the fireplace's sensor.

- **Unstable Stand:**

- Check all assembly screws and connections to ensure they are tightened.
- Ensure the stand is placed on a level surface.

For issues not covered here, please contact 4 EVER WINNER customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	4 EVER WINNER
Model Name	FTS 241108
Color	White
Material	Engineered Wood
Overall Dimensions (W x D x H)	70" x 13.66" x 30.9"
Fireplace Size	40 inches (width)
Heat Output	1500 Watts
Heating Coverage	Up to 300 sq ft
Temperature Range	60°F - 99°F
Timer	0.5 - 12 Hours
Weight Capacity (Top)	300 lbs
Item Weight	80 lbs
TV Compatibility	Up to 80 inches
Power Source	Corded Electric

