

[Manuals.plus](#) /

› [SSmall](#) /

› SSmall Metal Cardbot S RED Blitz Sports Car Transforming Robot Figure Instruction Manual

SSmall Cardbot S

SSmall Metal Cardbot S RED Blitz Sports Car Instruction Manual

Model: Cardbot S (RED Blitz)

1. PRODUCT OVERVIEW

The SSmall Metal Cardbot S RED Blitz is a transforming robot figure that converts between a robot mode and a sports car mode. This manual provides instructions for assembly, transformation, and general care of your RED Blitz figure.



Image 1: The RED Blitz figure in both robot and sports car configurations, showcasing its dynamic design and weapon effects.

2. SAFETY INFORMATION

- **Choking Hazard:** This product contains small parts. Not suitable for children under 3 years.
- **General Use:** Do not put parts of the toy in your mouth.
- **Handling:** Avoid throwing the toy to prevent damage to the product or injury to others.
- **Recommended Age:** Manufacturer recommended age is 16 years and up, due to complexity of transformation and small parts.

3. PACKAGE CONTENTS

Verify that all components listed below are present in your package:

- 1x RED Blitz Body (Transforming Figure)
- 1x Robot Card
- 1x Weapon Card
- 1x Instruction Manual (this document)

Scarlet Hurricane!!!!



레드블리드

4. SETUP AND TRANSFORMATION

The RED Blitz figure can transform between robot mode and sports car mode. Follow the steps carefully to avoid damage.

4.1. Transformation Overview

The transformation process involves articulating various joints and panels. Refer to the detailed visual guide below for specific steps.

Components



Package size 245 * 108 * 300 (mm)
(Transformation manual included)



Red Blitz body

Red Blitz Metal Card



Robot Card



Weapon Card

Image 3: Visual steps for transforming RED Blitz from robot to vehicle mode, and the transformation of the weapon card.

4.2. Robot Mode to Vehicle Mode

1. **Fold Legs:** Collapse the robot's legs and rotate them to form the rear section of the car.

- 2. **Position Arms:** Fold the arms inward and secure them against the robot's torso.
- 3. **Adjust Torso:** Compress and rotate the torso to align with the car's chassis.
- 4. **Form Car Body:** Close panels and connect sections to form the complete sports car body. Ensure all parts click into place securely.

4.3. Vehicle Mode to Robot Mode

- 1. **Separate Panels:** Carefully unclip and separate the car body panels.
- 2. **Extend Torso:** Extend and rotate the central body section to form the robot's torso.
- 3. **Unfold Arms:** Extend the arms from the sides of the vehicle and position them.
- 4. **Unfold Legs:** Separate and extend the rear section of the car to form the robot's legs. Adjust feet for stability.
- 5. **Final Adjustments:** Ensure all joints are locked and the robot stands upright.

5. OPERATION AND WEAPON ENGAGEMENT

The RED Blitz figure comes with Metal Cards that can be used to engage its special weapon.

5.1. Using Metal Cards

- The included Robot Card and Weapon Card are for display and role-play purposes.
- The Weapon Card can be transformed into the Boost Gambiera Weapon. Refer to Image 3 for visual guidance on transforming the Weapon Card.

5.2. Engaging the Boost Gambiera Weapon

Once the Weapon Card is transformed into the Boost Gambiera Weapon, it can be attached to the RED Blitz figure in robot mode. The specific attachment points are typically on the arms or back of the robot. This action simulates the "Scarlet Hurricane!" attack.

6. CARE AND MAINTENANCE

- **Cleaning:** Wipe the figure with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight to prevent discoloration or material degradation.
- **Handling:** Handle with care during transformation to avoid stressing joints or breaking small parts.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Figure does not transform smoothly.	Parts are misaligned or stuck.	Gently re-align parts. Do not force movement. Refer to the transformation guide (Image 3).
Joints feel loose.	Normal wear and tear or improper handling.	Avoid excessive force. If a joint is excessively loose, contact customer support.
Small part detached.	Accidental breakage or manufacturing defect.	If within warranty, contact customer support. For minor detachments, careful reattachment with appropriate adhesive may be possible (use caution).

8. PRODUCT SPECIFICATIONS

Model Name	Cardbot S (RED Blitz)
Brand	SSmall
Product Dimensions	9.65 x 4.25 x 11.81 inches
Item Weight	1.65 pounds
ASIN	B0DHC19CMW
Manufacturer Recommended Age	16 years and up

9. WARRANTY AND CUSTOMER SUPPORT

For warranty information, product support, or to report any issues, please contact SSmall customer service through their official website or the retailer where the product was purchased. Please have your product model number (Cardbot S) and ASIN (B0DHC19CMW) ready when contacting support.