Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Makute CPB008-2BL

Makute CPB008-2BL Cordless Air Blower User Manual

Model: **CPB008-2BL** | Brand: **Makute**

1. Important Safety Instructions

Read all safety warnings and instructions before operating this product. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- **Work Area Safety:** Keep the work area clean and well-lit. Cluttered or dark areas invite accidents.
- **Electrical Safety:** Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- **Personal Safety:** Always wear eye protection. Use appropriate personal protective equipment such as dust masks, non-skid safety shoes, hard hats, or hearing protection when necessary.
- **Tool Use and Care:** Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- **Battery Tool Use and Care:** Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- **Service:** Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

2. Package Contents

Carefully unpack all items and ensure you have received the following components:

- Makute CPB008-2BL Cordless Air Blower Unit
- 2 x 20V Batteries
- Battery Charger
- Blower Nozzles/Attachments (various types)
- User Manual (this document)

If any items are missing or damaged, please contact your retailer for assistance.

3. Product Overview

The Makute CPB008-2BL is a powerful and portable cordless air blower designed for various cleaning and inflating tasks. Its ergonomic design ensures comfortable use in tight spaces.



Figure 3.1: Makute CPB008-2BL Cordless Air Blower. This image displays the complete blower unit with the battery inserted and a nozzle attached, ready for operation.



Figure 3.2: Blower Nozzles. This image shows the different types of nozzles included with the Makute CPB008-2BL, designed for various air flow requirements and applications.

4. Assembly

1. **Attach the Nozzle:** Select the appropriate nozzle for your task. Align the nozzle with the blower's air outlet and push it firmly until it clicks into place. Ensure it is securely fastened.
2. **Insert the Battery:** Ensure the battery is fully charged (refer to Section 5). Slide the battery pack into the battery slot on the blower until it locks securely. A click indicates it is properly seated.
3. **Remove the Battery:** To remove the battery, press the battery release button (usually located on the battery pack) and slide the battery out of the blower.

5. Charging the Battery

The Makute CPB008-2BL comes with a quick-charge function. Follow these steps to charge the battery:

1. Connect the charger to a standard power outlet.
2. Slide the battery pack into the charger. Ensure the battery is correctly oriented and fully seated in the charger.
3. The charger's indicator light will show the charging status. Refer to the charger's specific instructions for light indications (e.g., red for charging, green for fully charged).
4. A fully discharged battery typically charges in approximately 2 hours. Do not overcharge the battery.
5. Once charging is complete, disconnect the charger from the power outlet and remove the battery.

Note: *Always use the original Makute charger provided with the product to avoid damage to the battery or charger.*

6. Operation

Before operating, ensure the battery is fully charged and securely inserted, and the nozzle is properly attached.

1. **Starting the Blower:** Press and hold the trigger switch to start the blower. The motor will begin to operate.
2. **Adjusting Speed:** The blower features a variable speed trigger. Press the trigger further to increase the air speed, and release slightly to decrease it. The speed range is 0 – 18000 RPM.
3. **Stopping the Blower:** Release the trigger switch to turn off the blower.
4. **Operating Tips:**
    - Direct the air flow away from yourself and others.
    - Use the appropriate nozzle for the task. A narrower nozzle provides more concentrated air flow, while a wider nozzle covers a larger area.
    - For optimal battery life, avoid continuous operation at maximum speed for extended periods.

7. Maintenance

Regular maintenance ensures optimal performance and extends the life of your Makute CPB008-2BL air blower.

- **Cleaning:** After each use, wipe down the exterior of the blower with a clean, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Air Vents:** Keep the air vents free from dust and debris to prevent overheating. Use a soft brush or compressed air to clear any blockages.
- **Battery Care:** Store batteries in a cool, dry place away from direct sunlight and extreme temperatures. Do not store fully discharged batteries for long periods.
- **Storage:** When not in use, store the blower, batteries, and charger in a dry, secure location out of reach of children.

8. Troubleshooting

Problem	Possible Cause	Solution
Blower does not start	Battery not inserted correctly or discharged.	Ensure battery is fully seated. Charge the battery.

Problem	Possible Cause	Solution
Reduced air flow	Nozzle blocked or air vents obstructed.	Clear any blockages from the nozzle or air vents.
Battery not charging	Charger not plugged in, faulty charger/battery.	Check power connection. Try another outlet. Contact support if issue persists.
Blower stops during operation	Battery discharged or overheating.	Charge battery. Allow blower to cool down if it feels hot.

9. Specifications

Feature	Detail
Model	CPB008-2BL
Brand	Makute
Voltage	20V
Air Flow	13.4 m^3/min
Speed	0 – 18000 RPM (Revolutions Per Minute)
Battery Charge Time	Approx. 2 hours (for a fully discharged battery)
Special Features	Portable, Ergonomic Design
Included Components	Blower Unit, 2 x 20V Batteries, Battery Charger, Nozzles

10. Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer directly. Makute is committed to providing quality products and support.

Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Makute. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHQV4QHF

More documents and user manuals: **https://manuals.plus/**