

## AngFan AngFan-588

# AngFan Professional Hair Clippers and Trimmer Set Instruction Manual

Model: AngFan-588

## 1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using this appliance. Keep this manual for future reference.

- Avoid use near water.
- Keep blades clean and dry.
- Supervise children during use or storage to prevent accidents.
- Do not disassemble the unit. For service, contact qualified personnel.
- Use only with the provided charging cable.

## 2. PACKAGE CONTENTS

Your AngFan Professional Hair Clippers and Trimmer Set includes:

- 1x Professional Hair Clipper
- 1x Professional Hair Trimmer
- Multiple N-Lock Hair Clipper Guards (1/16" to 1")
- Charging Cable (USB)
- Cleaning Brush
- Blade Oil
- Hair Cutting Cape
- Combs
- Scissors

## R-TYPE SELF-SHARPENING BLADES

High-performance precision-ground blades can cut even the thickest hair as smoothly as slicing through butter



Image: The complete AngFan Professional Hair Clippers and Trimmer Set, including both devices, various guide combs, charging cables, cleaning brush, oil, and a hair cutting cape.

### 3. PRODUCT OVERVIEW & FEATURES

The AngFan Professional Hair Clippers and Trimmer Set is designed for precision hair cutting and trimming, offering both cordless convenience and powerful performance.

- **Cordless Operation:** Enjoy the flexibility of cordless use with the power of a corded clipper.
- **Lithium Ion Power:** Up to 3-hour runtime on a full charge for multiple haircuts.
- **Smart Charge Technology:** Display light indicates battery status (fully charged, charging, low power).
- **Self-Sharpening Blades:** Precision-ground blades cut through thick hair and stay sharper longer.

- **Adjustable Taper Lever:** Easily adjust blade length for blending and fading haircuts.
- **N-Lock Attachment Guards:** Secure guards for cutting lengths from 1/16" to 1".

## RECHARGEABLE HAIR CLIPPER

Cordless & Coded operation  
is super convenient for cutting



20 MINUTES  
FAST-CHARGING  
GET POWER PROMPTLY

The Brand Used  
By Professionals



ADVANCED TECHNOLOGY  
EXCELLENT  
PERFORMANCE & POWER

*Image: Close-up view of the R-type self-sharpening precision-ground blades on the AngFan clipper, designed for smooth cutting.*

## LITHIUM BATTERY POWER

Up to 270 minutes with a charge time of 3 hours



HIGH-TORQUE  
POWERFUL MOTOR



HOLD A CHARGE  
FOR UP TO 9  
MONTHS  
(WHEN NOT IN USE)

The Brand Used  
By Professionals

Image: The AngFan clipper highlighting its lithium battery power, offering up to 270 minutes of runtime, and a high-torque powerful motor.

## 4. CHARGING INSTRUCTIONS

1. Ensure the clipper/trimmer is turned off before charging.
2. Plug the USB charging cable into the charging port on the device.
3. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer USB port.
4. The smart display light will indicate the charging status:
  - **Flashing Red:** Low power
  - **Solid Red:** Charging
  - **Solid Green:** Fully charged

5. A full charge typically takes approximately 3 hours.
6. To maximize battery health and life, charge the unit fully at least every 6 months.

## INTELLIGENT CHARGING TECHNOLOGY

Intelligent display light gives an indication of the battery status...Low power, charging, or fully charged




Image: Diagram illustrating the intelligent charging technology with solid green for fully charged, solid red for charging, and flashing red for low power.


## 5. SETUP

1. **Initial Charge:** Before first use, fully charge both the hair clipper and trimmer as per the "Charging Instructions" section.
2. **Attach Guide Comb:** Select the desired N-Lock attachment guard for your preferred hair length. Align the guard with the clipper/trimmer blade and push firmly until it clicks securely into place. Ensure it is properly seated to prevent accidental detachment during use.

3. **Adjust Taper Lever (Clipper Only):** For the hair clipper, use the adjustable taper lever on the side to fine-tune the blade length for blending and fading. Move the lever up for a shorter cut and down for a longer cut.

## 11 SNAP 'N LOCK CUTTING GUARDS

Meet cutting lengths between 1 inch and 2 inches



CUT HAIR WITHOUT WORRY WITH THE  
SNAP-N-LOCK SECURE ATTACHMENT CLIP

The Brand Used  
By Professionals

Image: A set of N-Lock cutting guards with smooth-glide teeth and secure attachment clips, designed for various cutting lengths.

## 6. OPERATING INSTRUCTIONS

### 6.1 Using the Hair Clipper

1. Ensure the clipper is fully charged and the desired guide comb is attached.
2. Turn on the clipper by sliding the power switch.
3. For optimal results, cut hair when it is clean and dry.
4. Hold the clipper with the blade flat against the head and move it slowly against the direction of hair growth.

5. Use the adjustable taper lever to achieve desired blending and fading effects.
6. After use, turn off the clipper and clean the blades.

## 6.2 Using the Hair Trimmer

1. Ensure the trimmer is fully charged.
2. Turn on the trimmer by sliding the power switch.
3. For precise lines and detailing, use the trimmer without a guard.
4. For beard trimming or shorter hair lengths, attach the appropriate guide comb.
5. Move the trimmer gently against the direction of hair growth for an even trim.
6. After use, turn off the trimmer and clean the blades.

### ADJUSTABLE TAPER LEVER

For effortless blending and highly customized cutting lengths that meet your specific styling needs



The Brand Used  
By Professionals



Image: A hand holding the AngFan Professional Hair Clipper, demonstrating its ergonomic design for comfortable use during haircuts.



Image: Close-up of the AngFan clipper's adjustable taper lever, allowing for effortless blending and customized cutting lengths.

## 7. MAINTENANCE

### 7.1 Cleaning the Blades

- 1. After each use, turn off the clipper/trimmer.
- 2. Use the provided cleaning brush to remove any loose hairs from the blades.
- 3. For a more thorough cleaning, detach the blade assembly (refer to user manual for specific instructions if needed).
- 4. Keep blades clean and dry to prevent rust and ensure optimal performance.

### 7.2 Oiling the Blades

- 1. Regularly oil the blades to maintain sharpness and smooth operation.
- 2. Apply a few drops of the provided blade oil across the top of the blades while the device is running.
- 3. Allow the device to run for a few seconds to distribute the oil, then turn it off.
- 4. Wipe off any excess oil with a soft cloth.

## 8. TROUBLESHOOTING

| Problem                  | Possible Cause                                                  | Solution                                                                                     |
|--------------------------|-----------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| Device not turning on    | Low battery; Power switch off                                   | Charge the device; Ensure power switch is in the ON position                                 |
| Poor cutting performance | Dull/dirty blades; Insufficient oil; Incorrect guard attachment | Clean and oil blades; Ensure guard is correctly attached; Replace blades if excessively dull |
| Device overheating       | Prolonged continuous use                                        | Turn off and allow to cool down before resuming use                                          |

## 9. SPECIFICATIONS

---

- **Model Number:** AngFan-588
- **Product Dimensions:** 5 x 1.51 x 1.5 inches
- **Item Weight:** 1.5 Pounds
- **Power Source:** Battery Powered (Lithium Ion)
- **Runtime:** Up to 3 hours on a full charge
- **Charging Time:** Approximately 3 hours
- **Color:** Blue+sliver
- **Manufacturer:** angfan

## 10. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official AngFan website.

## 11. LEGAL DISCLAIMER

---

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

## 12. PRODUCT VIDEOS

---

### AngFan Professional Hair Clippers & Trimmer Set Overview

Your browser does not support the video tag.

*Video Description: A seller provides an unboxing and initial overview of the AngFan Professional Hair Clippers and Trimmer Set, showcasing the contents and basic features.*

### All About These Professional Hair Clippers for Men

Your browser does not support the video tag.

*Video Description: A seller provides a detailed review and demonstration of the AngFan Professional Hair Clippers, covering its features, performance, and ease of use.*

### Pro Hair Clippers Set: Cordless Barber Kit for Fades & Cuts

Your browser does not support the video tag.

*Video Description: A seller demonstrates the AngFan Pro Hair Clippers Set, highlighting its cordless functionality and suitability for creating fades and various haircuts.*

## Product Overview for Angfan Professional Clippers

Your browser does not support the video tag.

*Video Description: A seller provides a comprehensive product overview of the AngFan Professional Clippers, detailing its features and benefits for users.*

© 2026 AngFan. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question