

manuals.plus /

- › [Dragon Touch](#) /
- › [Dragon Touch 10.1-inch Wi-Fi Digital Picture Frame User Manual](#)

Dragon Touch 850065712093

Dragon Touch 10.1-inch Wi-Fi Digital Picture Frame User Manual

Model: 850065712093



1. INTRODUCTION

1.1 Product Overview

The Dragon Touch 10.1-inch Wi-Fi Digital Picture Frame allows you to instantly share photos and videos with loved ones from anywhere in the world. Featuring a 1280x800 HD IPS touch screen, auto-rotate function, and 16GB internal storage, this frame provides a convenient way to display your cherished memories.



Image 1.1: The Dragon Touch 10.1-inch Wi-Fi Digital Picture Frame, showcasing its display with a vibrant image of a mother and child. A smartphone screen is overlaid, illustrating the Vphoto app interface for photo sharing.

1.2 Package Contents

Verify that all items are present in the package:

- 1 x Dragon Touch 10.1-inch Wi-Fi Digital Picture Frame
- 1 x Power Adapter
- 1 x Stand
- 1 x USB Cable
- 1 x User Manual (this document)



Image 1.2: An illustration detailing the components included in the product package, such as the frame, power adapter, stand, USB cable, and user manual.

2. SETUP

2.1 Initial Setup

1. **Power On:** Connect the power adapter to the frame and plug it into a power outlet. The frame will automatically power on.
2. **Language Selection:** Follow the on-screen prompts to select your preferred language.
3. **Wi-Fi Connection:** Connect the frame to a 2.4 GHz Wi-Fi network. *Note: 5 GHz networks are not supported.*
4. **App Installation:** Download the "Vphoto" app from your smartphone's app store (iOS or Android).
5. **Account Creation:** Open the Vphoto app and create an account.
6. **Frame Pairing:** Follow the app instructions to pair your smartphone with the digital picture frame. This typically involves scanning a QR code displayed on the frame or entering a unique frame code.




Image 2.1: A visual guide illustrating the three primary steps for initial setup: connecting to power and Wi-Fi, downloading the Vphoto app, and uploading photos.

3. OPERATING INSTRUCTIONS

3.1 Uploading Photos and Videos

The Dragon Touch digital picture frame supports multiple methods for uploading media:

- **Vphoto App:** Use the Vphoto app on your smartphone to instantly send photos and short videos to the frame. Multiple users can connect to the same frame to share memories.
- **Email:** The frame can be configured to receive photos via email. Check the frame settings for the unique email address.
- **TF Card (Micro SD Card):** Insert a TF card (up to 64GB) into the designated slot to display media directly or transfer files to internal storage.
- **USB Drive:** Connect a USB drive to the frame's USB port to display media directly or transfer files.



Image 3.1: Visual representation of the four supported methods for uploading media to the digital picture frame: Vphoto App, Email, TF card, and USB drive.

3.2 Display Settings

Customize your viewing experience through the frame's touch screen settings:

- **Auto-Rotate:** The frame automatically adjusts photo orientation whether placed in portrait or landscape mode.
- **Sleep Mode:** Configure a customized sleep schedule to automatically turn the screen off and on, conserving energy.
- **Slideshow Interval:** Adjust the duration each photo is displayed during a slideshow.
- **Transition Effects:** Select various transition styles for photos.

16GB Large Internal Storage

Support TF card (Max 64GB)



Image 3.2: The digital picture frame showcasing its auto-rotate feature, displaying an image in landscape orientation with an accompanying icon.

4. STORAGE MANAGEMENT

The frame comes with 16GB of built-in memory, capable of storing approximately 80,000 photos. For additional storage or file management, external options are available.

- **Internal Storage:** Manage photos and videos directly on the frame.
- **SD Card/USB Drive:** Use these to read files or export received photos and videos for better album management. *Important: Remove all external devices when resetting the photo frame.*

Auto-Rotate and Wall Mounted

Automatically adjust photo orientation and mount the frame wherever you like



Image 4.1: A visual representation of the frame's large internal storage capacity, depicted by numerous photos surrounding the device.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and frame. Avoid liquid cleaners or abrasive materials.
- **Placement:** Place the frame on a stable surface or mount it securely on a wall. Avoid direct sunlight or extreme temperatures.
- **Software Updates:** Periodically check for and install software updates to ensure optimal performance and access to new features.

6. TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Frame does not power on.	Ensure the power adapter is securely connected to both the frame and a working power outlet.
Cannot connect to Wi-Fi.	Verify that you are connecting to a 2.4 GHz Wi-Fi network. Check your Wi-Fi password. Restart your router and the frame.
Photos/Videos not appearing.	Confirm the frame is connected to Wi-Fi. Ensure media was successfully uploaded via the Vphoto app, email, or external storage. Check file formats for compatibility.
Frame is unresponsive.	Perform a soft reset by unplugging the power adapter, waiting 10 seconds, and plugging it back in. If issues persist, a factory reset may be necessary (refer to settings).
Email uploads fail.	Ensure the email address used is correct and the frame's email function is enabled. Avoid special characters like "#" in filenames, as these may cause issues.

7. SPECIFICATIONS

Feature	Detail
Model Number	850065712093
Screen Size	10.1 Inches
Resolution	1280x800
Display Type	HD IPS Touch Screen
Internal Storage	16GB (approx. 80,000 photos)
External Storage	Supports SD card (up to 64GB) and USB drive
Connectivity	Wi-Fi (2.4 GHz only)
Compatible Devices	Smartphone (via Vphoto App)
Product Dimensions	10.3 x 7.1 x 0.99 inches
Item Weight	1.72 pounds
Manufacturer	Dragon Touch







8. WARRANTY AND SUPPORT

For warranty information, technical support, or customer service inquiries, please refer to the official Dragon Touch website or contact their customer support directly. Details are typically provided on the product packaging or the manufacturer's website.

Online resources and FAQs may also be available to assist with common questions and issues.



Related Documents - 850065712093

<p>DRAGON TOUCH</p> <p>MODERN 15 PRO DIGITAL PHOTO FRAME</p>  <p>USER MANUAL</p>	<p>Dragon Touch Modern 15 Pro Digital Photo Frame User Manual</p> <p>This user manual provides comprehensive instructions for the Dragon Touch Modern 15 Pro digital photo frame, covering setup, file uploading via VPHOTO app, email, USB/TF card, and computer, key features, general settings, technical specifications, and troubleshooting.</p>
<p>DRAGON TOUCH</p> <p>CLASSIC 21 DIGITAL PHOTO FRAME</p>  <p>USER MANUAL</p>	<p>Dragon Touch Classic 21 Digital Photo Frame User Manual</p> <p>Comprehensive user manual for the Dragon Touch Classic 21 Digital Photo Frame, covering setup, file uploading (VPhoto app, email, USB, computer), key features, settings, technical specifications, and troubleshooting.</p>
<p>DRAGON TOUCH</p> <p>MODERN 16 DIGITAL PHOTO FRAME</p>  <p>USER MANUAL</p>	<p>Dragon Touch MODERN 16 Digital Photo Frame User Manual</p> <p>Comprehensive user manual for the Dragon Touch MODERN 16 Digital Photo Frame. Learn setup, photo/video uploading via app, email, USB, computer, key features, settings, and troubleshooting.</p>
<p>DRAGON TOUCH</p> <p>MODERN 15 DIGITAL PHOTO FRAME</p>  <p>USER MANUAL</p>	<p>Dragon Touch MODERN 15 Digital Photo Frame User Manual</p> <p>Comprehensive user manual for the Dragon Touch MODERN 15 Digital Photo Frame, covering setup, photo uploading via app, email, USB, and computer, key features like slideshows, multiple functions, general settings, technical specifications, troubleshooting, and FCC warnings.</p>
<p>DRAGON TOUCH</p> <p>CLASSIC 15 PRO DIGITAL PHOTO FRAME</p>  <p>USER MANUAL</p>	<p>Dragon Touch Classic 15 Pro User Manual: Setup, Features, and Troubleshooting Guide</p> <p>Get started with your Dragon Touch Classic 15 Pro digital photo frame. This user manual covers setup, photo and video uploading via VPhoto app, email, USB/TF card, key features, settings, and troubleshooting.</p>
<p>DRAGON TOUCH</p> <p>CLASSIC 10 DIGITAL PHOTO FRAME</p>  <p>USER MANUAL</p>	<p>Dragon Touch Classic 10 Digital Photo Frame User Manual</p> <p>User manual for the Dragon Touch Classic 10 Wifi Cloud Photo Frame, detailing setup, photo uploading via app, email, USB/SD card, music upload, key features like slideshows, multiple functions, general settings, technical specifications, and troubleshooting.</p>