



Manuals.plus /

› Tastyle /

› Tastyle Single Serve Hot & Iced Coffee Maker (Model 2.0) Instruction Manual

Tastyle 2.0

Tastyle Single Serve Hot & Iced Coffee Maker (Model 2.0) Instruction Manual

Your guide to brewing perfect coffee, hot or iced.

INTRODUCTION

Welcome to the Tastyle Single Serve Hot & Iced Coffee Maker experience. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new coffee maker. Please read all instructions carefully before first use.



Image: The Tastyle coffee maker, showcasing its compact design and versatility with both K-cup pods and ground coffee options, alongside a cup of hot coffee and a glass of iced coffee.

SETUP

1. **Unboxing:** Carefully remove all components from the packaging. Ensure all parts are present: coffee maker unit, 40oz removable reservoir, K-pod holder, and permanent ground filter.
2. **Initial Cleaning:** Before first use, wash the removable water reservoir, K-pod holder, and permanent ground filter with warm, soapy water. Rinse thoroughly. It is recommended to run a few cycles with just water to flush the internal system.
3. **Positioning:** Place the coffee maker on a stable, flat surface near a power outlet. Ensure adequate clearance around the unit.
4. **Fill Water Reservoir:** Remove the 40oz water reservoir from the back of the unit. Fill it with fresh, cold water up to the 'Max' line. Reattach the reservoir securely to the unit.
5. **Power Connection:** Plug the power cord into a standard 120V AC outlet. The ON/OFF button will illuminate.

40oz Removable Reservoir

Easy to fill and clean

Allows to brew 4 cups before refilling



Image: A user demonstrating the removal of the 40oz water reservoir for easy filling and cleaning.

OPERATING INSTRUCTIONS

Your Tastyle coffee maker offers versatile brewing options to suit your preference.

Brewing Coffee

1. Prepare Coffee:

- **For K-Cup Pods:** Insert a K-Cup pod into the K-pod holder. Close the lid firmly.
- **For Ground Coffee:** Fill the permanent ground filter with your desired amount of ground coffee (up to

30g). Place the filled filter into the K-pod holder. Close the lid firmly.

2. **Select Brew Style:** Choose from the following options on the control panel:
 - **Hot Brew:** For a standard hot coffee.
 - **Bold:** For a stronger, more intense hot coffee.
 - **Over Ice:** For iced coffee. This function automatically adjusts brewing temperature to minimize ice melting. For best results, use a 1:1 ice-to-water ratio.
3. **Choose Brew Size:** Select your desired cup size from 6, 8, 10, 12, 16, or 24 oz using the 'OZ' button. The corresponding indicator light will illuminate.
4. **Start Brewing:** Press the selected brew style button (Hot Brew, Bold, or Over Ice) to begin brewing. The coffee maker will start dispensing coffee into your mug.
5. **Auto Shut-Off:** The coffee maker will automatically shut off after 10 minutes of inactivity to save energy.

Enjoy 3 Brew Styles



Classic



Bold



Over Ice



Grounds

Pods



2 Ways to Brew Coffee
Pods & Grounds

Image: The coffee maker's control panel highlighting the three brew styles: Classic, Bold, and Over Ice, along with options for using ground coffee or pods.

6 Brew Sizes to Select



Image: Close-up of the control panel showing the brew size selection buttons (6oz, 8oz, 10oz, 12oz, 16oz, 24oz).

Travel Mug Compatibility

The coffee maker features a removable drip tray to accommodate various mug sizes, including travel mugs up to 7.3 inches tall. Simply remove the drip tray for taller containers.

Splatter-Preventing Design

Removable heightened drip tray included, reduce coffee splashing caused by gravity



Image: Comparison showing the coffee maker with and without the drip tray, illustrating how it accommodates different mug heights and prevents splashing.

MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and longevity of your Tastyle coffee maker.

Cleaning

- **Removable Parts:** The K-pod holder, permanent ground filter, and drip tray are removable and dishwasher

safe for easy cleaning.

- **Exterior:** Wipe the exterior of the coffee maker with a damp cloth. Do not immerse the unit in water.

Descaling

The coffee maker includes a built-in descaling reminder function. The 'DESCALE' light will illuminate in red when descaling is needed.

1. Fill the water reservoir with a descaling solution (e.g., vinegar and water mixture, or a commercial descaling agent).
2. Place an empty mug on the drip tray.
3. Press and hold the 'OVER ICE' button for 3 seconds to start the cleaning cycle.
4. Repeat the cycle with fresh water to rinse the system thoroughly.



Image: Visual guide to the descaling process, indicating the 'DESCALE' light and the button to initiate cleaning.

TROUBLESHOOTING

If you encounter any issues with your coffee maker, please refer to the following common solutions:

- **Coffee Not Brewing:** Ensure the water reservoir is filled, the K-cup or ground filter is correctly inserted, and the lid is firmly closed. Check if the unit is properly plugged into a working outlet.
- **Weak Coffee:** Try selecting the 'Bold' brew option. For ground coffee, ensure you are using the recommended amount and a suitable grind size.
- **'DESCALE' Light On:** This indicates it's time to descale your machine. Follow the descaling instructions in the Maintenance section.
- **Leaking:** Ensure the water reservoir is correctly seated and not overfilled. Check that the K-pod holder or ground filter is properly inserted and the lid is closed.
- **Unusual Taste:** Perform an initial cleaning cycle as described in the Setup section. Ensure all removable parts are clean.

If the problem persists, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Tastyle
Model Number	2.0
Color	Black
Product Dimensions	10.3"D x 4.7"W x 12.2"H
Water Reservoir Capacity	40 oz
Brew Sizes	6, 8, 10, 12, 16, 24 oz
Coffee Input Type	Ground, Pod (K-Cup compatible)
Special Features	Adjustable Brew Strength, Auto Shut-Off, Permanent Filter, Removable Tank, Splash-Preventing Design
Operation Mode	Semi-Automatic
Voltage	120 Volts
Item Weight	3.5 pounds
Dishwasher Safe Parts	Yes (removable parts)

WARRANTY & SUPPORT

Your Tastyle coffee maker comes with a **One Year Warranty**.

For any questions, technical support, or warranty claims, please contact Tastyle customer service:

- **Phone:** 1-972-467-4438
- **Email:** support@mytastyle.com

Please have your model number (2.0) and purchase information ready when contacting support.