

- Manuals.plus /
- › Polar Aurora /
- › Polar Aurora Heavy Duty Dog Crate, 43in Instruction Manual

Polar Aurora FDC666

Polar Aurora Heavy Duty Dog Crate (43-inch) Instruction Manual

Model: FDC666

1. PRODUCT OVERVIEW

The Polar Aurora Heavy Duty Dog Crate is designed for durability and convenience, suitable for medium to large dogs. It features a foldable design for easy setup and storage, double doors for access, and lockable wheels for mobility and stability.



Image: Fully assembled Polar Aurora Heavy Duty Dog Crate, 43-inch model.

2. SETUP INSTRUCTIONS

This dog crate features a new folding design for quick and easy setup without complex assembly. Follow these steps to unfold and prepare your crate for use:

1. **Step 1: Unpack the Crate.** Carefully remove the folded crate from its packaging.
2. **Step 2: Unfold the Sides.** Gently lift the top panel and unfold the side panels outwards until they form the crate's rectangular base.
3. **Step 3: Secure the Top.** Lower the top panel and secure it to the side panels using the integrated latches or hooks. Ensure all connections are firm.
4. **Step 4: Install Wheels (if detached).** If the wheels are not pre-attached, insert them into the designated slots at the bottom corners of the crate. Lock the casters to prevent movement during initial setup.
5. **Step 5: Check Doors.** Ensure both front and top doors open and close smoothly and that the upgraded plug locks

engage securely.



Foldable design for easy storage. Open with one click during

Image: Visual guide demonstrating the simple four-step unfolding process of the dog crate.

To fold the crate for storage, reverse these steps. Unlock the top panel, fold the sides inwards, and collapse the crate into a flat, compact form.



Ensure your furry companion has a cozy resting spot, regardless of the time or location

Image: The dog crate in its folded state, demonstrating its compact storage capability.

3. OPERATING INSTRUCTIONS

3.1 Using the Doors

- The crate features a double-door design (front and top) for convenient access.
- To open, slide the upgraded bolt locks and pull the door open.
- Always ensure both locks are fully engaged when the door is closed to secure your pet.

3.2 Utilizing Lockable Wheels


- The four 360-degree swivel casters allow for easy movement of the crate.
- To move the crate, unlock all four wheels by flipping the locking mechanism upwards.
- Once the crate is in the desired position, push the locking mechanism downwards on all wheels to securely anchor the crate in place.



Product Details



1. Not Segmental Welding, Strong and Sturdy
Effectively preventing dogs from biting off the round pipe and injuring themselves



2. Flexible Hinges



3. Upgraded plug lock



4. 360° Rolling Casters

Image: Detailed view of key components including flexible hinges, secure plug lock, and lockable rolling casters.

3.3 Proper Sizing for Your Pet

Ensure your dog's body height is lower than the inside height of the cage to allow them to stand comfortably. The 43-inch model is suitable for medium to large dogs.



Heavy Duty Dog cage

Fully Upgraded, Spacious, Sturdy And Comfortable



Image: Guide on how to choose the correct crate size based on your dog's dimensions.

4. MAINTENANCE

- **Cleaning:** Wipe down the crate regularly with a damp cloth and mild, non-toxic cleaner. Ensure the crate is dry before returning your pet.
- **Rust and Corrosion:** The crate is coated with a durable hammer-tone finish designed to resist rust and corrosion. For outdoor use, periodically inspect for any signs of wear and tear on the coating.
- **Locks and Hinges:** Periodically check the bolt locks and flexible hinges for smooth operation. Lubricate with a pet-safe lubricant if necessary.
- **Wheels:** Keep the caster wheels free of debris to ensure smooth movement.

5. TROUBLESHOOTING

- **Crate not folding/unfolding smoothly:** Check for any obstructions or bent components. Ensure all latches are

disengaged before folding.

- **Wheels not locking/rolling:** Inspect the caster wheels for debris or damage. Ensure the locking mechanism is fully engaged or disengaged.
- **Door latch issues:** If a door latch feels loose or does not secure properly, inspect the bolt and receiver for alignment or damage. Contact customer support if a component appears faulty or missing.
- **Missing or damaged parts upon arrival:** If you receive the product with missing screws or a loose rivet, please contact customer support immediately for a replacement or assistance.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	43" x 28" x 32.5"
Item Weight	63 Pounds
Material	20-gauge Steel, 0.6-inch diameter steel tubes
Color	Black
Special Feature	Foldable, Lockable Caster Wheels, Double Door
Number of Doors	2
Recommended Breed Size	Large
Model Number	FDC666

7. WARRANTY AND SUPPORT

7.1 Manufacturer's Warranty

This Polar Aurora dog crate comes with a **1-Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use.

7.2 Return Policy

If any issues arise within **30 days of purchase**, you may be eligible for a complimentary replacement. Please refer to the retailer's return policy for specific details regarding returns and replacements.

7.3 Customer Support

For any questions, concerns, or assistance with your product, please contact Polar Aurora customer support directly. Our team is available to ensure your complete satisfaction and peace of mind.

Contact information can typically be found on the product packaging or the official Polar Aurora website.

8. PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video demonstrating the features and functionality of the Polar Aurora Heavy Duty Dog Crate. Duration: 0:55.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DHS2JZ7J>

More documents and user manuals: <https://manuals.plus/>