

[Manuals.plus](#) /

> [Kysson](#) /

> Kysson 3-in-1 Portable Charger, 10000mAh Foldable Power Bank Fast Charging, MagSafe Charger Battery Pack Magnetic, Travel Wireless Charging Station for iPhone, iWatch, Air pods

Kysson D36

Kysson 3-in-1 Portable Charger User Manual

Model: D36

INTRODUCTION

Thank you for choosing the Kysson 3-in-1 Portable Charger. This versatile device combines a 10000mAh power bank with a multi-device wireless charging station, designed for convenience and efficiency. It allows simultaneous charging of your iPhone, Apple Watch, and AirPods, making it an ideal solution for both travel and daily use.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Kysson 3-in-1 Portable Charger:

- **Magnetic Charging Pad:** For MagSafe-compatible iPhones.
- **Apple Watch Charging Module:** Integrated charger for Apple Watch.
- **AirPods Charging Base:** Dedicated spot for wireless charging of AirPods.
- **USB-C Port:** For charging the power bank and wired device charging.
- **Power Button:** To activate the power bank.
- **LED Indicator Lights:** Display battery level and charging status.
- **Foldable Stand:** Allows the device to be used as a desktop charging station.



Image: The Kysson 3-in-1 Portable Charger in its compact, folded state, ready for travel.

SETUP

1. **Unboxing:** Carefully remove the Kysson 3-in-1 Portable Charger from its packaging. Verify all components are present: the charger unit, USB-C cable, and user manual.
2. **Initial Charge:** Before first use, fully charge the power bank. Connect the provided USB-C cable to the charger's USB-C port and plug the other end into a compatible USB-C power adapter (not included). The LED indicator lights will show charging progress.
3. **Folding Mechanism:** The device features a foldable design. Gently unfold the stand to transform it into a desktop charging station. Ensure it is stable on a flat surface.



Image: The Kysson charger set up as a desktop charging station, demonstrating its multi-device charging capability.

OPERATING INSTRUCTIONS

Charging Devices Wirelessly (Desktop Mode)

1. **Unfold the Stand:** Gently unfold the integrated stand to position the charger upright.
2. **Connect to Power (Optional):** For continuous desktop charging, connect the USB-C cable to a power adapter. The device supports pass-through charging, allowing it to charge itself and your devices simultaneously.
3. **Charge iPhone:** Align your MagSafe-compatible iPhone with the magnetic charging pad. The strong magnetic lock will secure the phone in place and initiate charging.
4. **Charge Apple Watch:** Place your Apple Watch onto the dedicated charging module. Ensure it is properly seated for charging to begin.
5. **Charge AirPods:** Place your AirPods charging case on the base of the unit. Ensure the case is aligned with the wireless charging area.

Charging Devices Wirelessly (Portable Power Bank Mode)

1. **Fold the Stand:** Fold the integrated stand back into the unit for a compact form factor.
2. **Activate Power Bank:** Press the power button on the side of the unit to activate the power bank. The LED indicators will light up.
3. **Charge iPhone:** Attach your MagSafe-compatible iPhone to the magnetic charging pad. The magnetic connection will hold it securely, and charging will commence.
4. **Charge Apple Watch:** Place your Apple Watch onto the charging module.
5. **Charge AirPods:** Place your AirPods charging case on the base.

Charging Devices via USB-C Cable

- Connect a USB-C to USB-C cable (not included) from the charger's USB-C port to your device. This port supports both input (recharging the power bank) and output (charging other devices).




Image: The Kysson charger functioning as a nightstand charging station, keeping devices organized and powered.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the charger. Do not use liquid cleaners or aerosols.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, fully charge the power bank at least once every three months if not in regular use.
- **Avoid Drops:** Protect the device from drops and impacts, which can damage internal components.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging wirelessly.	Improper alignment; device not wireless charging compatible; thick phone case; power bank not activated.	Ensure proper alignment on the charging pad. Verify device supports wireless charging. Remove thick cases. Press the power button to activate the power bank.
Slow charging.	Using a low-power adapter; multiple devices charging simultaneously; cable issue.	Use a 5V 3A / 9V 2.2A adapter for optimal speed. Charging multiple devices may reduce individual charging speed. Try a different USB-C cable.
Power bank not recharging.	Faulty cable or adapter; loose connection.	Check cable and adapter. Ensure connections are secure. Try a different cable or adapter.
Magnetic attachment is weak.	Non-MagSafe compatible phone/case; foreign objects between phone and charger.	Ensure your phone or case is MagSafe compatible. Remove any foreign objects.
Hinge for stand becomes loose.	Wear and tear; manufacturing variation.	Contact Kysson customer support for assistance.

Problem	Possible Cause	Solution
LED indicators not working.	Device completely discharged; internal malfunction.	Charge the power bank for an extended period. If issue persists, contact support.

SPECIFICATIONS

Model Number: D36

Battery Capacity: 10000 Milliamp Hours

Product Dimensions: 4.72 x 2.74 x 0.95 inches

Item Weight: 14.9 ounces

Connector Type: USB-C & Wireless

Input/Output: USB-C (5V 3A / 9V 2.2A adapter recommended for fast charging)

Wireless Output (iPhone): 15W (MagSafe compatible)

Wireless Output (Apple Watch): 2.5W

Wireless Output (AirPods): 5W

Special Features: Foldable Portable Charger Power Bank, 3-in-1 Wireless Charging Station, Adjustable Angle, Fast Charging Battery Pack, Travel Essentials, Lightweight Magnetic Charger Stand, Matte Velvety Finish.

Compatibility: iPhone 16/15/14/13/12 Pro Max/Pro/Plus, Apple Watch Ultra/SE/10/9/8/7/6/5/4, AirPods.

WARRANTY AND SUPPORT

Kysonn is committed to providing high-quality products and excellent customer service. Your Kysson 3-in-1 Portable Charger comes with the following support:

365-Day Quality Guarantee: Enjoy peace of mind with a full year quality guarantee.

Lifetime Technical Help: Access technical assistance for the lifetime of your product.

30-Day Free Returns: If you are not satisfied, you can return the product within 30 days for free.

24/7 Fast Support: Dedicated customer support is available around the clock.

For any inquiries, technical support, or warranty claims, please contact Kysson customer service via the details provided on the product packaging or the official Kysson website.




Image: Kysson Care details, highlighting customer support benefits.

