

[manuals.plus](#) /› [PUSAT](#) /› [Pusat Ghost Pro Wireless RGB Gaming Mouse User Manual](#)

PUSAT Ghost Pro

Pusat Ghost Pro Wireless RGB Gaming Mouse User Manual

1. INTRODUCTION

Thank you for choosing the Pusat Ghost Pro Wireless RGB Gaming Mouse. This manual provides detailed instructions for setting up, operating, and maintaining your new gaming mouse. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

2. PACKAGE CONTENTS

- Pusat Ghost Pro Wireless RGB Gaming Mouse
- 2.4GHz USB Wireless Receiver
- USB-C to USB-A Charging/Data Cable
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Pusat Ghost Pro mouse:



Image 1: Top-down view of the Pusat Ghost Pro mouse, highlighting the left and right click buttons, scroll wheel, and the subtle RGB logo.



Image 2: Left side view of the mouse, showing the two programmable side buttons.



Image 3: Bottom view of the mouse,

displaying the optical sensor, PTFE skates, ON/OFF switch, and the storage compartment for the 2.4GHz USB receiver.

1. **Left Click Button:** Primary action button.
2. **Right Click Button:** Secondary action button.
3. **Scroll Wheel:** For vertical scrolling and middle-click functionality.
4. **DPI Indicator LED:** A small LED (often green) located below the scroll wheel, indicating current DPI setting or battery status.
5. **Side Buttons (x2):** Programmable buttons located on the left side for additional functions.
6. **USB-C Port:** Located at the front for charging and wired connection.
7. **Optical Sensor:** High-precision PixArt PAW3395 sensor located on the bottom.
8. **PTFE Skates:** Ultra-smooth feet for effortless gliding.
9. **ON/OFF Switch:** Located on the bottom to power the mouse on or off.
10. **User Profile Switch:** Button on the bottom to cycle through 5 user-defined profiles.
11. **2.4GHz Wireless Receiver Storage:** Compartment on the bottom for storing the USB receiver.

4. SETUP

4.1. Initial Charging

Before first use, it is recommended to fully charge the mouse. Connect the USB-C end of the charging cable to the mouse and the USB-A end to a powered USB port on your computer or a USB wall adapter. The DPI indicator LED will show charging status (e.g., solid red for charging, green for fully charged).

4.2. Wireless Connection

1. Remove the 2.4GHz USB wireless receiver from its storage compartment on the bottom of the mouse.
2. Plug the USB receiver into an available USB port on your computer.
3. Slide the ON/OFF switch on the bottom of the mouse to the 'ON' position.
4. Your computer should automatically detect and install the necessary drivers. The mouse is now ready for use.

4.3. Software Installation (Optional)

For advanced customization of DPI settings, button assignments, RGB lighting, and macro creation, download the official Pusat Ghost Pro software from the manufacturer's website. Follow the on-screen instructions for installation.

5. OPERATING INSTRUCTIONS

5.1. Basic Functionality

The left and right click buttons perform standard mouse actions. The scroll wheel allows for vertical navigation. The side buttons are pre-programmed for common functions (e.g., forward/back in web browsers) but can be customized.

5.2. DPI Adjustment

The Pusat Ghost Pro features a PixArt PAW3395 sensor with adjustable DPI up to 26,000. DPI settings can be cycled through using a dedicated button (if present, typically below the scroll wheel) or customized and switched via the software. The DPI indicator LED may change color to reflect the current DPI stage.

5.3. Button Customization

All 6 buttons on the Pusat Ghost Pro mouse are programmable. Use the dedicated software to assign custom functions, macros, or keyboard shortcuts to each button according to your preferences.

5.4. RGB Lighting Control

The integrated RGB lighting can be customized using the software. You can select various lighting effects, colors, and brightness levels to match your setup.

5.5. User Profiles

The mouse supports up to 5 user-defined profiles. These profiles can store different DPI settings, button assignments, and RGB lighting configurations. Use the 'User Profile' button on the bottom of the mouse to cycle through your saved profiles.

6. CHARGING

When the mouse battery is low, the DPI indicator LED may flash or change color. Connect the mouse to your computer using the provided USB-C cable. The LED will indicate charging status. A full charge typically takes a few hours. The mouse can be used in wired mode while charging.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the mouse. Avoid harsh chemicals or abrasive materials.
- **Sensor:** Keep the optical sensor on the bottom clean and free from dust or debris for accurate tracking.
- **Storage:** When not in use for extended periods, turn off the mouse to conserve battery life. Store it in a cool, dry place.

8. TROUBLESHOOTING

- **Mouse not responding:** Ensure the mouse is turned 'ON' and fully charged. Verify the USB receiver is securely plugged into a working USB port. Try a different USB port.
- **Lag or disconnections:** Ensure the USB receiver is close to the mouse and not obstructed by metal objects. Avoid using the receiver near other wireless devices that may cause interference.
- **DPI not changing:** Ensure the mouse software is installed and updated. Check if the DPI button is functioning or if the profile switch is set to the desired profile.
- **Charging issues:** Try a different USB-C cable or USB port. Ensure the charging cable is fully inserted into both the mouse and the power source.

9. SPECIFICATIONS

Feature	Specification
---------	---------------


Model	Pusat Ghost Pro
Weight	54 grams
Sensor	PixArt PAW3395 Optical Sensor
DPI Range	Up to 26,000 DPI (Adjustable)
Tracking Speed	650 IPS (Inches Per Second)
Acceleration	50G
Switches	Kailh GM4.0 Mechanical Switches
Switch Lifespan	60 Million Clicks
Connectivity	2.4GHz Wireless, USB-C Wired
Number of Buttons	6 (Programmable)
Skates	100% PTFE
Hand Orientation	Ambidextrous
Rated Voltage	3.7V
Rated Current	6.5mA
Color	White

10. WARRANTY AND SUPPORT

Pusat products are designed for quality and performance. For warranty information, technical support, or customer service inquiries, please refer to the warranty card included with your product or visit the official Pusat website. Keep your proof of purchase for warranty claims.

© 2024 Pusat. All rights reserved.

Related Documents - Ghost Pro

	<p>Pusat One Shot Pro Wireless Gaming Mouse User Manual</p> <p>User manual for the Pusat One Shot Pro Wireless Gaming Mouse, detailing its features, setup, DPI adjustment, RGB lighting effects, and technical specifications. Includes instructions in English, Turkish, German, Spanish, French, and Italian.</p>
---	--

	<p>PUSAT Business Pro Wireless Mouse User Manual</p> <p>Comprehensive user manual for the PUSAT Business Pro Wireless Mouse, covering setup, features, and troubleshooting for 2.4GHz and Bluetooth connectivity.</p>
	<p>PUSAT WAVE ANC Bluetooth Headset User Manual</p> <p>Comprehensive user manual for the PUSAT WAVE ANC Bluetooth Headset, detailing product specifications, setup, Bluetooth pairing, button functions, ANC mode, wired mode, and LED indicator status.</p>
	<p>PUSAT Clutch Gamepad User Manual</p> <p>A comprehensive guide to the PUSAT Clutch Gamepad, detailing its specifications, button layout, setup procedures for various systems (Android, NSW, X-input), turbo functionality, charging, and vibration settings.</p>
	<p>Pusat K3 Pro Mechanical Gaming Keyboard User Manual</p> <p>Comprehensive user manual for the Pusat K3 Pro Mechanical Gaming Keyboard, detailing setup, features, backlighting customization, macro functions, and multimedia controls.</p>
	<p>Pusat Business Pro Steel Keyboard User Manual</p> <p>User manual for the Pusat Business Pro Steel Keyboard, detailing specifications, key features, system requirements, setup, pairing, charging, power management, and troubleshooting.</p>