

Dynacraft 8808-79

Dynacraft 24V Kids Golf Cart (Model 8808-79) Instruction Manual

Your guide to assembly, operation, and maintenance.

1. IMPORTANT SAFETY INFORMATION

Read this entire manual before operating the Dynacraft 24V Kids Golf Cart. Failure to follow instructions may result in serious injury or property damage. Keep this manual for future reference.

- **Adult Supervision Required:** Always supervise children operating the golf cart.
- **Age and Weight Limits:** Suitable for toddlers and kids aged 36 months to 5 years. Maximum weight capacity is not explicitly stated but designed for two riders.
- **Use Seatbelts:** Ensure all riders are securely fastened with the provided seatbelts.
- **Safe Operating Environment:** Operate on flat, dry surfaces away from traffic, pools, or steep inclines.
- **Footwear:** Always wear closed-toe shoes when operating the vehicle.
- **Remote Control:** Parents can use the remote control for added safety and control, especially for younger children.

2. SETUP AND ASSEMBLY

Carefully unpack all components and ensure all parts are present before beginning assembly. Refer to the assembly video for detailed visual instructions.

2.1 Unboxing and Parts Check

Before assembly, verify that all components listed in the packing list are included and undamaged. If any parts are missing or damaged, contact customer support.

- Main vehicle body
- Wheels (4)
- Steering wheel
- Seats (2) with seatbelts
- Roof/Canopy supports and canopy
- Golf accessories (balls, clubs, scorecard, dry erase marker, pretend sand bottle)
- Parental remote control
- Charger
- Assembly hardware (screws, washers, nuts)

2.2 Assembly Video Guide

Watch this video for a step-by-step guide on assembling your Dynacraft Kids Golf Cart. Although the video title mentions 12V, the assembly process is generally similar for 24V models.

Your browser does not support the video tag.

Video: 12V 7AH Ride on Golf Car Assembly Steps Guide. This video demonstrates the assembly process for a ride-on golf car, which is similar to the Dynacraft 24V Kids Golf Cart.

2.3 Key Assembly Steps (Visuals)

Below are visual aids for key assembly components and features.



REALISTIC DESIGN

Press the horn for authentic golf cart beeps, and enjoy real golf details like a scorecard with marker and sand bottle for a true course experience!

Realistic Design: The steering wheel features a functional horn and a scorecard with a dry erase marker for an authentic golf experience.



TWO-SEATER DESIGN

Spacious seating fits two riders comfortably, complete with seatbelts for a secure and smooth ride—perfect for cruising in style!

Two-Seater Design: Spacious seating for two riders, complete with seatbelts for safety and comfort.



REAL GOLF ACCESSORIES

Includes golf clubs and plastic golf balls,
—everything young golfers need for a realistic
and fun day on the course!

Real Golf Accessories: Includes golf clubs, plastic golf balls, and a pretend sand bottle for imaginative play.



REMOTE CONTROL

Parents can take charge with the included remote, ensuring every cruise stays safe, smooth, and under control.

Parental Remote Control: The included remote allows parents to control the golf cart's steering and speed for enhanced safety.

3. OPERATING INSTRUCTIONS

Familiarize yourself with the controls before allowing children to operate the golf cart.

3.1 Basic Controls

- **Power Button:** Located on the dashboard. Press to turn the vehicle ON/OFF.
- **Foot Pedal:** Press the foot pedal for acceleration. Release to brake.
- **Steering Wheel:** Turn left or right to steer the vehicle.
- **Speed Settings:** The vehicle has multiple speed settings (e.g., low and high speed, up to 5 MPH). Select the appropriate speed for the child's skill level and environment.
- **Forward/Reverse:** Use the gear selector to switch between forward and reverse modes.

3.2 Parental Remote Control

The remote control allows parents to override manual controls for safety. Ensure the remote is paired with the vehicle according to the instructions provided in the remote control manual.

- **Forward/Backward:** Control the vehicle's movement.
- **Left/Right:** Control the steering.
- **Speed Selection:** Adjust the speed remotely.
- **Emergency Stop:** A dedicated button on the remote can stop the vehicle immediately.

3.3 Multimedia Features

The golf cart includes built-in music and sound effects. Some models may offer Bluetooth connectivity or USB/AUX inputs for external audio devices.

Your browser does not support the video tag.

Video: How to Play with R9. This video demonstrates the operation and features of the golf cart, including driving and music.

4. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and safe operation of your golf cart.

4.1 Battery Charging

- **Initial Charge:** Charge the battery for 8-12 hours before first use. Do not charge for more than 18 hours.
- **Regular Charging:** Recharge after each use. Charging time is typically 8-12 hours.
- **Charger Connection:** Plug the charger into the designated charging port on the vehicle, then into a standard wall outlet.
- **Battery Indicator:** Monitor the battery indicator on the dashboard to check charge level.

4.2 General Care

- **Cleaning:** Wipe the vehicle with a damp cloth. Do not use abrasive cleaners or submerge in water.
- **Storage:** Store in a dry, cool place away from direct sunlight. If storing for extended periods, charge the battery monthly.
- **Inspection:** Regularly check for loose screws, damaged wires, or worn parts.

5. TROUBLESHOOTING

If you encounter issues, try these common solutions before contacting customer support.

- **Vehicle Not Moving:**
 - Check battery charge.
 - Ensure all electrical connections are secure.
 - Verify the power switch is ON.
 - Check if the remote control is active and not overriding manual controls.

- **Slow Operation:**

- Battery may be low; recharge fully.
- Operating on an incline or rough terrain.
- Vehicle may be overloaded (exceeding weight capacity).

- **Remote Control Not Working:**

- Check batteries in the remote control.
- Ensure the remote is properly paired with the vehicle.


6. SPECIFICATIONS

Feature	Detail
Brand	Dynacraft
Model Number	8808-79
Battery	24V
Max Speed	Up to 5 MPH
Recommended Age	36 months - 5 years
Product Dimensions	51.97 x 28.74 x 41.34 inches
Item Weight	63.5 pounds
Seating Capacity	2 riders
Features	Foot pedal acceleration, Parental remote control, Mini golf play accessories (balls, clubs, scorecard, dry erase marker, pretend sand bottle)

7. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact Dynacraft customer support.

- **Return Policy:** 30-day easy returns (refund/replacement).
- **Customer Support:** For assistance, contact Dynacraft Wheels customer service.
- **Protection Plans:** Optional 2-Year Protection Plan and Complete Protect plans are available for purchase.



© 2023 Dynacraft. All rights reserved.