

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Country Living](#) /
- › [Country Living 18 Inch Infrared Freestanding Electric Fireplace Stove Heater \(Model QC113RT\) User Manual](#)

## Country Living QC113RT

# Country Living 18 Inch Infrared Freestanding Electric Fireplace Stove Heater (Model QC113RT) User Manual

Brand: Country Living | Model: QC113RT

### IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this electric fireplace heater. Failure to follow these instructions may result in electric shock, fire, or serious injury.

#### General Safety

- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors. This heater is intended for indoor use only.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater has hot parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).

#### Electrical Safety

- Ensure the power outlet voltage matches the rating label on the appliance.
- Do not overload electrical circuits. Avoid using other high-wattage appliances on the same circuit.
- Always unplug the fireplace when not in use or before cleaning.
- Keep the power cord away from heated surfaces.

## PRODUCT OVERVIEW

The Country Living 18 Inch Infrared Freestanding Electric Fireplace Stove Heater provides supplemental zone heating with realistic flame effects. Designed with a durable metal body, this unit offers adjustable flame colors, speeds, and brightness, along with convenient remote control operation.

### Key Features

- **Realistic Flame Effects:** Choose from vibrant orange, calming blue, or a mixed-color 3D flame effect.
- **3-Sided Enlarged View:** Enjoy the flame display from multiple angles with large front and side display panels.
- **Year-Round Versatility:** Operate with or without heat for ambient flame effects in any season.
- **Effortless Control:** Adjust settings including flame, temperature, brightness, and timer via remote control.
- **Easy Assembly:** Minimal assembly required; simply attach the four legs and door handle.
- **Infrared Heating:** Provides efficient supplemental heat for areas up to 400 sq ft.



Figure 1: Front view of the Country Living 18 Inch Electric Fireplace Stove Heater in Black.

# CountryLiving™

## Electric Fireplace Stove Heater

Enjoy realistic flame effects with an optional heat setting for all-season use



Figure 2: The electric fireplace stove heater, highlighting its pet and child-safe design.

Your browser does not support the video tag.

Video 1: An overview of the Country Living brand and its fireplace products, demonstrating features and design.

### SETUP AND ASSEMBLY

The Country Living Electric Fireplace Stove Heater is designed for quick and easy assembly. Follow these steps to set up your unit:

1. Carefully remove all components from the packaging. Ensure all parts are present: main fireplace unit, four legs, door handle, and remote control.
2. Place the main fireplace unit on a soft, non-abrasive surface to prevent scratching during assembly.
3. Attach the four legs to the bottom of the fireplace unit using the provided screws. Ensure they are securely fastened.
4. Attach the minimalist door handle to the fireplace door.
5. Position the assembled fireplace on a firm, level surface, away from drapes, furniture, and high-traffic areas. Ensure there is adequate clearance around the unit for proper ventilation.
6. Plug the power cord directly into a grounded 120V AC outlet. Do not use extension cords or power strips.

Your freestanding fireplace is now ready to operate.

# Elevate Your Space Instantly

Designed for ultimate comfort



Energy Efficient



Easy Assembly



Quiet Operation



Multiple Heat Settings



20.8"

16.9"

10"

Figure 3: Product dimensions for placement and assembly reference. The unit measures 10"D x 16.9"W x 20.8"H.

## OPERATING INSTRUCTIONS

The electric fireplace can be operated using the control panel on the unit or the included remote control.

### Control Panel and Remote Control

The control panel is located on the unit, typically behind the door or on the front face. The remote control provides convenient access to all functions from a distance.



Figure 4: Illustration of the handheld remote control and the digital control panel on the fireplace unit, showing various settings.

### Functions:

- **Power (On/Off):** Press the power button to turn the unit on or off.
- **Flame Effect:**
  - **Flame Color:** Cycle through available flame colors (e.g., orange, blue, mixed) by pressing the flame color button.
  - **Flame Speed:** Adjust the speed of the flickering flame effect.
  - **Flame Brightness:** Increase or decrease the brightness of the flame display.
- **Heat Settings:**
  - **Temperature:** Set your desired room temperature. The unit will automatically maintain this temperature.
  - **Heat On/Off:** Activate or deactivate the heating function independently of the flame effect.
- **Timer:** Set an automatic shut-off timer from 30 minutes to 9 hours.

Refer to the digital display on the unit for current settings and temperature readings.

### MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your electric fireplace heater.

## Cleaning

- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Glass Panel:** Clean the glass panel with a soft cloth and a non-abrasive glass cleaner.
- **Air Vents:** Periodically vacuum or wipe the air intake and exhaust vents to prevent dust buildup, which can affect heating efficiency.

## Storage

If storing the fireplace for an extended period, unplug it and store it in a cool, dry place, preferably in its original packaging.

**Caution:** Always ensure the unit is unplugged and completely cool before performing any cleaning or maintenance.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	No power, power cord not plugged in, circuit breaker tripped.	Ensure unit is plugged into a live outlet. Check household circuit breaker.
No heat output.	Heat function not activated, thermostat set too low, air vents blocked.	Activate heat function. Increase thermostat setting. Clear any obstructions from air vents.
Flame effect not working.	Flame effect function not activated, LED lights faulty.	Activate flame effect function. If issue persists, contact customer support.
Remote control not working.	Dead batteries, obstruction, remote out of range.	Replace batteries. Ensure no obstructions between remote and unit. Operate within recommended range.
Unit is making unusual noise.	Dust buildup in fan, loose components.	Clean air vents. If noise persists or is severe, discontinue use and contact customer support.

## SPECIFICATIONS

- **Brand:** Country Living
- **Model Name:** CL-18-BLK
- **Item Model Number:** QC113RT
- **ASIN:** B0DHT6TPF4
- **Power Source:** Corded Electric
- **Product Dimensions:** 10"D x 16.9"W x 20.8"H
- **Material:** Metal
- **Finish Type:** Painted
- **Installation Type:** Freestanding
- **Heat Output:** 5000 British Thermal Units (BTU)
- **Special Features:** Corded, Digital Thermostat, Flame Technology, Flame customization, Multifunction Remote Control
- **Color:** Black

- **Ventilation Type:** Vent Free
- **Heating Coverage:** 400 sq ft
- **Included Components:** Digital Thermostat, Flame customization, Realistic logs, Remote Control, Timer
- **Item Weight:** 23 pounds
- **UPC:** 810116826339

## **WARRANTY AND SUPPORT**

This Country Living Electric Fireplace Stove Heater comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product or contact Country Living customer support.

For technical assistance, parts replacement, or any other inquiries, please contact the manufacturer, Country Living, directly. Contact information can typically be found on the product packaging or their official website.