

LITBLOOM JT-DC035V0450-C

LITBLOOM 4FT Lighted Pine Christmas Tree with Timer

Model: JT-DC035V0450-C

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for purchasing the LITBLOOM 4FT Lighted Pine Christmas Tree. This manual provides important information regarding the assembly, operation, maintenance, and safety of your new lighted tree. Please read it thoroughly before use and retain it for future reference.

This elegant pre-lit pine tree features 36 warm white LED lights and a timer function, designed for both indoor and covered outdoor holiday decoration.

2. IMPORTANT SAFETY INFORMATION

- Read all instructions before use.
- Do not connect the tree to power while it is still in its packaging.
- Ensure the power adapter is suitable for your local voltage.
- Keep away from heat sources, open flames, and water (unless specified for outdoor use).
- Do not attempt to modify or repair the product. Contact customer support for assistance.
- Unplug the tree from the power outlet when not in use or before cleaning.
- This product is rated IP44 waterproof for covered outdoor use. Avoid direct exposure to heavy rain or snow.
- Keep out of reach of children and pets.

3. PACKAGE CONTENTS

Please check to ensure all components are present:

- Lighted Pine Tree (4FT)

- Tree Base
- Power Adapter with Timer Function
- Ground Stakes (4 pieces)

4. SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Assemble the Base:** Place the tree base on a flat, stable surface.
3. **Insert Tree into Base:** Gently insert the bottom pole of the tree into the opening in the tree base. Ensure it is securely seated.
4. **Shape the Branches:** The branches are flexible. Carefully spread and shape them to achieve your desired full and natural appearance. The pre-strung lights are integrated with invisible wiring.
5. **Connect Power:** Plug the power adapter into the tree's power input. Then, plug the adapter into a standard electrical outlet.
6. **Outdoor Installation (Optional):** If using outdoors in a covered area, use the provided ground stakes to secure the tree base to the ground for added stability.



Image: The 4FT lighted pine tree with its power adapter, illustrating the connection point.



Image: A close-up view of the sturdy brown tree base, designed for stability.

5. OPERATING INSTRUCTIONS

Power On/Off

Once plugged into a power outlet, the tree lights will illuminate. To turn off, simply unplug the power adapter from the outlet.

Timer Function

The integrated power adapter includes a timer function. When the tree is plugged in, the timer will automatically activate, setting the lights to be ON for 6 hours and OFF for 18 hours. This cycle will repeat daily. There is no manual setting required for the timer; it begins when power is supplied.



Image: A detailed view of the pine tree branches adorned with warm white LED lights.

6. MAINTENANCE

Cleaning

- Always unplug the tree before cleaning.
- Wipe the tree and base with a soft, dry cloth.
- Do not use harsh chemicals or abrasive cleaners.

Storage

- Ensure the tree is completely dry before storing.
- Gently compress the branches back towards the main pole.
- Store the tree in its original packaging or a suitable storage bag in a cool, dry place, away from direct sunlight.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	Not plugged in; power outage; faulty connection.	Ensure the power adapter is securely plugged into both the tree and a working electrical outlet. Check the power source.

Problem	Possible Cause	Solution
Tree is unstable.	Base not properly assembled; uneven surface.	Ensure the tree pole is fully inserted into the base. Place the tree on a flat, level surface. Use ground stakes for outdoor stability.
Timer function not working.	Incorrect power cycle.	The timer starts its 6-hour ON / 18-hour OFF cycle from the moment it is plugged in. To reset the cycle, unplug the tree and plug it back in at your desired ON time.

8. SPECIFICATIONS

Feature	Detail
Model Number	JT-DC035V0450-C
Height	4FT (48 inches)
Product Dimensions	20"D x 20"W x 48"H
Number of LED Lights	36
Light Color	Warm White
Material	Plastic (Pine Tree)
Waterproof Rating	IP44 (for covered outdoor use)
Special Features	Bendable Branches, Prelit, Timer Function (6 hours ON / 18 hours OFF)
Power Source	Plug-in (Adapter Included)
Item Weight	3.64 pounds

9. WARRANTY & SUPPORT

LITBLOOM products are manufactured with quality and care. For any questions, concerns, or warranty inquiries, please contact LITBLOOM customer support through the retailer's platform or the official LITBLOOM website. Please have your model number (JT-DC035V0450-C) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question