Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

allimity AH59-02360A AH5902360A

Allimity AH59-02360A Replacement Remote Control User Manual

Model: AH59-02360A AH5902360A | Brand: allimity

1. Introduction

This user manual provides comprehensive instructions for the Allimity AH59-02360A Replacement Remote Control. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your remote. Please read this manual carefully before using the product.

2. Product Overview

The Allimity AH59-02360A is a replacement infrared remote control designed for compatibility with various Samsung TV models, including HT-D350, HT-D355, HTD350, and HTD355. It offers a straightforward solution for controlling your compatible Samsung home theater system or television.

Key Features:

- Direct replacement for original AH59-02360A remote.
- Compatible with Samsung TV models HT-D350, HT-D355, HTD350, HTD355.
- Infrared (IR) technology for reliable communication.
- Ergonomic design for comfortable handling.
- No programming required; works immediately after battery installation.

Product Images:



Figure 2.1: Front view of the Allimity AH59-02360A remote control, displaying its full button layout including power, function, numeric keypad, navigation, and media controls.



Figure 2.2: Angled view of the remote control, highlighting its ergonomic shape and button accessibility.



Figure 2.3: A different angled perspective of the remote, emphasizing its compact design.



Figure 2.4: Rear view of the remote control with the battery cover open, revealing the compartment for two AAA batteries.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control. Refer to Figure 2.4 for assistance.
2. Slide the battery cover downwards or press the latch and lift to open the compartment.
3. Insert two new AAA alkaline batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside.
4. Replace the battery cover by sliding it back into place until it clicks securely.

The remote control is now ready for use. No additional programming or pairing is required.

4. Operating Instructions

To operate your device using the Allimity AH59-02360A remote control, ensure there are no obstructions between the remote and the infrared sensor on your Samsung TV or home theater system.

4.1 Basic Operation

- **Aiming:** Always point the remote control directly towards the infrared sensor on your Samsung device.
- **Distance:** For optimal performance, operate the remote within a reasonable distance (typically up to 7 meters or 23 feet) from your device.
- **Button Functions:** Press the corresponding buttons for desired functions such as power on/off, volume control, channel selection, menu navigation, and input source selection. The button layout is intuitive and mirrors the original remote's functionality.

4.2 Compatibility

This remote control is specifically designed to be compatible with the following Samsung models:

- HT-D350
- HT-D355
- HTD350
- HTD355

If your device model is not listed, please contact customer support for assistance before purchasing or using the remote.

5. Maintenance

Proper maintenance ensures the longevity and reliable operation of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or immerse the remote in water.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new alkaline batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote. Store in a cool, dry place.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

6. Troubleshooting

If you experience issues with your Allimity AH59-02360A remote control, please refer to the following common troubleshooting steps:

1. **Remote Not Responding:**
    - Ensure new alkaline batteries are correctly installed with proper polarity (+/-).
    - Replace old batteries with fresh ones.
    - Check for any obstructions between the remote and the device's IR sensor.
    - Ensure you are pointing the remote directly at the device's IR sensor.
2. **Limited Range:**
    - Replace batteries, as low battery power can reduce range.
    - Ensure there are no strong light sources (like direct sunlight or fluorescent lights) interfering with the IR signal.
3. **Specific Buttons Not Working:**

- Clean the remote's surface and buttons to ensure no debris is preventing button presses.
- If only certain buttons fail, it might indicate internal damage. Consider contacting support.

If the problem persists after trying these steps, please contact customer support for further assistance.

7. Specifications

Attribute	Detail
Brand	allimity
Model	AH59-02360A AH5902360A
Compatible Devices	Samsung TV (HT-D350, HT-D355, HTD350, HTD355)
Connectivity Technology	Infrared (IR)
Material	Plastic Electronic
Product Dimensions (LxWxH)	15 x 5 x 1 cm
Item Weight	70 g
Batteries Required	Yes (2 x AAA, not included)
Special Features	Ergonomic
Color	Black
Country of Origin	China

8. Warranty and Support

8.1 Product Support

For any questions regarding compatibility, functionality, or if you encounter issues with your Allimity AH59-02360A replacement remote control, please contact the seller or manufacturer directly. They can provide specific guidance and assistance.
If your device model number is not explicitly listed as compatible, it is recommended to verify compatibility with the seller before purchase or use.

8.2 Warranty Information

Specific warranty terms for this replacement remote control are typically provided by the seller at the time of purchase. Please refer to your purchase documentation or contact the seller for detailed warranty information.

© 2024 Allimity. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHTKBFRS

More documents and user manuals: **https://manuals.plus/**