



Manuals.plus /

› **Jpbaisqic /**

› Instruction Manual: Replacement Accessories Kit for Lubluelu L20 Robot Vacuum Cleaner

Jpbaisqic Compatible With Lubluelu L20

Instruction Manual: Replacement Accessories Kit for Lubluelu L20 Robot Vacuum Cleaner

Brand: Jpbaisqic | Model: Compatible With Lubluelu L20

INTRODUCTION

This manual provides detailed instructions for the installation, maintenance, and care of the Jpbaisqic Replacement Accessories Kit for the Lubluelu L20 Robot Vacuum Cleaner. This kit is designed to help maintain the optimal performance of your robot vacuum by providing essential replacement parts.



Figure 1: Complete Replacement Accessories Kit for Lubluelu L20 Robot Vacuum Cleaner.

PACKAGE CONTENTS

The replacement kit includes the following components:

- 1 x Main Brush Roller
- 4 x Side Brushes
- 4 x HEPA Filters
- 2 x Mop Pads

COMPATIBILITY

This accessory kit is specifically designed for and compatible with the **Lubluelu L20 Robot Vacuum Cleaner**.

INSTALLATION GUIDE

Follow these steps to replace the components in your Lubluelu L20 Robot Vacuum Cleaner.

1. Main Brush Roller Installation

The main brush is made of high-quality rubber and brush materials, designed for effective cleaning with low noise. To replace:

1. Turn the robot vacuum cleaner upside down.
2. Locate the main brush cover, usually secured by latches or screws.
3. Open or remove the cover.
4. Lift out the old main brush roller.
5. Insert the new main brush roller into its slot, ensuring the ends align with the corresponding openings.
6. Close or reattach the main brush cover securely.



Figure 2: Main Brush Roller.

2. Side Brush Installation

The side brushes are durable and made of rubber, designed to reach deep into corners and edges. To replace:

1. Turn the robot vacuum cleaner upside down.
2. Locate the side brushes. They are typically held in place by a single screw or snap mechanism.
3. Remove the screw (if present) or gently pull the old side brush upwards to detach it.
4. Align the new side brush with the corresponding post on the robot.
5. Press down firmly or reattach the screw to secure the new side brush in place.

Accessories Kit for Lubluelu L20

Replacement Parts Lubluelu L20 Robot Vacuum Cleaner

Side Brushes

Heavy-Duty Side Brush Collect More Trash in Corners




Figure 3: Side Brushes.

3. HEPA Filter Installation

The HEPA filters are designed for efficient filtration, capturing up to 99% of dust, particles, and pet hair. To replace:

1. Open the dustbin compartment on your robot vacuum cleaner.

2. Remove the dustbin.
3. Locate the filter assembly within the dustbin.
4. Remove the old HEPA filter.
5. Insert the new HEPA filter into the designated slot, ensuring it fits snugly.
6. Reinsert the dustbin into the robot vacuum cleaner and close the compartment.

Washable and Reusable

Simply rinse with clean water and completely air dry before reusing filters.



Replacement Parts fit For Lubluelu L20

Figure 4: HEPA Filter.

4. Mop Pad Installation

The mop pads are made from a selection of microfibers, designed not to scratch the floor and suitable for various hard floor types. To attach:

1. Locate the mop pad attachment area on the underside of the robot vacuum cleaner or its water tank.
2. Align the new mop pad with the hook-and-loop fasteners or clips on the attachment area.
3. Press the mop pad firmly onto the fasteners to secure it in place.

Washable and Reusable

can be washed with water, so you
can increase the frequency of use



Figure 5: Mop Pads.

MAINTENANCE AND CARE

Regular maintenance of your replacement parts ensures your robot vacuum operates at peak performance and extends the lifespan of the components.

General Replacement Schedule

It is recommended to replace the kits every 3-6 months, depending on the frequency of use. For heavy usage, replacement may be needed sooner.

Cleaning the Main Brush Roller

Periodically remove hair and debris tangled around the main brush. Use the cleaning tool provided with your robot vacuum to cut and remove tangled hair. The main brush can also be rinsed with water if heavily soiled, but ensure it is completely dry before reinstallation.

Cleaning the Side Brushes

Remove any tangled hair or debris from the side brushes. If a side brush becomes bent or curly due to transportation or use, soak it in warm water for a few seconds to help it recover its original shape. Ensure they are dry before reattaching.

Cleaning the HEPA Filters

The HEPA filters are washable and reusable. To clean:

1. Remove the filter from the dustbin.
2. Tap the filter gently over a trash can to remove loose dust.
3. Rinse the filter under clean running water.
4. Allow the filter to air dry completely for at least 24 hours before reinstalling. Do not use a dryer or direct heat.

Cleaning the Mop Pads

The mop pads are washable and reusable. After each use, remove the mop pad and rinse it with clean water. For deeper cleaning, they can be machine washed with similar colors. Allow them to air dry completely before reattaching to the robot.

TROUBLESHOOTING

Bent or Curly Side Brush

If you receive a side brush that appears bent or curly due to packaging or transportation, simply soak it in warm water for approximately 10-15 seconds. This will help the rubber material regain its original shape. Allow it to cool and dry before installation.

SPECIFICATIONS

Feature	Detail
Model Number	Compatible With Lubluelu L20
Package Dimensions	7 x 3 x 2 inches
Item Weight	9.6 ounces
Manufacturer	JIN PENG
ASIN	B0DHTTHFDY
Batteries Required	No

WARRANTY AND SUPPORT

For any issues encountered after purchase or during use, please contact the seller's after-sales team via email. They aim to reply and resolve your problems within 24 hours.

Please refer to your original product purchase documentation for specific warranty terms and conditions.

