

Mycket ed2ccd90-ce69-49a9-84f2-6062ffe31d1e

Mycket Portable DAB/DAB+ and FM Radio User Manual

Model: ed2ccd90-ce69-49a9-84f2-6062ffe31d1e

1. INTRODUCTION

Thank you for choosing the Mycket Portable DAB/DAB+ and FM Radio. This device offers a superior audio experience with its versatile connectivity options, including DAB/DAB+ digital radio, traditional FM radio, Bluetooth 5.0 for wireless streaming, and USB playback. Its compact design and built-in rechargeable battery make it ideal for use at home or on the go. This manual will guide you through the setup, operation, and maintenance of your new radio.

2. PACKAGE CONTENTS

Please check the box for the following items:

- 1 x Mycket Portable DAB/DAB+ and FM Radio
- 1 x USB Power Cable (Type-C)
- 1 x User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your Mycket radio.






Figure 3.1: Front view of the Mycket Portable DAB/DAB+ and FM Radio, showing the LED display and control knobs.

Controls and Ports:

- **Power/Mode Knob:** Turn to power on/off, press to switch between DAB, FM, Bluetooth, and USB modes.
- **Tuning/Select Knob:** Rotate to tune stations or navigate menus, press to confirm selections.

- **Preset Buttons (FAV1/2/3):** Quick access to your favorite stored stations.
- **LED Display:** Shows station information, time, mode, and battery status.
- **Telescopic Antenna:** Extend for optimal radio reception.
- **USB-C Charging Port (DC 5V):** For charging the internal battery.
- **USB-A Port:** For playing MP3 files from a USB flash drive.
- **3.5mm AUX Out (Headphone Jack):** For private listening with headphones.

Personal Listening

Enjoy a private audio experience when you connect your headphones via the 3.5mm AUX Out port



Figure 3.2: Detailed view of the USB and 3.5mm AUX Out ports on the Mycket radio, demonstrating headphone connectivity.

4. SETUP

4.1 Charging the Battery

The radio comes with a built-in 2200 mAh rechargeable battery, providing up to 12 hours of listening time on a single charge.

1. Connect the supplied USB Type-C cable to the DC 5V charging port on the radio.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a powered USB port.
3. The LED display will indicate charging status. The battery icon will show full when charging is complete.

USB Rechargeable & 2200mAh Battery Powered

Built-in 2200mAh battery for up to 12 hours of listening, perfect for use at home or on the trip



Figure 4.1: The Mycket radio being charged via its USB-C port, indicating its rechargeable battery feature.

4.2 Initial Power On

To power on the radio, rotate the Power/Mode knob clockwise. The display will light up, and the radio will enter the last used mode.

5. OPERATING INSTRUCTIONS

5.1 Mode Selection

Press the Power/Mode knob repeatedly to cycle through the available modes: DAB, FM, Bluetooth, and USB.

5.2 DAB/DAB+ Radio Operation

Extend the telescopic antenna fully for best reception.

1. Switch to DAB mode.
2. **Automatic Scan:** The radio will automatically perform a full scan for available DAB/DAB+ stations upon first use or if no stations are found. To initiate a manual scan, press and hold the Tuning/Select knob.
3. **Station Selection:** Rotate the Tuning/Select knob to browse through the list of available stations. Press the knob to select a station.
4. **Storing Presets:** The radio supports up to 40 DAB presets. To store a station, tune to the desired station, then press and hold one of the FAV1/2/3 buttons until the display confirms the preset is saved. For other presets, navigate to the preset menu and follow on-screen instructions.
5. **Recalling Presets:** Briefly press FAV1/2/3 for quick access. For other presets, navigate to the preset list and select.

80 Preset Stations

Store up to 80 of your favorite stations for easy recall.
Select them instantly using the PRESET
Buttons(40 DAB & 40 FM)



Figure 5.1: The Mycket radio's display showing station information, highlighting its capacity for 80 preset stations (40 DAB & 40 FM).

5.3 FM Radio Operation

Extend the telescopic antenna fully for best reception.

1. Switch to FM mode.
2. **Automatic Scan:** Press and hold the Tuning/Select knob to automatically scan and store available FM stations.
3. **Manual Tuning:** Briefly rotate the Tuning/Select knob to fine-tune the frequency.
4. **Storing Presets:** The radio supports up to 40 FM presets. To store a station, tune to the desired station, then press and hold one of the FAV1/2/3 buttons until the display confirms the preset is saved. For other presets, navigate to the preset menu and follow on-screen instructions.
5. **Recalling Presets:** Briefly press FAV1/2/3 for quick access. For other presets, navigate to the preset list and select.

5.4 Bluetooth Operation

The radio features Bluetooth 5.0 for wireless audio streaming.

1. Switch to Bluetooth mode. The display will show "Bluetooth" or a pairing indicator.
2. On your external device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "Mycket Radio" from the list to pair. Once connected, the display will confirm the connection.
4. You can now stream audio from your device to the radio.

5.5 USB Playback

The radio supports MP3 playback from a USB flash drive.

1. Insert a USB flash drive containing MP3 files into the USB-A port.
2. Switch to USB mode. The radio will automatically detect and begin playing the first compatible audio file.
3. Use the Tuning/Select knob to navigate through tracks.

5.6 Headphone Use

For private listening, connect any standard 3.5mm headphones to the AUX Out port on the radio. The internal speaker will automatically mute when headphones are connected.

5.7 Standby Timer

The radio includes a standby timer function. Refer to the on-screen menu options for setting the desired sleep duration.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Mycket radio, follow these maintenance guidelines:

- **Cleaning:** Wipe the radio with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. If storing the radio for an extended period, charge it to about 50% and recharge every few months.
- **Environment:** Keep the radio away from direct sunlight, extreme temperatures, high humidity, and dusty environments.
- **Antenna:** Handle the telescopic antenna with care to prevent bending or breaking.

7. TROUBLESHOOTING

If you encounter any issues with your radio, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Radio does not power on.	Battery is depleted.	Connect the radio to a power source using the USB cable and allow it to charge.
Poor DAB/FM reception.	Antenna not extended or weak signal area.	Fully extend the telescopic antenna. Try repositioning the radio or moving to an area with better signal coverage. Perform a new auto-scan.
Bluetooth device not pairing.	Radio not in Bluetooth mode or device too far.	Ensure the radio is in Bluetooth mode. Move your device closer to the radio (within 10 meters). Ensure no other device is currently connected to the radio.
USB playback not working.	USB drive not inserted correctly or unsupported file format.	Ensure the USB drive is fully inserted. Verify that the audio files are in MP3 format. Try a different USB drive.
No sound from speaker.	Volume too low or headphones connected.	Increase the volume. Check if headphones are plugged into the 3.5mm jack; unplug them if not needed.

8. SPECIFICATIONS

Feature	Specification
Radio Tuner	DAB/DAB+, FM
Bluetooth Version	5.0
Preset Stations	80 (40 DAB, 40 FM)
USB Playback	MP3 files via USB-A port
Display	2-inch LED screen
Speaker Output	6W Internal Magnetic Speaker
Battery	Built-in 2200 mAh (3.7V - 2.2Ah) rechargeable Lithium-ion
Battery Life	Up to 12 hours (approx.)
Power Supply	DC 5V via USB-C
Headphone Output	3.5mm AUX Out Jack
Dimensions (L x W x H)	8.7 x 8.7 x 13 cm
Weight	610 g

6W Internal Magnetic Speaker

Provide you better bass music with its powerful 6W built in speakers.






Figure 8.1: Diagram illustrating the 6W internal magnetic speaker of the Mycket radio.

9. WARRANTY AND SUPPORT

Mycket is committed to providing high-quality products and customer satisfaction. This product comes with a 12-month coverage period from the date of purchase. For any inquiries, technical assistance, or support, please contact our customer service team. We offer 24/7 customer service to ensure a worry-free experience.

© 2024 Mycket. All rights reserved.

Related Documents - ed2ccd90-ce69-49a9-84f2-6062ffe31d1e

<div><p>Portable DAB+ / FM Radio User Manual</p><p>ENG User manual FRA Manuel de l'utilisateur ITA Manuale d'uso</p><p>DEU Benutzerhandbuch NLD Handleiding</p><p><small>Please read this user manual completely before operating the unit and when the product is under warranty.</small></p></div>	<div><p>Portable DAB+ / FM Radio User Manual - Operation and Specifications</p><p>Comprehensive user manual for the mycket Portable DAB+ / FM Radio with Bluetooth. Includes setup, operation, system settings, specifications, and troubleshooting.</p></div>															
<div><p>Portable DAB+ / FM Radio User Manual</p><p>ENG User manual FRA Manuel de l'utilisateur ITA Manuale d'uso</p><p>DEU Benutzerhandbuch NLD Handleiding</p><p><small>Please read this user manual completely before operating the unit and when the product is under warranty.</small></p></div>	<div><p>Mycket Portable DAB/FM Radio User Manual</p><p>Comprehensive user manual for the Mycket Portable DAB/FM Radio, covering setup, operation, features like Bluetooth connectivity, alarms, FM/DAB tuning, and specifications.</p></div>															
<div><p> Lyreco</p><p>REACH DECLARATION FOR SVHC (Substances of Very High Concern)</p><p>Information enligt REACH (artikel 33)</p><p><small>Lyreco, the Lyreco logo and the Lyreco name are registered trademarks of Lyreco Ltd. in the UK and other countries. All other trademarks are the property of their respective owners. The information provided in this document is for informational purposes only and does not constitute a warranty. The information is subject to change without notice. The information is provided as is, without any warranty, express or implied. The information is provided on an "as is" basis and is not intended to be used for any purpose other than for informational purposes only. The information is provided for informational purposes only and is not intended to be used for any purpose other than for informational purposes only.</small></p><table><thead><tr><th>Substance</th><th>Product description</th><th>Concentration</th><th>Use</th><th>SCIP number</th></tr></thead><tbody><tr><td>1000000000000000000</td><td>Mycket Portable DAB/FM Radio</td><td>0.1% - 100%</td><td>Radio</td><td>1000000000000000000</td></tr><tr><td>1000000000000000000</td><td>Mycket Portable DAB/FM Radio</td><td>0.1% - 100%</td><td>Radio</td><td>1000000000000000000</td></tr></tbody></table><p><small>© 2015 Lyreco Ltd. All rights reserved. No part of this publication may be reproduced without prior written permission from Lyreco Ltd.</small></p></div>	Substance	Product description	Concentration	Use	SCIP number	1000000000000000000	Mycket Portable DAB/FM Radio	0.1% - 100%	Radio	1000000000000000000	1000000000000000000	Mycket Portable DAB/FM Radio	0.1% - 100%	Radio	1000000000000000000	<div><p>Lyreco REACH Deklaration för SVHC (Substances of Very High Concern)</p><p>Lyreco REACH Deklaration för Ämnen av Mycket Hög Oro (SVHC) enligt Artikel 33. Listar produkter som innehåller SVHC-ämnena över 0,1% koncentration, inklusive artikelnummer, produktbeskrivningar, SVHC-namn, CAS-nummer och SCIP-nummer. Ger en länk till ECHA SCIP-databasen för ytterligare information.</p></div>
Substance	Product description	Concentration	Use	SCIP number												
1000000000000000000	Mycket Portable DAB/FM Radio	0.1% - 100%	Radio	1000000000000000000												
1000000000000000000	Mycket Portable DAB/FM Radio	0.1% - 100%	Radio	1000000000000000000												