

[Manuals.plus](#) /

› [TOZO](#) /

› TOZO OpenEarRing Wireless Earbuds User Manual

TOZO OpenEarRing T13064

TOZO OpenEarRing Wireless Earbuds User Manual

Model: OpenEarRing T13064

1. INTRODUCTION

Thank you for choosing the TOZO OpenEarRing Wireless Earbuds. These innovative clip-on earbuds are designed for supreme comfort and a secure fit, allowing you to enjoy high-quality audio while remaining aware of your surroundings. With advanced Bluetooth 5.4 connectivity and a long-lasting battery, they are perfect for sports, daily commutes, and extended listening sessions.

Key Features:

- **Supremely Comfortable Ultra-Light Design:** Weighing only 5.1g per earbud, offering a pressure-free listening experience.
- **Digital Display & 40 Hours Playtime:** Up to 10 hours on a single charge, with an additional 30 hours from the charging case.
- **Intuitive Touch Controls:** Easily manage calls and music with simple touch gestures.
- **IPX5 Water Resistance:** Nanometric protective coating protects against sweat and rain, ideal for outdoor activities.
- **Skin-Friendly Silicone:** Made with ambient silicone for comfortable, long-term wear without irritation.

2. WHAT'S IN THE BOX

Please check the contents of your package:

- TOZO OpenEarRing Earbuds (Left and Right)
- Wireless Charging Case
- USB-C to USB-A Charging Cable
- User Manual and Quick Guide

3. PRODUCT OVERVIEW



Image: The TOZO OpenEarRing earbuds and their charging case, showcasing their unique clip-on design and compact form factor.



All-Day Comfort, Effortless Listening

Enjoy a comfortable listening experience with our innovative ear ring design. It sits gently outside the ear, providing a secure and snug fit for all-day wear.

Image: A person comfortably wearing the TOZO OpenEarRing earbuds, demonstrating their secure and unobtrusive fit for all-day comfort.

SmartPow Technology

Exclusive algorithms for precise power control, paired with a low-power chip and an HD display.



Image: The TOZO OpenEarRing charging case with its smart digital display, showing the battery percentage for both the case and individual earbuds.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case features a digital display to show the battery level.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer's USB port.
3. The digital display on the case will show the charging status. A full charge provides up to 40 hours of total playtime (10 hours from earbuds + 30 hours from case).

40-Hour Battery Power

Keep the music going with an impressive 40-hour battery life, so you can enjoy your tunes all day without recharging worries.



**HOUR
PLAYTIME**

10 Hours From a Single Charge

Image: A visual representation of the TOZO OpenEarRing's impressive 40-hour battery life, highlighting 10 hours from a single earbud charge and additional power from the charging case.

4.2 Pairing with Your Device

The earbuds will automatically enter pairing mode when taken out of the charging case.

1. Open the charging case and take out both earbuds. They will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "TOZO OpenEarRing" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
5. If pairing fails, place the earbuds back into the case, close the lid, wait a few seconds, and then repeat the steps.

5. OPERATING INSTRUCTIONS

5.1 Wearing the Earbuds

The TOZO OpenEarRing earbuds are designed to clip securely and comfortably onto your ear, sitting outside the ear canal.

1. Gently open the clip of the earbud.
2. Position the earbud over your ear, ensuring the speaker part is aligned with your ear canal opening, but not inserted into it.
3. Release the clip so it gently secures the earbud to your outer ear. Adjust for a comfortable and stable fit.

Adaptive for Every Moment

Whether at work, during workouts, or on the go, the TOZO Open EarRing seamlessly adapts to your environment, letting you enjoy your music while staying aware of your surroundings.


The image is a composite of three photographs. The top photograph shows a young man with dark, curly hair wearing a white t-shirt and a white TOZO OpenEarRing earbud, looking off to the side. The bottom-left photograph shows a young woman with blonde hair wearing a light blue button-down shirt and a white TOZO OpenEarRing earbud, smiling while holding a brown paper coffee cup. The bottom-right photograph shows a young woman with blonde hair in a ponytail wearing a blue tank top and a white TOZO OpenEarRing earbud, looking forward.

Image: Three individuals demonstrating the versatility of TOZO OpenEarRing earbuds during work, exercise, and casual listening, highlighting their adaptive design for every moment.

5.2 Touch Controls

The TOZO OpenEarRing earbuds feature intuitive touch controls on each earbud. The specific functions may vary slightly depending on your device and app settings.

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap

Action	Left Earbud	Right Earbud
Next Track	Double Tap	Double Tap
Previous Track	Triple Tap	Triple Tap
Answer/End Call	Single Tap	Single Tap
Reject Call	Press and Hold (2s)	Press and Hold (2s)
Activate Voice Assistant	Press and Hold (2s)	Press and Hold (2s)

5.3 Sound Quality

Experience captivating sound with powerful bass, crisp vocals, and clear highs. The OpenEarRing design allows for an immersive audio experience while maintaining situational awareness.

Captivating Sound, Powerful Bass

Immerse yourself in rich soundscapes, with deep bass, crisp vocals, and clear highs that bring your favorite tracks to life.



Image: An internal diagram illustrating the acoustic structure of the TOZO OpenEarRing, emphasizing its components designed for powerful bass and clear audio reproduction.

5.4 TOZO App Integration

Enhance your listening experience by connecting your TOZO OpenEarRing earbuds to the TOZO App. The app offers 32 preset EQ settings tailored to different music genres and scenarios, allowing for personalized audio. You can also receive firmware updates through the app.

TOZO APP with 5 Preset EQ

TOZO Open Earring is compatible with TOZO app, and you can choose from 32 preset EQ settings tailored to different music genres, preferences, and scenarios, creating a personalized audio experience.



32 Types of EQ
Sound Modes



Firmware
Updates



Image: Screenshots of the TOZO App interface, showcasing various EQ sound modes, firmware update options, and community features for a customized audio experience.

6. MAINTENANCE

6.1 Cleaning

- Use a soft, dry, lint-free cloth to clean the earbuds and charging case.
- Do not use abrasive cleaners, alcohol, or chemical sprays.
- Ensure the charging contacts on both the earbuds and the case are clean and dry.

6.2 Water Resistance (IPX5)

The TOZO OpenEarRing earbuds are IPX5 water-resistant, meaning they can withstand splashes of water and sweat. They are suitable for workouts and light rain. However, they are not designed for submersion in water or for use during swimming or showering. Ensure the earbuds are dry before placing them back into the charging case to prevent damage.

6.3 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store the case in a cool, dry place away from extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Solution
Earbuds not charging	• Ensure earbuds are correctly seated in the charging case. • Check if the charging cable is securely connected to both the case and the power source. • Verify the charging case has sufficient battery. • Clean the charging contacts on both earbuds and case.
Cannot pair with device	• Ensure Bluetooth is enabled on your device. • Place earbuds back in the case, close, then reopen to re-enter pairing mode. • Forget "TOZO OpenEarRing" from your device's Bluetooth list and try pairing again. • Ensure earbuds are fully charged.
No sound or low volume	• Adjust the volume on both your device and the earbuds. • Ensure earbuds are properly connected to your device. • Try playing different audio sources.
Connection unstable/dropping	• Keep your device within the effective Bluetooth range (typically 10 meters/33 feet) without major obstacles. • Avoid strong electromagnetic interference. • Ensure earbuds are fully charged.

8. SPECIFICATIONS

Feature	Detail
Brand	TOZO
Model Name	Open EarRing
Model Number	T13064
Control Type	Touch Control
Connectivity Technology	Wireless (Bluetooth 5.4)
Wireless Communication Technology	Bluetooth

Feature	Detail
Item Weight	37.7 Grams
Frequency Range	20 Hz - 20,000 Hz
Special Features	Microphone included, IPX5 Water Resistance
Battery Composition	Lithium-ion
Rechargeable Battery	Yes
Total Playtime	Up to 40 hours (with charging case)
Earbud Playtime (single charge)	Up to 10 hours
Charging Time	Approx. 2 hours (for full charge of case and earbuds)
Color	Khaki
Form Factor	Over-Ear (Clip-on)
Headphone Jack	No Jack

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Please note that the manufacturer's warranty information is not explicitly provided in the product specifications. For details regarding warranty coverage, please refer to the product packaging or contact TOZO customer support directly.

9.2 Customer Support

For any questions, technical assistance, or support regarding your TOZO OpenEarRing Wireless Earbuds, please visit the official TOZO website or contact their customer service team. Contact information can typically be found on the product packaging or on the TOZO official website.

© 2025 TOZO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question