

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Need](#) /
- > [Need L Shaped Folding Desk \(Model 10HBNDAC11-140BB-N\) Instruction Manual](#)

Need 10HBNDAC11-140BB-N

Need L Shaped Folding Desk Instruction Manual

Model: 10HBNDAC11-140BB-N

1. PRODUCT OVERVIEW

The Need L Shaped Folding Desk is a versatile and space-saving workstation designed for home offices, gaming setups, and various other activities. Its reversible and foldable design allows for flexible configuration and easy storage or relocation. Constructed with durable materials, this desk provides a stable and ample workspace.



Image 1.1: The Need L Shaped Folding Desk configured for a home office or gaming setup.

2. SAFETY INFORMATION

Please read and adhere to the following safety guidelines to ensure safe use of your desk:

- Always assemble the desk according to the provided instructions.
- Keep the desk on a stable, level surface to prevent wobbling or tipping.
- Avoid placing excessively heavy objects on the edges of the desk. Distribute weight evenly.
- Do not leave the desk unattended while in use, especially by children or pets, to prevent accidents.

3. SETUP AND ASSEMBLY

The Need L Shaped Folding Desk is designed for quick and easy setup. It consists of two main pieces that can be joined to form an L-shape, or used separately. The legs feature a folding mechanism for portability.

3.1. Unpacking

Carefully remove all components from the packaging. Verify that all parts are present before beginning assembly.

3.2. Folding Mechanism

Each desk section features folding legs. To unfold, gently pull the legs outwards until they lock into place. To fold, locate the hinge mechanism and press the release button or lever to allow the legs to collapse inwards. This design facilitates easy transport and storage.




Image 3.1: Detail of the folding leg mechanism and adjustable feet.

3.3. Reversible L-Shape Configuration

The desk's L-shaped configuration is reversible, allowing the shorter section to be attached to either the left or right side of the main desk. This flexibility accommodates different room layouts and user preferences.

1. Position the main desk section in your desired location.
2. Align the smaller, detachable section with either the left or right end of the main desk.
3. Securely attach the two sections using the provided hardware. Ensure all connections are tight for stability.

Two-Way setup

Direction of Writing desk on the Left or Right Side according to Your Habits



Image 3.2: Illustration of the reversible L-shaped setup options.

Extra part can be installed left or right



Image 3.3: Visual guide for attaching the extension on either side.

4. OPERATING AND USAGE

This desk is suitable for a variety of uses:

- **Home Office:** Provides ample space for monitors, laptops, and office supplies.
- **Gaming:** The L-shape offers an expansive surface for multiple screens and gaming peripherals.
- **Crafting/Hobbies:** Utilize the large surface for creative projects.
- **Flexible Workstation:** The ability to separate into two desks or fold for storage makes it adaptable to changing needs.



Image 4.1: Example of the desk used in a home office environment.



Image 4.2: Example of the desk configured for a gaming setup.

5. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your desk:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Protection:** Use coasters for drinks and placemats for hot items to protect the desk surface from stains and heat damage.

6. TROUBLESHOOTING

If you encounter any issues with your desk, consider the following:

- **Wobbling:** Ensure the desk is on a flat surface. Check that all leg connections are securely tightened. The adjustable feet pads can be used to level the desk on uneven floors.

- **Difficulty Folding/Unfolding:** Ensure the hinge mechanisms are clear of obstructions and operate smoothly. Do not force the mechanism.
- **Surface Damage:** For minor scratches, furniture repair kits may be used. For significant damage, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Need
Model Number	10HBNDAC11-140BB-N
Product Dimensions	20.5"D x 54.7"W x 28.7"H
Color	Teak + Black
Style	Modern
Base Material	Metal
Top Material Type	Engineered Wood (E1-grade solid particle wood)
Special Feature	L Shape, Folding Design, Reversible
Item Weight	41 Pounds
Required Assembly	Yes (Minimal)
Tabletop Thickness	1 Inches



Image 7.1: Detailed dimensions of the L Shaped Folding Desk.

8. WARRANTY AND SUPPORT

This Need L Shaped Folding Desk comes with a **Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty documentation included with your purchase or contact Need customer support directly.

For any questions, assistance, or to report issues, please contact Need customer support through their official channels. Contact information can typically be found on the product packaging or the manufacturer's website.