

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [bixdo](#) /

> [Water Flosser Travel Size - Portable Water Flosser Cordless for Teeth Gums Braces Cleaning, Oral Irrigator with 3 Modes, IPX7, Low Noise for Adult Kids, Mini Travel Essentials, A30 Pro Purple Viori Purple](#)

bixdo A30 Pro

bixdo A30 Pro Water Flosser User Manual

Model: A30 Pro

INTRODUCTION

The bixdo A30 Pro Water Flosser is a portable and cordless oral irrigator designed for effective cleaning of teeth, gums, and braces. Featuring three customizable modes and IPX7 waterproofing, it offers a convenient and efficient solution for daily oral hygiene, suitable for both adults and children.



Image: The bixdo A30 Pro Water Flosser in purple, demonstrating its compact design and the various included jet tips and storage bag.

SAFETY INFORMATION

- Do not use with broken or damaged parts.
- Keep away from children.

- Do not use if you have certain medical conditions.
- Unplug and turn off when not in use.
- Do not submerge in water.
- Allow to dry after each use.
- Do not use while sleeping or unconscious.

PACKAGE CONTENTS

Your bixdo A30 Pro Water Flosser package includes the following items:

- 1 x A30 Pro travel water flosser
- 1 x Soft Clean Dual Stream Jet Tip
- 1 x Standard Jet Tip
- 1 x Orthodontic Jet Tip
- 1 x USB Charging Cable
- 1 x Storage Bag
- 1 x Instruction Manual




Image: A visual representation of all items included in the bixdo A30 Pro Water Flosser package, such as the flosser unit, various tips, charging cable, and storage bag.

SETUP

1. Initial Charging

Before first use, fully charge the water flosser. Connect the USB charging cable to the device and a compatible power source (e.g., power adapter, laptop, power bank). A full charge provides up to 28 days of use.

Portable Water Flosser for Travel

28 Day Use on Full Charge



Image: The bixdo A30 Pro Water Flosser connected to a USB charging cable, illustrating its compatibility with different charging methods like power adapters, laptops, and power banks.

2. Filling the Water Tank

Open the water tank cover and fill the 165ml tank with water. Ensure the tank is securely closed after filling to prevent leaks.

Tritan Material of Water Tank & Nozzle Tips

Same Material Selection for Baby Bottles, More Clean and Dishwasher Safe



Image: A hand filling the water tank of the bixdo A30 Pro Water Flosser directly from a faucet, highlighting the ease of refilling.

3. Attaching Nozzles

Select the desired jet tip (Soft Clean Dual Stream, Standard, or Orthodontic) and firmly insert it into the nozzle opening on top of the flosser until it clicks into place. The device also features a built-in compartment for storing nozzles.

bixdo

- ✓ **5x Wide** Effective Teeth Cleaning
- ✓ **20%** Softness Increase
- ✓ Removes **Up to 99.9%** Plaque

OTHERS

- ✗ Causes Sensitive, Bleeding Gums
- ✗ Unable to Effectively Remove Food Debris Below the Gum Line




Image: A close-up view of the bixdo A30 Pro Water Flosser demonstrating how to insert a jet tip and showcasing the convenient internal storage compartment for additional tips.

OPERATING INSTRUCTIONS

1. Powering On/Off

Press the power button to turn the device on. Press it again to turn it off.

2. Mode Selection

The bixdo A30 Pro offers 3 customizable cleaning modes:

- **Gentle Mode:** Suitable for first-time users and sensitive gums.
- **Standard Mode:** For common teeth flossing and gum massage.
- **Pulse Mode:** For cleaning food residue deep inside and periodontal areas, ideal for braces.

To switch between modes, press the mode selection button. The indicator lights will show the currently selected mode.



Image: A visual guide to the three distinct cleaning modes of the bixdo A30 Pro Water Flosser: Gentle, Standard, and Pulse, detailing their recommended applications for various oral care needs.

3. Usage Steps

To use, fill the 165ml tank with water, select one of the 3 cleaning modes (Gentle, Standard, Pulse), and maneuver the tip along the gum line and between teeth. For optimal results, use daily for deep cleaning.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and usage of the bixdo Mini Water Flosser for Adults and Kids, including how to fill the tank, select modes, and effectively clean teeth and gums.



Gentle Mode

For 1st-time users
& sensitive gum

Normal Mode

For common
teeth flossing and
gum massage

Strong Mode

For cleaning food
residue deep
inside and
periodontal

Orthodontics Care

Deeply clean crevice
between teeth, braces
and gum line

Oral Massage

Teeth Care & Improve
Gum Health
Remove food residue
and **99.8%** plaque

Complete Treatment

52% more effective in
improving in orthodontic
gum bleeding
2 times effect in
improving common gum
bleeding and gingivits

Image: A person using the bixdo A30 Pro Water Flosser, emphasizing its IPX7 waterproof design which allows for safe use in the shower.

MAINTENANCE

1. Cleaning the Unit

After each use, clean the unit and allow it to dry. The water tank and nozzle tips are made from Tritan material, which is durable and dishwasher safe for easy cleaning.



IPX7 WATERPROOF

Safe Use in the Shower

Image: A visual representation of the Tritan material used for the water tank and nozzle tips, highlighting its durability, BPA-free nature, and ease of cleaning, similar to baby bottle material.

2. Storage

Store the unit in the provided storage bag. The built-in compartment keeps your nozzles and small accessories organized, making it ideal for travel.

TROUBLESHOOTING

If you encounter any issues with your bixdo A30 Pro Water Flosser, please refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Connect it to the USB charging cable and allow it to charge for a few hours.
- **Weak water pressure:** Check if the water tank is sufficiently filled. Ensure the jet tip is securely attached and not clogged. Clean the tip if necessary.
- **Water leakage:** Verify that the water tank cover is properly sealed and the jet tip is firmly inserted.

- **Unusual noise:** If the device makes an unusual noise, turn it off immediately and check for any obstructions in the water path or nozzle. If the issue persists, contact customer support.

For further assistance, please contact bixdo customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	1.87 x 2.24 x 4.92 inches; 9.91 ounces
Item Model Number	A30 Pro
Batteries	1 Lithium Ion battery required (included)
Manufacturer	bixdo
Power Source	Battery Powered
Special Features	Portable, multi modes, oral irrigator, rechargeable, travel
Product Benefits	Gum Health, Prevents Bad Breath, Prevents Cavities, Removes Plaque
Unit Count	1.0 Count
Wattage	4 Watt-hours
Waterproof Rating	IPX7 (internal and external dual protection)
Noise Level	52.25dB
Tank Capacity	165ml
Pulse Rate	Up to 1500 times per minute

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided in your product packaging or visit the official bixdo website. Keep your purchase receipt for warranty claims.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.