

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bobtot](#) /

› [Bobtot Portable Bluetooth Speaker User Manual](#)

Bobtot ET2240A

Bobtot Portable Bluetooth Speaker User Manual

Model: ET2240A

Brand: Bobtot

1. INTRODUCTION

This manual provides comprehensive instructions for the Bobtot Portable Bluetooth Speaker (Model ET2240A). This device is designed for portable audio playback, featuring IPX7 waterproofing, TWS pairing capability, and a built-in microphone for hands-free calls. Please read this manual thoroughly before using the product to ensure proper operation and longevity.

What's in the Box



The Bobtot Portable Bluetooth Speaker package includes the following items:

- 1 x Portable Bluetooth Speaker (Green)
- 1 x USB Charging Cord
- 1 x Carrying Strap
- 1 x User Manual

2. SAFETY INFORMATION

To ensure safe and optimal performance of your Bobtot Portable Bluetooth Speaker, please observe the following safety guidelines:

- Do not disassemble, repair, or modify the speaker. This may void the warranty and pose safety risks.
- Keep the speaker away from extreme temperatures, direct sunlight, and open flames.
- Although the speaker is IPX7 waterproof, avoid prolonged submersion beyond specified limits (up to 30 feet for 30 minutes). Ensure the charging port cover is securely closed before exposure to water.
- Use only the provided charging cable or a certified equivalent.
- Do not expose the speaker to corrosive liquids.
- Clean the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
- Dispose of the speaker and its battery responsibly according to local regulations.



Image: The speaker's IPX7 waterproof capability allows for use in wet environments.

3. SETUP

3.1 Charging the Speaker

Before first use, fully charge the speaker. The speaker is equipped with a 1200mAh battery.

1. Locate the charging port on the speaker (usually covered by a waterproof flap).
2. Connect the provided USB charging cable to the speaker's charging port.
3. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate. Charging typically takes approximately 3 hours for a full charge.
5. Once fully charged, the indicator light will change or turn off. Disconnect the charging cable and ensure the waterproof flap is securely closed.



Image: The speaker offers extended playing time on a single charge, ideal for outdoor activities.

3.2 Powering On/Off

- **To Power On:** Press and hold the Power button for a few seconds until you hear an audible prompt or see an indicator light.
- **To Power Off:** Press and hold the Power button again for a few seconds until you hear an audible prompt or the indicator light turns off.

4. OPERATING INSTRUCTIONS

4.1 Bluetooth Pairing

The speaker uses Bluetooth 5.3 for stable and fast connections up to 30 feet.

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED). If it's not flashing, it might automatically enter pairing mode upon power-on or require a specific button press (refer to the speaker's physical buttons for a Bluetooth icon).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Bobtot ET2240A" (or similar name) from the list of found devices.
4. Once connected, the speaker will provide an audible confirmation, and the LED indicator will stop flashing.



Image: Easy Bluetooth 5.3 connectivity for seamless audio streaming.

4.2 True Wireless Stereo (TWS) Pairing

You can pair two Bobtot ET2240A speakers together to create a larger, immersive stereo sound experience (20W peak combined output).

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one of the speakers (this will be the primary speaker), double-press the TWS pairing button (or the Play/Pause button if it serves this function). The speaker will enter TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. You will hear an audible confirmation once TWS pairing is successful.
4. Once paired, connect your device to the primary speaker via Bluetooth as described in Section 4.1. The audio will now play through both speakers, with one acting as the left channel and the other as the right channel.



Image: TWS pairing allows two speakers to deliver a wider stereo soundstage.

4.3 Controls and Functions

The speaker features intuitive controls for media playback and calls. While the exact button layout may vary, common functions include:

- **Power Button:** Press and hold to power on/off.
- **Play/Pause Button:** Press once to play or pause music. Double-press to call back the last dialed number (when connected to a phone).
- **Volume Up (+):** Press to increase volume.
- **Volume Down (-):** Press to decrease volume.
- **Next Track:** Long press Volume Up (+) (or dedicated button).
- **Previous Track:** Long press Volume Down (-) (or dedicated button).

4.4 Hands-Free Calling

The built-in microphone allows for convenient hands-free calls and online meetings.

- **Answer Call:** When a call comes in, press the Play/Pause button once to answer.
- **End Call:** During a call, press the Play/Pause button once to end the call.
- **Reject Call:** Press and hold the Play/Pause button to reject an incoming call.
- **Call Back:** Double-press the Play/Pause button to redial the last number.

5. MAINTENANCE

Proper maintenance ensures the longevity and performance of your speaker.

- Cleaning:** Wipe the speaker with a soft, slightly damp cloth. Do not use abrasive cleaners, alcohol, or solvents. Ensure the charging port cover is sealed before cleaning with water.
- Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery to about 50% every few months to preserve battery health.
- Water Exposure:** After exposure to water, especially saltwater or chlorinated water, rinse the speaker with fresh water and allow it to air dry completely before charging or using. Ensure the charging port cover is dry and sealed.

6. TROUBLESHOOTING

If you encounter issues with your Bobtot Portable Bluetooth Speaker, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|----------------------------|---|--|
| Speaker does not power on. | Low battery. | Charge the speaker for at least 3 hours. |
| Cannot pair via Bluetooth. | Speaker not in pairing mode; device Bluetooth off; too far from device; interference. | Ensure speaker is in pairing mode. Turn device Bluetooth off and on. Move speaker closer to device. Clear other Bluetooth devices. |
| No sound or low volume. | Volume too low on speaker or device; speaker not connected; incorrect audio output. | Increase volume on both speaker and connected device. Re-pair the speaker. Check device's audio output settings. |
| TWS pairing fails. | Speakers already connected to other devices; not in TWS pairing mode. | Disconnect both speakers from any Bluetooth devices. Ensure both are powered on and initiate TWS pairing correctly. |
| Sound distortion. | Volume too high; low battery; poor Bluetooth connection. | Reduce volume. Charge the speaker. Move closer to the connected device. |

7. SPECIFICATIONS

Detailed technical specifications for the Bobtot Portable Bluetooth Speaker (Model ET2240A):

Model Name: ET2240A

Brand: Bobtot

Connectivity Technology: Bluetooth 5.3

Wireless Communication Range: Up to 33 Feet (10 meters)

Speaker Type: Portable Speaker

Speaker Size: 2 Inches

Speaker Maximum Output Power: 5 Watts (Single Speaker)

Audio Output Mode: Stereo (with TWS pairing)

Frequency Response: 18 KHz

Special Features: Bass Boost, Built-in Microphone, Lightweight, Stereo Pairing (TWS), Waterproof (IPX7)

Water Resistance Level: IPX7 (Submersible up to 30 ft for 30 minutes)

Power Source: Battery Powered

Battery Capacity: 1200 mAh

Charging Time: Approximately 3 Hours

Playing Time: Up to 15 hours (at 50% volume)

Control Method: Touch (buttons)

Material: Acrylonitrile Butadiene Styrene (ABS)

Product Dimensions: 3.9"D x 2.9"W x 2.7"H (9.9cm x 7.4cm x 6.9cm)

Item Weight: 8.1 ounces (231 Grams)

Included Components: Portable Speaker, Charging Cord, Carrying Strap, User Manual

Manufacturer: MOSWS INTERNATIONAL LIMITED

Date First Available: December 12, 2024




Image: The speaker's 5W output and passive radiators deliver clear, loud sound with enhanced bass.

8. WARRANTY INFORMATION

The Bobtot Portable Bluetooth Speaker comes with an extended warranty. For specific details regarding the warranty period, coverage, and terms and conditions, please refer to the warranty card included in your product packaging or visit the official Bobtot website. Keep your purchase receipt as proof of purchase for warranty claims.


9. CUSTOMER SUPPORT

If you require further assistance, have questions, or encounter issues not covered in this manual, please contact Bobtot customer support:

- **Online Support:** Visit the official Bobtot website or their Amazon Brand Store for FAQs and contact options.
- **Seller Contact:** For purchases made on Amazon, you can contact the seller "Bobtot Direct" through your Amazon order history.

For more information about Bobtot products, visit the [Bobtot Store on Amazon](#).

Related Documents - ET2240A


| | |
|---|--|
|  | <p><u>Bobtot Triangle Portable Wireless Speaker Quick Start Guide</u></p> <p>A quick start guide for the Bobtot Triangle Outdoor Portable Wireless Speaker, covering setup, features, TWS pairing, and specifications.</p> |
|  | <p><u>Bobtot SoundAir Portable Wireless Speaker Quick Start Guide</u></p> <p>Get started with your Bobtot SoundAir portable wireless speaker. This guide covers setup, Bluetooth pairing, TWS mode, charging, specifications, and customer support.</p> |
|  | <p><u>Bobtot Triangle Outdoor Portable Wireless Speaker Quick Start Guide</u></p> <p>A quick start guide for the Bobtot Triangle outdoor portable wireless speaker, covering device overview, buttons and ports, charging instructions, initial setup, and TWS sync mode.</p> |
|  | <p><u>Bobtot B901D 5.1 Channel Home Theater System: Connection Instructions and Setup Guide</u></p> <p>Comprehensive connection instructions and setup guide for the Bobtot B901D 5.1 Channel Home Theater System. Learn how to connect various devices via HDMI ARC, Optical, Coaxial, RCA, Bluetooth, USB, and SD card. Includes troubleshooting and after-sale service information.</p> |
|  | <p><u>Bobtot SoundAir1 Portable Wireless Speaker - Quick Start Guide</u></p> <p>Get started with your Bobtot SoundAir1 portable wireless speaker. This guide covers setup, charging, Bluetooth pairing, TWS mode, and specifications for this IPX6 water-resistant speaker.</p> |
|  | <p><u>Bobtot Sound Air2 Portable Wireless Speaker: Quick Start Guide & User Information</u></p> <p>Get started with your Bobtot Sound Air2 portable wireless speaker. This guide covers packing contents, specifications, device overview, button controls, setup, connectivity, TWS pairing, troubleshooting, warnings, and customer support.</p> |



[Bobtot Triangle Portable Speaker Model Difference - ET2240A, ET2240B](#)

Letter of Model Difference for the Bobtot Triangle Portable Speaker, models ET2240A and ET2240B, FCC ID 2AZ43-ET2240A. Details two appearances with unchanged circuitry and RF chip.


lang:en score:35 filesize: 496.02 K page_count: 1 document date: 2023-03-28



[Confidentiality Request for Triangle Portable Speaker by Bobtot](#)

Official request for confidentiality under sections 0.457 and 0.459 of CFR 47 for the Triangle Portable Speaker, model ET2240A and ET2240B, FCC ID 2AZ43-ET2240A, trademarked Bobtot. This document outlines the need to withhold Block Diagram, Schematics, and Operational Description from public review due to proprietary information.


lang:en score:33 filesize: 164.21 K page_count: 1 document date: 2023-03-28



[Bobtot Triangle Portable Wireless Speaker Quick Start Guide](#)

A quick start guide for the Bobtot Triangle Outdoor Portable Wireless Speaker, covering setup, features, TWS pairing, and specifications.

lang:i-klingon score:25 filesize: 272.34 K page_count: 1 document date: 2023-03-30



[Bobtot Triangle Outdoor Portable Wireless Speaker Quick Start Guide](#)

A quick start guide for the Bobtot Triangle outdoor portable wireless speaker, covering device overview, buttons and ports, charging instructions, initial setup, and TWS sync mode.

lang: i-klingon score:17 filesize: 295.64 K page_count: 5 document date: 2023-07-15



[Bobtot Triangle Outdoor Portable Wireless Speaker Quick Start Guide](#)

Get started with your Bobtot Triangle portable wireless speaker. This quick start guide covers setup, features, specifications, and troubleshooting.

lang: i-klingon score:15 filesize: 176.17 K page_count: 1 document date: 2025-09-24